E-Z-GO DIAGNOSTICS PORT REPAIR INSTRUCTIONS



CAUTION!

Failure to follow the instructions given could result in severe damage to your E-Z-GO RXV.

- 1. Turn the key switch to the off position.
- **2.** Ensure the charger is unplugged from the vehicle.
- **3.** Locate the diagnostics port underneath the seat on the passenger side by the controller, usually zip tied to the red batery cable.



4. If you have wiring loom covering the wires leading to the data port, remove it by peeling back the electrical tape holding it in place.



5. Pull the wiring loom away from the wires.



6. Mark all four wires in a straight line across.



7. Pick **ONE** of the wires to start with. Cut it and move on to step 8.

You should only cut one wire at a time because one of the wires has power and cutting that wire with the ground wire at the same time could blow a circuit in the controller. The repair available for this is a full rebuild of the controller.



8. Strip the wire you just cut on the side leading to the controller.



9. Being sure to match the colors, place the barrel connector on the wire.



10. Crimp the connector. Go back to step 7 and repeat the steps until all four wires are connected.

