



# SIDE TABLE

## - INSTALLATION INSTRUCTIONS -

**1** Remove from packaging

**2** Place mounting bracket on either the left or right front leg

**3** Place as high as possible on the non-moving part of the leg

**4** Angle the mounting bracket at 45 degrees facing out from the chair



**5** Hand tighten the screws

**6** Adjust the angle of the mounting bracket so you can still close the chair without hindrance

**7** Place table into the bracket and check that its movement is not obstructed by the chair arm when swung around

**8** Tighten the screws

### **i** NOTES

- Table must be removed when packing up chair
- Mounting bracket can stay attached to chair once fitted
- Maximum weight on the table is 5 KG
- Undo orange lever to adjust position.
- Press orange button to adjust the angle of the table

### PARTS INCLUDED

- Table on pole (pre-assembled)
- Mounting bracket
- Screws
- Table carry bag

### TOOLS REQUIRED

- Screwdriver