



VT-155SBB: Repairing the Compressor

Using these instructions, you will be able to repair the compressor of the VT-155SBB

Be sure to have the unit *unplugged* while performing the installation.

INSTRUCTIONS:



Locate the compressor at the back of the unit. One side is connected to the process or gas injection tube and the other is connected with the seal tube (on the body of the dry filter, not its two ends). Vacuum the compressor. This process will take about 15 minutes to complete.



Gas injection



Nip the process tube (gas injection tube)



Weld the process tube (gas injection tube).



Nip the seal tube (on the dry filter body) and then weld its end.



Finally, add anti-rust paint at the end of the aforementioned welded process and seal tubes.

Questions?

Contact Vinotemp customer service at 1-800-777-8466 or info@vinotemp.com.