Woodoc Gel Stain Specification Sheet



Typical Application:

For interior use only. Woodoc Gel enriches and enhances the colour and appearance of wood. The intensity of colour is easier to control than with conventional liquid stains. Pine furniture can be turned into rich wood colours, light woods can become darker woods and the colour of darker woods can be enhanced.

Product Features:

- Woodoc Gel Stain should be applied only to wood that is free of any previous coating, waxes or oils.
- Remove any old finishes/layers completely.
- Woodoc Gel Stain does not protect wood. After tinting use a suitable clear sealer/varnish.
- Available in a selected range of woodas well as fashion tints: Traditional Teak, Cherrywood, African Mahogany, Antique Oak, Imbuia, Ebony, Butter, Arizona Orange, Dawn Red, Forever Green, Adriatic Blue, Purple Sky.
- Complete how-to-use instructions on label.

Application Note:

Because the natural colour and absorbency of woods differ, the appearance attained with Woodoc Gel Stain can differ on application. It is recommended that a trial application on a similar piece of timber be carried out first. Apply with a sponge/cloth until the desired colour is achieved. Wait for at least one hour and finish off with a suitable clear sealer/varnish.

No: WGS/002/EU **Dated:** 23/11/11

Name:

Woodoc Gel Stain **Description:** Gel stain for wood

Application:

Apply directly to wood with a sponge/cloth. Discard cloth after use/wash with water immediately after use.

Note: Always wear protective gloves when applying Gel Stain.

Drying Time:

Quick-drying, but wait at least one hour before sealing wood.

Coverage:

Approximately 5 m² per 250 ml bottle (one coat)

Incompatibility:

White spirits, Acetone, Lacquer Thinners, Benzene and other solvents.

Packaging:

250 ml

ALWAYS READ THE DIRECTIONS ON THE BOTTLE BEFORE STARTING WORK. PRODUCT WILL STAIN CLOTHES. PLEASE BE CAREFUL WHEN USING PRODUCT.

FLAMMABLE. Keep out of reach of children. Harmful if ingested. Drink 3 – 5 glasses of water. Prevent vomiting. Consult a medial doctor immediately. Skin contact: immediately rinse off with water. Eye contact: rinse thoroughly with water.



Manufactured and marketed by: Rekara Mills (Pty) Ltd PO Box 16, Fort Beaufort 5720, South Africa Tel +2746 645 1109 Fax +2746 645 1538

European Distribution: Woodoc Europe Tel. +44 (0)1223 655 686 Fax +44 (0)1223 280 388 info@woodoc.eu