

# DANGER

KEEP OUT OF REACH OF CHILDREN  
READ SAFETY DIRECTIONS BEFORE OPENING OR USING

# NOVITHOR™

THE PESTICIDE FREE  
TERMITE PROTECTION SYSTEM

# TPC Powder

Contents: 20 kg



Ensyslex Australasia Pty Ltd ABN 53 102 221 965

Warehouse D, Building 6, The Switchyard  
161 Manchester Road Auburn NSW 2144

[www.NOVITHOR.com](http://www.NOVITHOR.com)

CUSTOMER SERVICE 13 35 36

™ Trademark of Ensyslex Inc. used under licence by Ensyslex Australasia Pty Ltd.

## DIRECTIONS FOR USE

**NOVITHOR Cementitious Parge** is a two part system.

This product, NOVITHOR TPC Powder, should be mixed with NOVITHOR TPC Liquid, at a ratio of 20 kg NOVITHOR TPC Powder : 5 L NOVITHOR TPC Liquid (4:1)

Mix NOVITHOR TPC Powder and NOVITHOR TPC Liquid at the correct ratio with a low speed mechanical paddle mixer until a smooth, lump free, brushable paste is achieved. Apply the paste by brush or trowel to the substrate to a minimum thickness of 4 mm. The combined product, **NOVITHOR Termite Proof Cementitious Parge** has a working time of 1 hour. The pot life is 4 hours if the pot is sealed. The cure time is 24 hours.

## SUBSTRATE PREPARATION

Substrate must be structurally sound, clean and free of loose particles, dust, dirt, oils, grease, wax or other contaminating materials.

## CLEAN UP

Clean all tools and application equipment with water.

## STORAGE

Store locked up. Check with your local Council regarding the disposal of contents. Keep out of the reach of children.

## SAFETY DIRECTIONS

This product may cause irritation and an allergic reaction to the skin. It may cause serious eye injury and irritation to the respiratory system. Wear protective gloves, clothing, eye and face protection. Avoid inhaling dust/ fumes/ gas/ mist/ vapours/ spray. Ensure adequate ventilation during mixing and application.

## FIRST AID

**Eye Contact:** Immediately hold eyelids apart and flush the eye continuously with running water. Ensure complete irrigation of the eye by keeping eyelids apart and away from eye and moving the eyelids by occasionally lifting the upper and lower lids. Continue flushing until advised to stop by the Poisons Information Centre 13 11 26 or a doctor, or for at least 15 minutes.



Transport to hospital or doctor without delay. Removal of contact lenses after an eye injury should only be undertaken by skilled personnel.

**Skin Contact:** Immediately flush body and clothes with large amounts of water, using safety shower if available. Quickly remove all contaminated clothing, including footwear. Wash skin and hair with running water. Continue flushing with water until advised to stop by the Poisons Information Centre, or for at least 15 minutes. Transport to hospital, or doctor. **Inhalation:** Lay patient down. Keep warm and rested. Prostheses such as false teeth, which may block the airway, should be removed, where possible, prior to initiating first aid procedures. Apply artificial respiration if not breathing, preferably with a demand valve resuscitator, bag-valve mask device, or pocket mask as trained. Perform CPR if necessary. Transport to hospital, or doctor, without delay.

**Ingestion:** Do NOT induce vomiting. If vomiting occurs, lean patient forward or place on left side (head-down position, if possible) to maintain open airway and prevent aspiration. Observe the patient carefully. Never give liquid to a person showing signs of being sleepy or with reduced awareness i.e., becoming unconscious. Give water to rinse out mouth, then provide liquid slowly and as much as casualty can comfortably drink. Seek medical advice.

## SAFETY DATA SHEET

Additional information is listed on the Safety Data Sheet which is available from Ensyslex on request. Call Customer Service 13 35 36 or visit our web site at [www.Ensyslex.com.au](http://www.Ensyslex.com.au).

**NOTICE:** Ensyslex warrants that this product conforms to its chemical description and is reasonably fit for the purposes stated on the label when used in accordance with Directions for Use under normal conditions of use. No warranty of merchantability or fitness for a particular purpose, express or implied, extends to the use of the product contrary to label instructions or under abnormal conditions.

**See the details stamped on the front of the bag for Batch Number and Date of Manufacture.**

L-AU-NOVI1003 4.2 05.23