

User Manual

2.4-inch Visible Light Terminal

Date: December 2023

Doc Version: 1.0

English

Thank you for choosing our product. Please read the instructions carefully before operation. Follow these instructions to ensure that the product is functioning properly. The images shown in this manual are for illustrative purposes only.



For further details, please visit our Company's website www.zkteco.com.

Copyright © 2023 ZKTECO CO., LTD. All rights reserved.

Without the prior written consent of ZKTeco, no portion of this manual can be copied or forwarded in any way or form. All parts of this manual belong to ZKTeco and its subsidiaries (hereinafter the "Company" or "ZKTeco").

Trademark

ZKTECO is a registered trademark of ZKTeco. Other trademarks involved in this manual are owned by their respective owners.

Disclaimer

This manual contains information on the operation and maintenance of the ZKTeco equipment. The copyright in all the documents, drawings, etc. in relation to the ZKTeco supplied equipment vests in and is the property of ZKTeco. The contents hereof should not be used or shared by the receiver with any third party without express written permission of ZKTeco.

The contents of this manual must be read before starting the operation and maintenance of the supplied equipment. If any of the content(s) of the manual seems unclear or incomplete, please contact ZKTeco before starting the operation and any information contained in this manual or any of the amendments made thereto. ZKTeco does not extend the warranty of any kind, including, without limitation, any warranty of design, merchantability, or fitness for a particular purpose. ZKTeco does not assume responsibility for any errors or omissions in the information or documents which are referenced by or linked to this manual. The entire risk as to the results and performance obtained from using the information is assumed by the user.

ZKTeco in no event shall be liable to the user or any third party for any incidental, consequential, indirect, special, or exemplary damages, including, without limitation, loss of business, loss of profits, business interruption, loss of business information or any pecuniary loss, arising out of, in connection with, or relating to the use of the information contained in or referenced by this manual, even if ZKTeco has been advised of the possibility of such damages.

This manual and the information contained therein may include technical, other inaccuracies or typographical errors. ZKTeco periodically changes the information herein which will be incorporated into new additions/amendments to the manual. ZKTeco reserves the right to add, delete, amend, or modify the information contained in the manual from time to time in the form of circulars, letters, notes, etc. for better operation and safety of the machine/unit/equipment. The said additions or amendments are meant for improvement /better operations of the machine/unit/equipment and such amendments shall not give any right to claim any compensation or damages under any circumstances.

ZKTeco shall in no way be responsible (i) in case the machine/unit/equipment malfunctions due to any non-compliance of the instructions contained in this manual (ii) in case of operation of the machine/unit/equipment beyond the rate limits (iii) in case of operation of the machine and equipment in conditions different from the prescribed conditions of the manual.

The product will be updated from time to time without prior notice. The latest operation procedures and relevant documents are available on http://www.zkteco.com

If there is any issue related to the product, please contact us.

ZKTeco Headquarters

Address ZKTeco Industrial Park, No. 32, Industrial Road,

Tangxia Town, Dongguan, China.

Phone +86 769 - 82109991

Fax +86 755 - 89602394

For business-related queries, please write to us at sales@zkteco.com.

To know more about our global branches, visit <u>www.zkteco.com</u>.

About the Company

ZKTeco is one of the world's largest manufacturer of RFID and Biometric (Fingerprint, Facial, Finger-vein) readers. Product offerings include Access Control readers and panels, Near & Far-range Facial Recognition Cameras, Elevator/floor access controllers, Turnstiles, License Plate Recognition (LPR) gate controllers and Consumer products including battery-operated fingerprint and face-reader Door Locks. Our security solutions are multi-lingual and localized in over 18 different languages. At the ZKTeco state-of-the-art 700,000 square foot ISO9001-certified manufacturing facility, we control manufacturing, product design, component assembly, and logistics/shipping, all under one roof.

The founders of ZKTeco have been determined for independent research and development of biometric verification procedures and the productization of biometric verification SDK, which was initially widely applied in PC security and identity authentication fields. With the continuous enhancement of the development and plenty of market applications, the team has gradually constructed an identity authentication ecosystem and smart security ecosystem, which are based on biometric verification techniques. With years of experience in the industrialization of biometric verifications, ZKTeco was officially established in 2007 and now has been one of the globally leading enterprises in the biometric verification industry owning various patents and being selected as the National High-tech Enterprise for 6 consecutive years. Its products are protected by intellectual property rights.

About the Manual

This manual introduces the operations of **2.4-inch Visible Light Terminal**.

All figures displayed are for illustration purposes only. Figures in this manual may not be exactly consistent with the actual products.

Features and parameters with \star are not available in all devices.

Document Conventions

Conventions used in this manual are listed below:

GUI Conventions

For Software		
Convention	Description	
Bold font	Used to identify software interface names e.g., OK, Confirm, Cancel.	
>	Multi-level menus are separated by these brackets. For example, File > Create > Folder.	
For Device		
	Description	
Convention	Description	
Convention <>	Description Button or key names for devices. For example, press <ok>.</ok>	

Symbols

Convention	Description	
	This represents a note that needs to pay more attention to.	
P	The general information which helps in performing the operations faster.	
*	The information which is significant.	
۷	Care taken to avoid danger or mistakes.	
	The statement or event that warns of something or that serves as a cautionary example.	

Table of Contents

1	SAFETY MEASURES8			8
2	EL	ECT	RICAL SAFETY	9
3	0	PERA	TION SAFETY	10
4	IN	STR	UCTION FOR USE	12
	4.1	Find	GER POSITIONING 🛨	
	4.2	Sta	NDING POSITION, FACIAL EXPRESSION AND STANDING POSTU	re 13
	4.3	Reg	ISTRATION OF FACE TEMPLATE	
	4.4	Sta	NDBY INTERFACE	
	4.5	VIRT	rual Keyboard	18
	4.6	Ver	IFICATION MODE	
	4.6	5.1		19
	4.6	5.2	FACIAL VERIFICATION	22
	4.6	5.3		24
	4.6	5.4	QR CODE VERIFICATION *	27
	4.6	5.5	Password Verification	27
	4.6	5.6	COMBINED VERIFICATION	30
5	0	/ER\	/IEW	32
	5.1	Арр	EARANCE	
	5.2	CON	INECTION CABLES AND WIRING DESCRIPTION	
	5.2	2.1	CONNECTION CABLES	33
	5.2	2.2	WIRING DESCRIPTION	35
6	IN	STA	LLATION	
	6.1	Ілут	ALLATION ENVIRONMENT	
	6.2	Dev	ICE INSTALLATION	
7	M	AIN	MENU	40
8	US	SER I	MANAGEMENT	42
	8.1	Use	R REGISTRATION	
	8.1	1.1	Register a User ID and Name	42
	8.	1.2	User Role	43
	8.1	1.3	Register Fingerprint★	44
	8.1	1.4	Face	44

	8.1	1.5 Card★	45
	8.1	1.6 Password	46
	8.1	1.7 Access Control Role	47
	8.2	SEARCH USER	48
	8.3	EDIT USER	49
	8.4	Delete User	50
	8.5	DISPLAY STYLE	51
9	US	SER ROLE	53
10	CC	OMMUNICATION SETTINGS	<mark> 56</mark>
	10.1	NETWORK SETTINGS	56
	10.2	2 Serial Comm	<mark></mark> 58
	10.3	PC CONNECTION	59
	10.4	WI-FI SETTINGS	60
	10.5	5 CLOUD SERVER SETTING	64
	10.6	5 WIEGAND SETUP	65
	10	0.6.1 WIEGAND INPUT	65
	10	0.6.2 WIEGAND OUTPUT	69
	10.7	⁷ Network Diagnosis	70
11	SY	/STEM SETTINGS	71
	11.1	DATE AND TIME	72
	11.2	2 Access Logs Setting	74
	11.3	FACE PARAMETERS	76
	11.4	FINGERPRINT *	80
	11.5	5 FACTORY RESET	82
	11.6	5 SECURITY SETTINGS	83
12	PE	ERSONALIZE SETTINGS	85
	12.1	INTERFACE SETTINGS	85
	12.2	2 Voice Settings	87
	12.3	BELL SCHEDULES	88
	12.4	PUNCH STATES OPTIONS	90
	12.5	5 SHORTCUT KEY MAPPINGS	92
13	DA	ATA MANAGEMENT	96
	13.1	DELETE DATA	96

14	ACCESS CONTROL	98
	14.1 Access Control Options	
	14.2 TIME SCHEDULE	102
	14.3 Holidays	104
	14.4 COMBINED VERIFICATION	105
	14.5 ANTI-PASSBACK SETUP	107
	14.6 DURESS OPTIONS SETTINGS	109
15	USB MANAGER	111
	15.1 DOWNLOAD	
	15.2 UPLOAD	<u>112</u>
16	ATTENDANCE SEARCH	<u>1</u> 13
17	AUTOTEST	115
18	SYSTEM INFORMATION	
19	CONNECT TO ZKBIO CVACCESS SOFTWARE	118
	19.1 SET THE COMMUNICATION ADDRESS	
	19.2 ADD Device on the Software	119
	19.3 ADD PERSONNEL ON THE SOFTWARE	
	19.4 Mobile Credential *	121
AP	PENDIX 1	126
	REQUIREMENTS OF LIVE COLLECTION AND REGISTRATION OF VISIBLE I	LIGHT FACE
	TEMPLATES	126
	REQUIREMENTS FOR VISIBLE LIGHT DIGITAL FACE TEMPLATE DATA	
AP	PENDIX 2	129
	PRIVACY POLICY	
EC	O-FRIENDLY OPERATION	133

1 Safety Measures

The below instructions intend to ensure that the user can use the product correctly to avoid danger or property loss. The following precautions are to keep users safe and prevent any damage. Please read carefully before installation.

Noncompliance with instructions could lead to product damage or physical injury (may even cause death).

- 1. Read, follow, and retain instructions All safety and operational instructions must be properly read and followed before bringing the device into service.
- Do not ignore warnings Adhere to all warnings on the unit and in the operating instructions.
- Accessories Use only manufacturer-recommended or product-sold accessories. Please do not use any other components other than manufacturer suggested materials.
- Precautions for the installation Do not place this device on an unstable stand or frame. It may fall and cause serious injury to persons and damage to the device.
- Service Do not try to service this unit yourself. Opening or removing covers may expose you to hazardous voltages or other hazards.
- 6. Damage requiring service Disconnect the system from the Mains AC or DC power source and refer service personnel under the following conditions:
 - When cord or connection control is affected.
 - When the liquid spilled, or an item dropped into the system.
 - If exposed to water or due to inclement weather (rain, snow, and

more).

If the system is not operating normally, under operating instructions.

Just change controls defined in operating instructions. Improper adjustment of the controls may result in damage and involve a qualified technician to return the device to normal operation.

And do not connect multiple devices to one power adapter as adapter overload can cause over-heat or fire hazard.

- Replacement parts When replacement parts are needed, service technicians must only use replacement parts provided by the supplier. Unauthorized substitutes can result in a burn, shock, or other hazards.
- 8. Safety check On completion of service or repair work on the unit, ask the service technician to perform safety checks to ensure proper operation of the device.
- 9. **Power sources** Operate the system only from the label's power source form. If the sort of power supply to use is unclear, call your dealer.
- **10. Lightning** Can install external lightning conductors to protect against electrical storms. It stops power-ups from destroying the system.

Recommended installing the devices in areas with limited access.

2 Electrical Safety

- Before connecting an external cable to the device, complete grounding properly, and set up surge protection; otherwise, static electricity will damage the mainboard.
- Make sure that the power has been disconnected before you wire, install, or dismantle the device.
- Ensure that the signal connected to the device is a weak-current (switch)

signal; otherwise, components of the device will get damaged.

- Ensure that the standard voltage applicable in your country or region is applied. If you are not sure about the endorsed standard voltage, please consult your local electric power company. Power mismatch may cause a short circuit or device damage.
- In the case of power supply damage, return the device to the professional technical personnel or your dealer for handling.
- To avoid interference, keep the device far from high electromagnetic radiation devices, such as generators (including electric generators), radios, televisions, (especially CRT) monitors, or speakers.

3 Operation Safety

- If smoke, odour, or noise rise from the device, turn off the power at once and unplug the power cable, and then please contact the service centre.
- Transportation and other unpredictable causes may damage the device hardware. Check whether the device has any intense damage before installation.
- If the device has major defects that you cannot solve, contact your dealer as soon as possible.
- Dust, moisture, and abrupt temperature changes can affect the device's service life. You are advised not to keep the device under such conditions.
- Do not keep the device in a place that vibrates. Handle the device with care. Do not place heavy objects on top of the device.
- Do not apply rosin, alcohol, benzene, pesticides, and other volatile substances that may damage the device enclosure. Clean the device accessories with a piece of soft cloth or a small amount of cleaning agent.
- If you have any technical questions regarding usage, contact certified or

experienced technical personnel.

<u>Note</u>:


- Make sure whether the positive polarity and negative polarity of the DC 12V power supply is connected correctly. A reverse connection may damage the device. It is not advisable to connect the AC 24V power supply to the DC 12V input port.
- Make sure to connect the wires following the positive polarity and negative polarity shown on the device's nameplate.
- The warranty service does not cover accidental damage, damage caused by mis-operation, and damage due to independent installation or repair of the product by the user.

4 Instruction for Use

Before getting into the device features and functions, it is recommended to be familiar with the below fundamentals.

4.1 Finger Positioning★


Recommended fingers: Index, middle, or ring fingers; avoid using the thumb or pinky, as they are difficult to accurately press onto the fingerprint reader.



Note: Please use the correct method when pressing your fingers onto the fingerprint reader for registration and identification. Our company will assume no liability for recognition issues that may result from incorrect usage of the product. We reserve the right of final interpretation and modification concerning this point.

4.2 Standing Position, Facial Expression and Standing Posture

> The recommended distance



The distance between the device and a user whose height is in a range of 1.55m to 1.85m is recommended to be 0.3 to 1.2m. Users may slightly move forward or backward to improve the character of facial images captured.

Recommended standing posture and facial expression




Facial Expression

Standing Posture

<u>Note</u>: Please keep your facial expression and standing posture natural while enrolment or verification.

4.3 Registration of Face Template

Try to keep the face in the centre of the screen during registration. Please face the camera and stay still during face template registration. The screen looks like this:



Correct face template registration and authentication method

- Recommendation for registering a face
 - When registering a face, maintain a distance of 50cm to 80cm between the device and the face.
 - Be careful to keep your facial expression natural and not to change. (smiling face, drawn face, wink, etc.)
 - If you do not follow the instructions on the screen, the face registration may take longer or may fail.
 - Be careful not to cover the eyes or eyebrows.

- Do not wear hats, masks, sunglasses or eyeglasses.
- Be careful not to display two faces on the screen. Register one person at a time.
- It is recommended for a user wearing glasses to register both faces with and without glasses.

Recommendation for authenticating a face

- Ensure that the face appears inside the guideline displayed on the screen of the device.
- Sometimes, authentication may fail due to the change in the wearing glasses then the one used while registration. In such a case, you may require authenticating your face with the previously worn glasses. If your face was registered without glasses, you should authenticate your face without glasses further.
- If a part of the face is covered with a hat, a mask, an eye patch, or sunglasses, authentication may fail. Do not cover the face, allow the device to recognize both the eyebrows and the face.

4.4 Standby Interface

After connecting the power supply, the following standby interface is displayed:



- Tap ¹/₂ to enter the User ID input interface.
- When there is no Super Administrator set in the device, tap 👫 to go to the menu.
- After adding a Super Administrator on the device, it requires the Super Administrator's verification before opening the menu functions.

	• 15:39			
4	Please input user ID.			
	1	2	3	\times
	4	5	6	^
	7	8	9	\sim
	5	0	123	ок

Note: For the security of the device, it is recommended to register a super administrator the first time you use the device.

• The punch state options can also be displayed and used directly on the standby interface. Tap anywhere on the screen apart from the icons, and six shortcut keys appears on the screen, as shown in the figure below:



 Press the corresponding punch state key to select your current punch state, which is displayed in green. Please refer to "Shortcut Key Mappings" for the specific operation method.

Note: The punch state options are off by default and need to select other mode options in the "Punch State Option" to get the punch state options on the standby screen.

4.5 Virtual Keyboard



<u>Note:</u> The device supports the input in English language, numbers, and symbols.

- Tap [EN] to switch to the numeric keyboard.
- Press [123] to switch to the symbolic keyboard.
- Tap [@#&] to return to the English keyboard.
- Tap [) to exit the virtual keyboard.

4.6 Verification Mode

4.6.1 Fingerprint Verification★

> 1:N Fingerprint Verification Mode

Compares the fingerprint that is being pressed onto the fingerprint reader with all of the fingerprint data that is stored in the device.

The device enters the fingerprint authentication mode when a user presses his/her finger onto the fingerprint scanner.

Please follow the correct way to place your finger onto the sensor. For details, please refer to section Finger Positioning.

▲ 15:37 III ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲
 ▲ 15:38 ▲

1:1 Fingerprint Verification Mode

Compares the fingerprint that is being pressed onto the fingerprint reader with the fingerprints that are linked to User ID input via the virtual keyboard.

Verification is successful:

Verification is failed:

Users may verify their identities with 1:1 verification mode when they cannot gain access with 1: N authentication method.


Press on the main interface and enter the 1:1 fingerprint verification mode.

Input the user ID and press [OK].



If an employee registers a face template, password and card in addition to the


fingerprint, the following screen will appear. Select the $\widehat{\mbox{\ensuremath{\widehat{m}}}}$ icon to enter fingerprint verification mode.



4.6.2 Facial Verification

> 1:N Facial Verification Mode

It compares the acquired facial templates with all face template data registered in the device. The following is the pop-up prompt box of comparison results.



> 1:1 Facial Verification Mode

Compare the face captured by the camera with the facial template related to the entered user ID.


Press un the main interface and enter the 1:1 facial verification mode.

Enter the user ID and click [OK].




If an employee registers a fingerprint, password and card in addition to the face

template, the following screen will appear. Select the 🗣 icon to enter face verification mode.



After successful verification, the prompt box displays "**Successfully Verified.**", as shown below:




If the verification is failed, it prompts "Please adjust your position!".

4.6.3 Card Verification 🖈

> 1: N Card Verification Mode

The 1: N Card Verification mode compares the card number in the card induction area with all the card number data registered in the device; The following is the card verification screen.



> 1:1 Card Verification Mode

The 1:1 Card Verification mode compares the card number in the card induction area with the number associated with the employee's User ID registered in the device.

Press unthe main interface and enter the 1:1 card verification mode.

Enter the user ID and click [OK].



If an employee registers a fingerprint, face template and password in addition


to the card, the following screen will appear. Select the icon to enter card verification mode.



4.6.4 QR Code Verification ★

In this verification mode, the device compares the QR code image collected by the QR code collector with all the QR code data in the device.

Tap **Mobile Credential** on the ZKBioAccess Mobile Page, and a QR code will appear, which includes employee ID and card number (static QR code only includes card number) information. The QR code can replace a physical card on a specific device to achieve contactless authentication. Please refer to <u>19.4</u> <u>Mobile Credential</u>.




4.6.5 Password Verification

The device compares the entered password with the registered password of the given User ID.

Tap the button on the main screen to enter the 1:1 password verification mode. Then, input the user ID and press [**OK**].




If an employee registers a fingerprint, face template and card in addition to the password, the following screen will appear. Select the *science* icon to enter password verification mode.



Input the password and press [OK].



Below are the display screens after entering a correct password and a wrong password, respectively.



4.6.6 Combined Verification

This device allows you to use a variety of verification methods to increase security. There are a total of 21 distinct verification combinations that can be implemented, as listed below:

Combined Verification	Symbol Definition
------------------------------	--------------------------

Symbol	Definition	Explanation
1	or	This method compares the entered verification of a person with the related verification template previously stored to that Personnel ID in the Device.
+	and	This method compares the entered verification of a person with all the verification templates previously stored to that Personnel ID in the Device.

 Verification Mode
Password/Fingerprint/Card/Face
⊖ Fingerprint Only
⊖User ID Only
Password
Card Only


Procedure to set for Combined Verification Mode

- Combined verification requires personnel to register all the different verification methods. Otherwise, employees will not be able to successfully verify the combined verification process.
- For instance, when an employee has registered only for the face template data, but the Device verification mode is set as "Face + Password", the employee will not be able to complete the verification process successfully.
- This is because the Device compares the face template of the person with the registered verification template (both the face template and the Password) previously stored to that Personnel ID in the Device.
- But as the employee has registered only the face template but not the Password, the verification will not get completed and the Device displays "Verification Failed".

5 Overview

5.1 Appearance

SpeedFace V3L:




5.2 Connection Cables and Wiring Description

5.2.1 Connection Cables



Giru			
Pin	Description		
6	Power In		
Pin	Description		
4	Network		
	Description		
Pin	Description		
Pin 4	Description USB		
	USB		
4	USB 485A 485A 485A 485A 485A 485A 485A 485A 485A 485A 100 100 100 12V-OUT		






Pin		Description
	NC	
	СОМ	Lock
	NO	
12	SEN	
	GND	
	BUT	Door sensor, Exit Button and Auxiliary In
	AUX	
	GND	

BELL+	Bell
BELL-	Dell
ALARM+	
ALARM-	Alarm

5.2.2 Wiring Description

Press 👫 on the initial interface to enter the main menu, as shown below:

Power Connection




Recommended AC Adapter

- 1. 12V ± 10%, at least 1500mA.
- To share the power with other devices, use an AC Adapter with higher current ratings.

Ethernet Connection

Connect the device and computer software over an Ethernet cable. As shown in the example below:




Click on [COMM.] > [Ethernet] > [IP Address], input the IP address and click on [OK].

Note: In LAN, the IP addresses of the server (PC) and the device must be in the same network segment when connecting to the ZKBio CVAccess software.

> USB Connection


The device supports the connection of KF1000-U reader \bigstar and USB disk.

KF1000-U Reader★:



For more details, please refer to the KF1000-U User Manual.


USB Disk:



For more details, please refer to the <u>15 USB Manager</u>.


RS485 and Wiegand Connection

RS485:




<u>Note:</u> 485A and 485B can be connected to the Barrier gate or the 485 Reader, separately, but cannot be connected to the gate and reader at the same time.

Wiegand:




Lock Relay Connection

The system supports Normally Opened Lock and Normally Closed Lock. The NO LOCK (normally unlocked when power-on) is connected with 'NO' and 'COM' terminals, and the NC LOCK (normally locked when power-on) is connected with 'NC' and 'COM' terminals. Take NC Lock as an example below:



Door Sensor, Exit Button, Alarm & Auxiliary Connection



6 Installation

6.1 Installation Environment

Please refer to the following recommendations for installation.












6.2 Device Installation


- 1. Attach the mounting template sticker to the wall, and drill holes according to the mounting paper.
- 2. Fix the backplate on the wall using wall mounting screws.
- 3. Attach the device to the backplate.
- 4. Fasten the device to the backplate with a security screw.





4

0






8

7 Main Menu

Press 👫 on the initial interface to enter the main menu, as shown below:



Menu	Description	
User Mgt.	To Add, Edit, View, and Delete information of a User.	
User Role	To set the permission scope of the custom role and enroller for the users, that is, the rights to operate the system.	
СОММ.	To set the relevant parameters of Network, Serial Comm., PC Connection, Wi-Fi, Cloud Server, Wiegand and Network Diagnosis.	
System	To set parameters related to the system, including Date & Time, Access Logs Setting, Face & Fingerprint parameters, Video Intercom parameters, Security Setting and resetting to factory settings.	
Personalize	To customize settings of User Interface, Voice, Bell Schedules, Punch State Options and Shortcut Key Mappings settings.	
Data Mgt.	To delete all relevant data in the device.	
Access Control	To set the parameters of the lock and the relevant access control device including options like Time schedule, Holiday Settings, Combine verification, Anti-Passback Setup, and Duress Option Settings.	
USB Manager	To upload or download specific data from a USB drive.	
Attendance Search	To query the specified Event logs.	
Autotest	To automatically test whether each module functions properly, including the LCD Screen, Audio, Microphone, Fingerprint sensor, Camera, and Real-Time Clock.	
System Info	To view Privacy Policy, Data Capacity and Device and Firmware information of the current device.	

8 User Management

8.1 User Registration

Tap **User Mgt.** on the main menu.



8.1.1 Register a User ID and Name

Tap New User and enter the User ID and Name.

♠	New User	11	♠	New User	11
User ID			Fingerprint		
		2			O
Name			Face		
					O
User Role			Card Number	r	
	Normal Us	ser			
Fingerprint			Password		
		0			
Face			Access Cont	trol Role	
		0			

Note:

- 1) A name can take up to 36 characters.
- 2) The user ID may contain 1-14 digits by default, support number and <u>alphabetic</u>.
- 3) During the initial registration, you can modify your ID but not after the registration.
- If the message "Duplicated!" appears, you must choose a different User ID because the one you entered already exists.

8.1.2 User Role

On the New User interface, tap on **User Role** to set the user's duty as either **Normal User or Super Admin**.

- Super Admin: The Super Administrator owns all management privileges
 in the Device.
- Normal User: If the Super Admin is registered already in the device, then the Normal Users will not have the privilege to manage the system and can only access authentic verifications.
- User Defined Roles: The Normal User can also be assigned custom roles with User Defined Role. The user can be permitted to access several menu options as required.




<u>Note</u>: If the selected user role is the Super Admin, then the user must pass the identity authentication to access the main menu. The authentication is based

on the authentication method(s) that the super administrator has registered.

8.1.3 Register Fingerprint 🖈

Tap **Fingerprint** in the **New User** interface to enter the fingerprint registration page.

- Select the finger to be enrolled.
- Press the same finger on the fingerprint reader three times.
- Green indicates that the fingerprint was enrolled successfully.




8.1.4 Face

Tap **Face** in the **New User** interface to enter the face registration page.

- Please face towards the camera and place yourself in such a way that your face image fits inside the white guiding box and stays still during face registration.
- A progress bar shows up while registering the face and then "Enrolled

Successfully" message is displayed as the progress bar completes.


• If the face is registered already then, the "**Duplicated Face**" message shows up. The registration interface is as follows:



8.1.5 Card 🛨

Tap **Card** in the **New User** interface to enter the card registration page.

- Swipe the card underneath the card reading area on the Card interface. The registration of the card will be successful.
- If the card has already been registered, the message "Error! Card already enrolled" appears. The registration interface looks like this:



8.1.6 Password

Tap **Password** in the **New User** interface to enter the password registration page.

- On the Password interface, enter the required password and re-enter to confirm it and tap **OK**.
- If the re-entered password is different from the initially entered password, then the device prompts the message as "Password does not match!", where the user needs to re-confirm the password again.
- The password may contain 6 to 8 digits by default.



8.1.7 Access Control Role

The **Access Control Role** sets the door access privilege for each user. It includes the access group, verification mode and it facilitates setting the group access time period.

- Tap Access Control Role > Access Group to assign the registered users to different groups for better management. New users belong to Group 1 by default and can be reassigned to other groups. The device supports up to 99 Access Control groups.
- Tap **Time Period**, to select the time to use.
- The user may specify one or more fingerprints that have been registered as a duress fingerprint(s). When press the finger corresponding to the duress fingerprint on the sensor and pass the verification, the system will immediately generate a duress alarm.

Access Control	A Duress Fingerprint
Access Group	
1	
Time Period	
Duress Fingerprint	
Undefined	
	Please select duress fingerprint.

8.2 Search User

On the Main Menu, tap User Mgt., and then tap All Users to search a User.

 On the All-Users interface, tap on the search bar on the user's list to enter the required retrieval keyword (where the keyword may be the user ID, surname, or full name) and the system will search for the related user information.

🔦 User Mgt.	•	All Users 1
New User	1 Lucy	ŝ∎ \$
All Users	2 Mik e	1 @
🕗 Display Style	3 Jame	@ ?S
	4 Shaw	ي ۱
	Q	

8.3 Edit User

On the **All-Users** interface, tap on the required user from the list and tap **Edit** to edit the user information.

•	User: 1 Lucy	♠	Edit : 1 Lucy	11
Edit		User ID		
				1
Delete		Name		
				Lucy
		User Role		
			Norma	al Us e r
		Fingerprint		
				1
		Face		
				1

Note: The process of editing the user information is the same as adding a new user, except that the User ID cannot be modified while editing a user. The process in detail refers to "6.1 User Registration".

8.4 Delete User

On the **All-Users** interface, tap on the required user from the list and tap **Delete** to delete the user or specific user information from the device. On the **Delete** interface, tap on the required operation, and then tap **OK** to confirm the deletion.


Delete Operations

- Delete User: Deletes all the user information (deletes the selected User as a whole) from the Device.
- Delete Fingerprint Only: Deletes the fingerprint information of the selected user.
- **Delete Face Only:** Deletes the face information of the selected user.
- Delete Password Only: Deletes the password information of the selected user.
- Delete Card Number Only: Deletes the card information of the selected user.

Ser : 1 Lucy	 ♠ Delete : 1 Lucy
Edit	Delete User
Delete	Delete Fingerprint Only
	Delete Face Only
	Delete Password Only
	Delete Card Number Only

8.5 Display Style

On the **Main Menu**, tap **User Mgt.**, and then tap **Display Style** to enter Display Style setting interface.



All the Display Styles are shown as below:

Multiple Line:

Mixed Line:

•	All Users 1	•	All Users 1
1	Lucy	1	🕸 1 H 🚳
@∎:(3	Lucy	
2	Mike	2	3 @
@ L		Mike	
3	James	3	ŵ
Â		James	
4	Shawn	4	Ę
Ł		Shawn	
Q		Q	

9 User Role

User Role facilitates to assign some specific permissions to certain users, based on the requirement.

- On the Main menu, tap User Role, and then tap on the User Defined Role to set the user defined permissions.
- The permission scope of the custom role can be set up into 3 roles, that is, the custom operating scope of the menu functions of the user.

K User Role	
User Defined Role 1	
User Defined Role 2	
User Defined Role 3	
27 Enroller	

- On the **User Defined Role** interface, toggle **Enable Defined Role** to enable or disable the user defined role.
- Tap on **Name** and enter the custom name of the role.

Ser Defined Role 1
Enable Defined Role
\bigcirc
Name
User Defined Role 1
Define User Role

- Then, by tapping on Define User Role, select the required privileges for the new role, and then press the Return button.
- During privilege assignment, the main menu function names will be displayed on the left and its sub-menus will be listed on the right.
- First tap on the required **Main Menu** function name, and then select its required sub-menus from the list.

♦ User Defined Role 1 ↓	Ser Role
☑ User Mgt.	● Normal User
☑ Comm.	Enroller
☑ System	⊖ Super Admin
Personalize	
🗌 Data Mgt.	

Note: If the User Role is enabled for the Device, tap on **User Mgt.** > **New User** > **User Role** to assign the created roles to the required users. But if there is no super administrator registered in the Device, then the device will prompt "**Please enroll super admin first!**" when enabling the User Role function.

10 Communication Settings

Communication Settings are used to set the parameters of the Network, Serial Comm, PC Connection, Wi-Fi, Cloud Server, Wiegand, and Network Diagnosis.

Tap **COMM.** on the main menu.



10.1 Network Settings

When the device needs to communicate with a PC over the Ethernet, you need to configure network settings and ensure that the device and the PC connect to the same network segment.

Tap **Ethernet** on the **Comm.** Settings interface to configure the settings.

♠	Ethernet	11	
IP Address			
	192.16	8.163.99	
Subnet Mask	(
	255.2	55.255.0	
Gateway			
	192.1	68.163.1	
DNS			
		0.0.0.0	
ТСР СОММ.	Port		
		4370	
<u>n</u>			

Function Name	Description	
IP Address	The default IP address is 192.168.1.201. It can be modified according to the network availability.	
Subnet Mask	The default Subnet Mask is 255.255.255.0. It can be modified according to the network availability.	
Gateway	The Default Gateway address is 0.0.0.0. It can be modified according to the network availability.	
DNS	The default DNS address is 0.0.0.0. It can be modified according to the network availability.	
TCP COMM. Port	The default TCP COMM Port value is 4370. It can be modified according to the network availability.	
DHCP	Dynamic Host Configuration Protocol dynamically allocates IP addresses for clients via server.	

Display in Status	Toggle to set whether to display the network icon on the
Bar	status bar.

10.2 Serial Comm

Serial Comm function establishes communication with the device through a serial port (RS485/Master Unit).

Tap Serial Comm. on the Comm. Settings interface.

Serial Comm	Serial Port
Serial Port	● No Using
No Using	
Baudrate 115200	○RS485(PC)
	⊖ Master Unit

Function Name	Description		
	No Using: No communication with the device through the serial port.		
Serial Port RS485(PC): Communicate with the device th RS485 serial port.			
	Master Unit: When RS485 is used as the function of " Master unit ", it can be connected to a card reader.		

	There are 4 baud rate options at which the data communicates with PC. They are: 115200 (default), 57600, 38400, and 19200.	
Baud Rate	The higher the baud rate, the faster is the communication speed, but also less reliable.	
	Hence, a higher baud rate can be used when the communication distance is short; when the communication distance is long, choosing a lower baud rate is more reliable.	

10.3 PC Connection

Comm Key facilitates to improve the security of the data by setting up the communication between the device and the PC. Once the Comm Key is set, a password is required to connect the device to the PC software.

Tap **PC Connection** on the **Comm.** Settings interface to configure the communication settings.

Function Name	Description	
Comm Key	The default password is 0 and can be changed. The Comm Key can contain 1-6 digits.	
Baud Rate	It is the identification number of the device, which ranges between 1 and 254. If the communication method is RS485, you need to input this device ID in the software communication interface.	

10.4 Wi-Fi Settings

The device provides a Wi-Fi module, which can be built-in within the device module or can be externally connected.

The Wi-Fi module enables data transmission via Wi-Fi (Wireless Fidelity) and establishes a wireless network environment. Wi-Fi is enabled by default in the device. If you don't need to use the Wi-Fi network, you can toggle the Wi-Fi to disable the button.

Tap **Wi-Fi Settings** on the **Comm.** Settings interface to configure the Wi-Fi settings.

♠	Wi-Fi Settings	
WIFI	\bigcirc	

Searching the Wi-Fi Network

- WIFI is enabled in the device by default. Toggle the Solution to enable or disable WIFI.
- Once the Wi-Fi is turned on, the device will search for the available Wi-Fi within the network range.
- Tap on the required Wi-Fi name from the available list and input the correct password in the password interface, and then tap Connect to Wi-Fi (OK).

٠.	Wi-Fi Settings	11	٠.	360-1	2-test	
WIFI	(WPA2PSK	
	Not in the netwo	ork range		ng Password	ength: Very Stro I	
ZYPT-HW	4	(
360-12-tes	st	Â,				
MINI-zkt6-	6	(P)		ct to Wi-Fi (OK)	Cancel (ESC)	
WIFI Enabled: Tap on the required		equired	Tap or	the passv	vord field to ent	er

network from the searched network list.

Tap on the password field to enter the password and tap on **Connect** to Wi-Fi (OK).

 When the WIFI is connected successfully, the initial interface will display the Wi-Fi logo.

> Adding Wi-Fi Network Manually

The Wi-Fi can also be added manually if the required Wi-Fi does not show on the list.

K Wi-Fi Setti	ings Jl	Add Wi-Fi Network
ÑÐ∙¢1	(P)	SSID
pl-10	(Network Mode
PLtest-4	(P)	Auth. Mode
Add Wi-Fi Network		
Advanced		
Tap on Add Wi-Fi Ne	twork to add	On this interface, enter the Wi-Fi
the Wi-Fi manually.		network parameters. (The added

<u>Note:</u> After successfully adding the WIFI manually, follow the same process to search for the added Wi-Fi name.

> Advanced Setting

On the **Wi-Fi Settings** interface, tap on **Advanced** to set the relevant parameters as required.

K Wi-Fi Settings	11	 Ethernet
MINI-zkt6-3	(Â	DHCP
MERCURY_1544	•i)	IP Address
	-	0.0.0
ZKTeco-tes	$\left(i \right)$	Subnet Mask
		0.0.0
Add Wi-Fi Network		Gateway
		0.0.0
Advanced		

Function Name	Description	
DHCP	Dynamic Host Configuration Protocol (DHCP) dynamically allocates IP addresses to network clients. If the DHCP is enabled, then the IP cannot be set manually.	
IP Address	The IP address for the Wi-Fi network, the default is 0.0.0.0. It can be modified according to the network availability.	
Subnet Mask	The default Subnet Mask of the Wi-Fi network is 255.255.255.0. It can be modified according to the network availability.	
Gateway	The Default Gateway address is 0.0.0.0. It can be modified according to the network availability.	

10.5 Cloud Server Setting

Tap **Cloud Server Setting** on the **Comm.** Settings interface to connect with the

ADMS server.

A Cloud Server Setting 🔥
Server Mode
ADMS
Enable Domain Name
\bigcirc
Server Address
0.0.0
Server Port
8081
Enable Proxy Server
\bigcirc

Functio	on Name	Description	
Enable Domain Name	Server Address	Once this mode is turned ON, the domain name mode "http:// " will be used, such as http://www.XYZ.com, while "XYZ" denotes the domain name.	
Disable Domain Name	Server Address	The IP address of the ADMS server.	
	Server Port	Port used by the ADMS server.	
Enable Proxy Server		The IP address and the port number of the proxy server is set manually when the proxy is enabled.	

HTTPS

Based on HTTP, transmission encryption and identity authentication ensures the security of the transmission process.

10.6 Wiegand Setup

It is used to set the Wiegand input and output parameters.

Tap **Wiegand Setup** on the **Comm.** Settings interface to set up the Wiegand input and output parameters.

	🔦 🦳 Wiegand Setup	
	Wiegand Input	
	Wiegand Output	
10.6.1 Wiegand Ir	nput	
	K Wiegand Options	
	Wiegand Format	
	Wiegand Bits	
	26	
	Pulse Width(us)	
	100	
	Pulse Interval(us)	
	1000	
	ID Type	
	User ID	

Function Description

Function Name	Description		
Wiegand Format	Its value can be 26 bits, 34 bits, 36 bits, 37 bits, and 50 bits.		
Wiegand Bits	The number of bits of the Wiegand data.		
Pulse Width(us)	The value of the pulse width sent by Wiegand is 100 microseconds by default, which can be adjusted within the range of 20 to 400 microseconds.		
Pulse Interval(us)	(us) The default value is 1000 microseconds and car be adjusted within the range of 200 to 2000 microseconds.		
ID Type	Select between the User ID and card number.		

Various Common Wiegand Format Description:

Wiegand Format	Description
	ECCCCCCCCCCCCCCCCCCO
	It consists of 26 bits of binary code. The 1st bit is the
Wiegand26	even parity bit of the 2^{nd} to 13^{th} bits, while the 26^{th} bit is
	the odd parity bit of the 14^{th} to 25^{th} bits. The 2^{nd} to 25^{th}
	bits are the card numbers.

Wiegand 26a	ESSSSSSSCCCCCCCCCCCO
	It consists of 26 bits of binary code. The 1^{st} bit is the
	even parity bit of the 2^{nd} to 13^{th} bits, while the 26^{th} bit is
	the odd parity bit of the 14^{th} to 25^{th} bits. The 2^{nd} to 9^{th}
	bits is the site codes, while the $10^{th}\ to\ 25^{th}$ bits are the
	card numbers.
	ECCCCCCCCCCCCCCCCCCCCCCCCCCCC
	It consists of 34 bits of binary code. The 1 st bit is the
Wiegand34	even parity bit of the 2 nd to 17 th bits, while the 34 th bit is
	the odd parity bit of the 18 th to 33 rd bits. The 2 nd to 25 th
	bits are the card numbers.
	ESSSSSSSSCCCCCCCCCCCCCCCCCCCCCCCCCCCCCC
	It consists of 34 bits of binary code. The 1 st bit is the
Wiegand34a	even parity bit of the 2 nd to 17 th bits, while the 34 th bit is
Wieganusta	the odd parity bit o <mark>f the</mark> 18 th to 33 rd bits. The 2 nd to 9 th
	bits is the site codes, while the 10^{th} to 25^{th} bits are the
	card numbers.
	OFFFFFFFFFFFFFFFFCCCCCCCCCCCMME
	It consists of 36 bits of binary code. The 1 st bit is the odd
	parity bit of the 2 nd to 18 th bits, while the 36 th bit is the
Wiegand 36	even parity bit of the 19^{th} to 35^{th} bits. The 2^{nd} to 17^{th} bits
	is the device codes. The 18^{th} to 33^{rd} bits is the card
	numbers, and the 34^{th} to 35^{th} bits are the manufacturer
	codes.
L	1

Wiegand 36a	EFFFFFFFFFFFFFFFFFFFCCCCCCCCCCCCC
	It consists of 36 bits of binary code. The 1 st bit is the
	even parity bit of the 2^{nd} to 18^{th} bits, while the 36^{th} bit is
	the odd parity bit of the 19th to 35^{th} bits. The 2^{nd} to 19^{th}
	bits is the device codes, and the 20^{th} to 35^{th} bits are the
	card numbers.
Wiegand 37	OMMMMSSSSSSSSSSSSCCCCCCCCCCCCCCCC
	It consists of 37 bits of binary code. The 1 st bit is the odd
	parity bit of the 2 nd to 18 th bits, while th <mark>e 37th bit is</mark> the
	even parity bit of the 19 th to 36 th bits. The 2 nd to 4 th bits
	is the manufa <mark>cturer c</mark> odes. The 5 th to 16 th bits is the site
	codes, and the 21 st to 36 th bits are the card numbers.
	EMMMFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFF
	It consists of 37 bits of binary code. The 1 st bit is the
	even parity bit of th <mark>e 2nd t</mark> o 18 th bits, while the 37 th bit is
Wiegand37a	the odd parity bit of the 19^{th} to 36^{th} bits. The 2^{nd} to 4^{th}
	bits is the manufacturer codes. The 5^{th} to 14^{th} bits is the
	device codes, and 15 th to 20 th bits are the site codes, and
	the 21 st to 36 th bits are the card numbers.
	ESSSSSSSSSSSSSSSSCCCCCCCCCCCCCCCCCCCCCC
	сссссо
	It consists of 50 bits of binary code. The 1 st bit is the
Wiegand50	even parity bit of the 2^{nd} to 25^{th} bits, while the 50^{th} bit is
	the odd parity bit of the 26^{th} to 49^{th} bits. The 2^{nd} to 17^{th}
	bits is the site codes, and the 18^{th} to 49^{th} bits are the
	card numbers.

"C" denotes the card number; "E" denotes the even parity bit; "O" denotes the odd parity bit.

"F" denotes the facility code; "M" denotes the manufacturer code; "P" denotes the parity bit; and "S" denotes the site code.

10.6.2 Wiegand Output

٠.	Wiegand Options	11
Wiegand	l Format	
Wiegand	d Output Bits	
		26
Failed ID)	
	D	sabled
Site Cod	e	
	D	sabled
Pulse W	idth(us)	
		100

Function Name	Description	
Wiegand Format	Its value can be 26 bits, 34 bits, 36 bits, 37 bits, and 50 bits.	
Wiegand Output Bits	After selecting the required Wiegand format, select the corresponding output bit digits from the Wiegand format.	


User Manual

Failed ID	If the verification fails, the system will send the failed ID to the device and replace the card number or personnel ID with the new one.		
Site Code	It is similar to the device ID. The difference is that a site code can be set manually and is repeatable on a different device. The valid value ranges from 0 to 256 by default.		
Pulse Width(us)	The time width represents the changes in the quantity of electric charge with regular high-frequency capacitance within a specified time.		
Pulse Interval(us)	The time interval between pulses.		
ID Type	Select the ID types as either User ID or card number.		

10.7 Network Diagnosis

It helps to set the network diagnosis parameters.

Tap **Network Diagnosis** on the **Comm.** Settings interface. Enter the IP address that needs to be diagnosed and tap **Start the Diagnostic Test** to check whether the network can connect to the device.



11 System Settings

It helps to set related system parameters to optimize the accessibility of the device.

Tap **System** on the **Main Menu** interface to get into its menu options.

System	m J	1	System	11
🕘 Date Time			Access Logs Settings	
Access Logs S	Settings		Face	
Face			Ringerprint	
Fingerprint			🙆 Reset	
🙆 Reset			Security Settings	

11.1 Date and Time

Tap **Date Time** on the **System** interface to set the date and time.

🔦 🛛 Date Ti	me	11	
Date and Time Auto	Sync		
Set the NTP Server	Adress		
Secule IVIE Server.	Auuress		
Select Time Zone			
	UTC+	8:00	
24-Hour Time			
Date Format		Í	
	YYYY-MN	1-DD	

- Tap **Date and Time Auto Sync** to enable automatic time synchronization based on the service address you enter.
- Tap Manual Date and Time to manually set the date and time and then tap to Confirm and save.
- Tap Select Time Zone to manually select the time zone where the device is located.
- Enable or disable this format by tapping 24-Hour Time. If enabled, then select the **Date Format** to set the date.
- Tap Daylight Saving Time to enable or disable the function. If enabled, tap Daylight Saving Mode to select a daylight-saving mode and then tap Daylight Saving Setup to set the switch time.


🔦 🛛 Daylight Saving Setup	 Daylight Saving Setup
Start Month	Start Date
1	00-00
Start Week	Start Time
1	00:00
Start Day	End Date
Sunday	00-00
Start Time	End Time
00:00	00:00
End Month	
1	
Week Mode	Date Mode

 When restoring the factory settings, the time (24-hour) and date format (YYYY-MM-DD) can be restored, but the device date and time cannot be restored.

Note: For example, if a user sets the time of the device (18:35 on March 15, 2020) to 18:30 on January 1, 2021. After restoring the factory settings, the time of the device will remain at 18:30 on January 1, 2021.

11.2 Access Logs Setting

Tap Access Logs Settings on the System interface.




Function Name	Description	
Alphanumeric User ID	Enable/Disable the alphanumeric as User ID.	
Access Log Alert	When the record space of the attendance access reaches the maximum threshold value, the device automatically displays the memory space warning. Users may disable the function or set a valid value between 1 and 9999.	

Periodic Del of Access Logs	When access logs reach its maximum capacity, the device automatically deletes a set of old access logs. Users may disable the function or set a valid value between 1 and 999.	
Authentication Timeout(s)	The amount of time taken to display a successful verification message. Valid value: 1 to 9 seconds.	
Face comparison Interval(s)	After the interval identifying is clicked (selected), for example, if the comparison interval is set to 5 seconds, then the face recognition will verify the face every 5 seconds. Valid value: 0 to 9 seconds. 0 means continuous identifying, 1 to 9 means identifying at intervals.	

11.3 Face Parameters

Tap Face on the System interface to go to the Face parameter settings.

Face	11	+ Face	11
1:N Threshold Value		Image Quality	
	47		70
1:1 Threshold Value		Minimum Face Size	
	63		80
Face Enrollment Threshold		LED Light Trigger Value	
	70		80
Face Pitch Angle		Motion Detection Sensitivity	
	30		4
Face Rotation Angle		Live Detection	
	25	(\supset



Function Name	Description
1:N Threshold Value	Under 1:N verification mode, the verification will only be successful when the similarity between the acquired facial image and all registered facial templates is greater than the set value. The valid value ranges from 0 to 100. The higher the thresholds, the lower the misjudgement rate and the higher the rejection rate, and vice versa. It is recommended to set the default value of 47.
1:1 Threshold Value	Under 1:1 verification mode, the verification will only be successful when the similarity between the acquired facial image and the user's facial templates enrolled in the device is greater than the set value. The valid value ranges from 0to 100. The higher the thresholds, the lower the misjudgement rate and the higher the rejection rate, and vice versa. It is recommended to set the default value of 63.
Face Enrollment Threshold	During face enrollment, 1:N comparison is used to determine whether the user has already registered before. When the similarity between the acquired facial image and all registered facial templates is greater than the set threshold, it indicates that the face has already been registered.
Face Pitch Angle	It is the pitch angle tolerance of a face for facial

	template registration and comparison. If a face's pitch angle exceeds the set value, it will be filtered by the algorithm, i.e., ignored by the terminal thus no registration and comparison interface will be triggered.
Face Rotation Angle	It is the rotation angle tolerance of a face for facial template registration and comparison. If a face's rotation angle exceeds the set value, it will be filtered by the algorithm, i.e., ignored by the terminal thus no registration and comparison interface will be triggered.
Image Quality	It is the image quality for facial registration and comparison. The higher the value, the clearer image is required.
Minimum Face Size	It sets the minimum face size required for facial registration and comparison. If the minimum size of the captured image is smaller than the set value, then it will be filtered off and not recognized as a face. This value can also be interpreted as the face comparison distance. The farther the individual is, the smaller the face, and the smaller number of pixels of the face obtained by the algorithm. Therefore, adjusting this parameter can adjust the farthest comparison distance of faces. When the value is 0, the face comparison distance is not limited.

LED Light Trigger Threshold	This value controls the turning on and off of the LED light. The larger the value, the LED light will turn on or off more frequently.
Motion Detection Sensitivity	It sets the value for the amount of change in a camera's field of view known as potential motion detection that wakes up the terminal from standby to the comparison interface. The larger the value, the more sensitive the system would be, i.e., if a larger value is set, the comparison interface activates with much ease, and the motion detection is frequently triggered.
Live Detection	It detects the spoof attempt using visible light images to determine if the provided biometric source sample is of a real person (a live human being) or a false representation.
Live Detection Threshold	It facilitates judging whether the captured visible image is a real person (a live human being). The larger the value, the better the anti-spoofing performance using visible light.
Anti-spoofing Using NIR	Using near-infrared spectra imaging to identify and prevent fake photos and videos attack.
Anti-flicker Mode	It is used when WDR is turned off. It helps to reduce flicker when the device's screen flashes at the same frequency as the light.
Face algorithm	It has facial algorithm related information and pause the facial template update.

Cove Dhoto os Tomulato	After disable this function, face re-registration is
Save Photo as Template	required after an algorithm upgrade.

11.4 Fingerprint ★

Tap **Fingerprint** on the **System** interface to go to the Fingerprint parameter settings.

Singerprint
1:1 Threshold Value
15
1:N Threshold Value
35
FP Sensor Sensitivity
Low
1:1 Retry Attempts
3
Fingerprint Image
Always Show

Function Name	Description
1:1 Threshold Value	Under 1:1 verification method, the verification will only be successful when the similarity between the acquired fingerprint data and the fingerprint template associated with the entered user ID enrolled in the device is greater than the set value.

1:N Threshold Value	Under 1:N verification method, the verification will only be successful when the similarity between the acquired fingerprint data and the fingerprint templates enrolled in the device is greater than the set value.
FP Sensor Sensitivity	To set the sensibility of fingerprint acquisition. It is recommended to use the default level " Medium ". When the environment is dry, resulting in slow fingerprint detection, you can set the level to " High " to raise the sensibility; when the environment is humid, making it hard to identify the fingerprint, you can set the level to " Low ".
1:1 Retry Times	In 1:1 Verification, users might forget the registered fingerprint, or press the finger improperly. To reduce the process of re-entering user ID, retry is allowed.
Fingerprint Image	To set whether to display the fingerprint image on the screen during fingerprint enrollment or verification. Four choices are available: Show for Enroll: to display the fingerprint image on the screen only during enrollment. Show for Match: to display the fingerprint image on the screen only during verification. Always Show: to display the fingerprint image on screen during enrollment and verification.
	on screen during enrollment and verification. None: not to display the fingerprint image.

11.5 Factory Reset

The Factory Reset function restores the device settings such as communication settings and system settings, to the default factory settings (this function does not clear registered user data).

Tap **Reset** on the **System** interface and then tap **OK** to restore the default factory settings.

System	11	
🕘 Date Time		
Access Logs Settings		
Face		r
Reset?Restart		
ок		
Cancel		

11.6 Security Settings

Tap Security Settings on the System interface to go to the Security settings.


٠.	Security Settings	11
Security	Mode	
Standald	one Communication	
SSH		
User ID	Masking	
Display	Verification Name	

Function Name	Description
Security Mode	Select whether to enable the security mode to protect the device and the user's personal information. You can set the device to work offline and hide the user's personal information to prevent leakage during user verification.
Standalone Communication	To avoid being unable to use when the device is offline, you can download the C/S software (such as ZKAccess 3.5) on your computer in advance for offline use.

SSH	SSH is used to enter the background of the device for maintenance.
User ID Masking	When enabled, and then the user is successfully compared and verified, the User ID in the displayed verification result will be replaced with an * to achieve secure protection of sensitive private data.
Display Verification Name	Set whether to display the username in the verification result interface.
Display Verification Mode	Set whether to display the verification mode in the verification result interface.

12 Personalize Settings

Tap **Personalize** the **Main Menu** interface to customize interface settings, voice, bell, punch state options, and shortcut key mappings.



12.1 Interface Settings

Tap **User Interface** on the **Personalize** interface to customize the display style of the main interface.

Ser Interface	11	
Menu Screen Timeout(s)		
	99999	
Idle Time to Slide Show(s)		
	None	
Slide Show Interval(s)		
	999	
Idle Time to Sleep(m)		
[Disabled	
Main Screen Style		
	Style 1	

Function Name	Description		
Wallpaper	It helps to select the main screen wallpaper according to the user preference.		
Language	It helps to select the language of the device.		
Menu Screen Timeout (s)	When there is no operation, and the time exceeds the set value, the device automatically goes back to the initial interface. The function can either be disabled or set the required value between 60 and 99999 seconds.		
Idle Time to Slide Show (s)	When there is no operation, and the time exceeds the set value, a slide show is displayed. The function can be disabled, or you may set the value between 3 and 999 seconds.		

Slide Show Interval (s)	It is the time interval in switching between different slide show pictures. The function can be disabled, or you may set the interval between 3 and 999 seconds.			
Idle Time to Sleep (m)	If the sleep mode is activated, and when there is no operation in the device, then the device will enter standby mode. This function can be disabled or set a value within 1-999 minutes.			
Main Screen Style	The style of the main screen can be selected according to the user preference.			

12.2 Voice Settings

Tap **Voice** on the **Personalize** interface to configure the voice settings.


•	Voice	
Voice Prompt		
Touch Prompts		
Volume		
		50

Function Description

Function Name	Description
Voice Prompt	Toggle to enable or disable the voice prompts during function operations.
Touch Prompt	Toggle to enable or disable the keypad sounds.
Volume	Adjust the volume of the device which can be set between 0-100.

12.3 Bell Schedules

Tap **Bell Schedules** on the **Personalize** interface to configure the Bell settings.



New Bell Schedule

Tap **New Bell Schedule** on the **Bell Schedule** interface to add a new bell schedule.

Sell Schedules	New Bell Schedule
New Bell Schedule	Bell Status
	\bigcirc
All Bell Schedules	Bell Time
	Repeat
	Never
	Ring Tone
	bell01.wav
	Internal Bell Delay(s)
	5

Function Name	Description			
Bell Status	Toggle to enable or disable the bell status.			
Bell Time	Once the required time is set, the device automatically triggers to ring the bell during that time.			
Repeat	Set the required number of counts to repeat the scheduled bell.			
Ring Tone	Select a ringtone.			
Internal Bell Delay(s)	Set the replay time of the internal bell. Valid values range from 1 to 999 seconds.			

All Bell Schedules

Once the bell is scheduled, on the **Bell Schedules** interface, tap **All Bell Schedules** to view the newly scheduled bell.

Edit the Scheduled Bell

On the **All Bell Schedules** interface, tap on the required bell schedule, and tap **Edit** to edit the selected bell schedule. The editing method is the same as the operations of adding a new bell schedule.

Delete a Bell

On the **All Bell Schedules** interface, tap the required bell schedule, tap **Delete**, and then tap **Yes** to delete the selected bell.

12.4 Punch States Options

Tap **Punch States Options** on the **Personalize** interface to configure the punch state settings.

 Punch State Options 	•	Punch State Mode	11
Punch State Mode	⊙ Off		
	⊖Manu	ual Mode	
	⊖ Auto	Mode	
	⊖Manu	ual and Auto Mode	
	⊖Manu	ual Fixed Mode	

Function Name	Description
	Off: Disable the punch state function. Therefore, the punch state key set under Shortcut Key Mappings menu will become invalid.
	Manual Mode: Switch the punch state key manually, and the punch state key will disappear after Punch State Timeout.
	Auto Mode: The punch state key will automatically switch to a specific punch status according to the predefined time schedule which can be set in the Shortcut Key Mappings.
Punch State Mode	Manual and Auto Mode: The main interface will display the auto-switch punch state key. However, the users will still be able to select alternative that is the manual attendance status. After timeout, the manual switching punch state key will become auto-switch punch state key.
	Manual Fixed Mode: After the punch state key is set manually to a particular punch status, the function will remain unchanged until it is being manually switched again. Fixed Mode: Only the manually fixed punch
	state key will be shown. Users cannot change the status by pressing any other keys.

12.5 Shortcut Key Mappings

Users may define shortcut keys for attendance status and for functional keys which will be defined on the main interface. So, on the main interface, when the shortcut keys are pressed, the corresponding attendance status or the function interface will be displayed directly.

Tap **Shortcut Key Mappings** on the **Personalize** interface to set the required shortcut keys.



- On the **Shortcut Key Mappings** interface, tap on the required shortcut key to configure the shortcut key settings.
- On the Shortcut Key (that is "F1") interface, tap function to set the functional process of the shortcut key either as punch state key or function key.
- If the Shortcut key is defined as a function key (such as New user, All users, etc.), the configuration is completed as shown in the image below.

← F1	► F1
Punch State Value	Function
0	New User
Function	
Punch State Options	
Name	
Check-In	

If the Shortcut key is set as a punch state key (such as check in, check out, etc.), then it is required to set the punch state value (valid value 0~250), name.

Set the Switch Time

- The switch time is set in accordance with the punch state options.
- When the **Punch State Mode** is set to **Auto Mode**, the switch time should be set.
- On the **Shortcut Key** interface, tap **Set Switch Time** to set the switch time.
- On the **Switch Cycle** interface, select the switch cycle (Monday, Tuesday, etc.) as shown in the image below.

• F1			Switch Cycle	11
Punch State Value	0		☑ Monday	
Function Punc	ch State Options		✓ Tuesday	
Name	Check-In		☑ Wednesday	
Set Switch Time			🗹 Thursday	
			🗹 Friday	
	🔦 🦳 Set Sv	vitcl	h Time 🛛 🖊	
	Switch Cycle			
	M	ond	ay Tuesday W	
	Monday			
	Tuesday			
	Wednesday			
	Thursday			

• Once the Switch cycle is selected, set the switch time for each day, and tap **OK** to confirm, as shown in the image below.

Monday	Set Switch Time 💦
08:00 08 00 08 00 HH MM	Switch Cycle Monday Tuesday W Monday 08:00 Tuesday Wednesday Thursday
Confirm (OK) Cancel (ESC)	

Note: When the function is set to Undefined, the device will not enable the punch state key.

13 Data Management

On the Main Menu, tap Data Mgt. to delete the relevant data in the device.



13.1 Delete Data


Tap **Delete Data** on the **Data Mgt.** interface to delete the required data.

🔦 Delete Data 🗸		A Delete Data	11
Delete Access Records		Delete Admin Role	
Delete All Data	L	Delete Access Control	
Delete Admin Role	ľ	Delete User Photo Templates	
Delete Access Control		Delete Wallpaper	
Delete User Photo Templates		Delete Screen Savers	

Function Name	Description
Delete Access Records	To delete the access records conditionally.


Delete All Data	To delete the information and access records of all registered users.
Delete Admin Role	To remove all the administrator privileges.
Delete Access Control	To delete all the access data.
Delete User Photo Templates	To delete all the user photo templates on the device.
Delete Wallpaper	To delete all the wallpapers in the device.
Delete Screen Savers	To delete all the screen savers in the device.

The user may select **Delete All or Delete by Time Range** when deleting the access records, attendance photos or block listed photos. Selecting **Delete by Time Range**, you need to set a specific time range to delete all data within a specific period.



14 Access Control

On the **Main Menu**, tap **Access Control** to set the schedule of the door opening, locks control and to configure other parameters settings related to access control.




To gain access, the registered user must meet the following conditions:

- 1. The relevant door's current unlock time should be within any valid time zone of the user's time period.
- The corresponding user's group must be already set in the door unlock combination (and if there are other groups, being set in the same access combo, then the verification of those group's members is also required to unlock the door).
- 3. In default settings, new users are allocated into the first group with the default group time zone, where the access combo is "1" and is set in unlock state by default.

14.1 Access Control Options

Tap **Access Control Options** on the **Access Control** interface to set the parameters of the control lock of the terminal and related equipment.



Function Name	Description
Gate Control Mode	It toggles between ON or OFF switch to get into gate control mode or not. When set to ON , the interface removes the Door Lock Delay, Door Sensor Delay, and Door Sensor Type options.
Door Lock Delay (s)	The length of time that the device controls the electric lock to be in unlock state. Valid value: 1~99 seconds.

Door Sensor Delay (s)	If the door is not locked and is left open for a certain duration (Door Sensor Delay), an alarm will be triggered. The valid value of Door Sensor Delay ranges from 1 to 255 seconds.
Door Sensor Type	There are three Sensor types: None, Normal Open, and Normal Closed. None: It means the door sensor is not in use. Normally Open: It means the door is always left open when electric power is on. Normally Closed: It means the door is always left closed when electric power is on.
Verification Mode	The supported verification mode includes Password/Fingerprint/Card/Face, Fingerprint Only, User ID Only, Password, Card Only, Fingerprint/Password, Fingerprint/Card, User ID + Fingerprint, Fingerprint + Password, Fingerprint + Card, Fingerprint + Password + Card, Password + Card, Password/Card, User ID + Fingerprint + Password, Fingerprint + (Card/User ID), Face Only, Face + Fingerprint, Face + Password, Face + Card, Face + Fingerprint + Card, Face + Fingerprint + Password.
Door Available Time Period	It sets the timing for the door so that the door is accessible only during that period.

Normal Open Time Period	It is the scheduled time-period for "Normal Open" mode so that the door is always open during this period.
Master Device	 While configuring the master and slave devices, you may set the state of the master as Out or In. Out: A record of verification on the master device is a check-out record. In: A record of verification on the master device is a check-in record.
Slave Device	 While configuring the master and slave devices, you may set the state of the slave as Out or In. Out: A record of verification on the slave device is a check-out record. In: A record of verification on the slave device is a check-in record.
Auxiliary Input Configuration	Sets the door unlock time period and auxiliary output type of the auxiliary terminal device. Auxiliary output types include None, Trigger door open, Trigger Alarm, Trigger door open and Alarm.
Speaker Alarm	It transmits a sound alarm or disassembly alarm from the local. When the door is closed or the verification is successful, the system cancels the alarm from the local.

	The access control reset parameters include door
	lock delay, door sensor delay, door sensor type,
Depart Assess Catting	verification mode, door available time period,
Reset Access Setting	normal open time period, master device, and
	alarm. However, erased access control data in
	Data Mgt. is excluded.

14.2 Time Schedule

Tap **Time Rule Setting** on the Access Control interface to configure the time settings.

- The entire system can define up to 50 Time Periods.
- Each time-period represents **10** Time Zones, i.e., **1** week and **3** holidays, and each time zone is a standard 24 hour period per day and the user can only verify within the valid time-period.
- One can set a maximum of 3 time periods for every time zone. The relationship among these time-periods is "OR". Thus, when the verification time falls in any one of these time-periods, the verification is valid.
- The Time Zone format of each time-period is H**H MM-HH MM**, which is accurate to minutes according to the 24-hour clock.

Tap the grey box to search the required Time Zone and specify the required Time Zone number (maximum up to 50 zones).

•	Time Rule[2/50]	11
Sunday		
	[00:00 23:5	i9] [0
Monday		
	[00:00 23:5	i9] [0
Tuesday		
	[00:00 23:5	i9] [0
Wednes	day	
	[00:00 23:5	i9] [0
0		
\mathcal{A}		

On the selected Time Zone number interface, tap on the required day (that is Monday, Tuesday, etc.) to set the time.

	Time Period 1 00:00 23:59		
	00 00 23 59		
	HH MM HH MM		
	Confirm (OK) Cancel (ESC)		

Specify the start and the end time, and then tap **OK**.

Note:

- 1. The door is inaccessible for the whole day when the End Time occurs before the Start Time (such as **23:57~23:56**).
- It is the time interval for valid access when the End Time occurs after the Start Time (such as 08:00~23:59).
- The door is accessible for the whole day when the End Time occurs after the Start Time (such that Start Time is **00:00** and End Time is **23:59**).
- 4. The default Time Zone 1 indicates that the door is open all day long.

14.3 Holidays

Whenever there is a holiday, you may need a distinct access time; but changing everyone's access time one by one is extremely cumbersome, so a holiday access time can be set that applies to all employees and the user will be able to open the door during the holidays.

Tap **Holidays** on the **Access Control** interface to set the holiday access.

♠	Holidays
Add Holiday	
All Holidays	

> Add a New Holiday

Tap Add Holiday on the Holidays interface and set the holiday parameters.

A Holidays	
No.	
1	
Date	
Undefined	
Holiday Type	
Holiday Type 1	
Repeats Every Year	

> Edit a Holiday

On the **Holidays** interface, select a holiday item to be modified. Tap **Edit** to modify holiday parameters.

Delete a Holiday

On the **Holidays** interface, select a holiday item to be deleted and tap **Delete**. Press **OK** to confirm the deletion. After deletion, this holiday does not display on the **All Holidays** interface.

14.4 Combined Verification

Access groups are arranged into different door-unlocking combinations to achieve multiple verifications and strengthen security.

In a door-unlocking combination, the range of the combined number N is $0 \le N$ ≤ 5 and the number of members N may all belong to one access group or may belong to five different access groups.

Tap **Combined Verification** on the **Access Control** interface to configure the combined verification setting.



On the combined verification interface, tap the Door-unlock combination to be set, and tap the **up** and **down** arrows to input the combination number, and then press **OK**.

For Example:

- If the Door-unlock combination 1 is set as (01 03 05 06 08). It indicates that the unlock combination 1 consists of 5 people and all the 5 individuals are from 5 groups, namely, AC Group 1, AC Group 3, AC Group 5, AC Group 6, and AC Group 8, respectively.
- If the Door-unlock combination 2 is set as (02 02 04 04 07). It indicates that the unlock combination 2 consists of 5 people; the first two are from AC Group 2, the next two are from AC Group 4, and the last person is from AC Group 7.
- If the Door-unlock combination 3 is set as (09 09 09 09 09). It indicates

that there are 5 people in this combination; all of which are from AC Group 9.

 If the Door-unlock combination 4 is set as (03 05 08 00 00). It indicates that the unlock combination 4 consists of only three people. The first person is from AC Group 3, the second person is from AC Group 5, and the third person is from AC Group 8.


<u>Note</u>: To delete the door-unlock combination, set all Door-unlock combinations to 0.

14.5 Anti-passback Setup

A user may be followed by some person(s) to enter the door without verification, resulting in a security breach. So, to avoid such situations, the Anti-Passback option was developed. Once it is enabled, the check-in and check-out record must occur alternatively to open the door to represent a consistent pattern.

This function requires two devices to work together:

One device is installed on the indoor side of the door (master device), and the other one is installed on the outdoor side of the door (the slave device). The two devices communicate via the Wiegand signal. The Wiegand format and Output type (User ID/Card Number) adopted by the master device and slave device must be consistent.



Tap Anti-passback Setup on the Access Control interface.

Anti-passback Setup	Anti-passback Direc
Anti-passback Direction No Anti-p	⊙ No Anti-passback
	⊖Out Anti-passback
	⊖ In Anti-passback
	⊖ In/Out Anti-passback

Function Name	Description
Anti-passback Direction	No Anti-passback: The Anti-Passback function is disabled, which means successful verification through either the master device or slave device can unlock the door. The attendance state is not saved in this option. Out Anti-passback: The user can check-out only if the last record is a check-in record otherwise an alarm is raised. However, the user can check-in freely. In Anti-Passback: The user can check-in again only if the last record is a check-out record otherwise an alarm is raised. However, the user can check-out freely.

In/Out Anti-passback: In this case, a user can		
check-in only if the last record is a check-out or		
the user can check-out only if the last record is a		
check-in otherwise the alarm is triggered.		

14.6 Duress Options Settings

Once a user activates the duress verification function with a specific authentication method(s), and when he/she is under coercion and authenticates using duress verification, the device unlocks the door as usual. At the same time, a signal is sent to trigger the alarm as well.

On the **Access Control** interface, tap **Duress Options** to configure the duress settings.

• Duress Options	
Alarm on Password	
	\bigcirc
Alarm on 1:1 Match	
	\bigcirc
Alarm on 1:N Match	
	\bigcirc
Alarm Delay(s)	
	10
Duress Password	
	None
	Alarm on Password Alarm on 1:1 Match Alarm on 1:N Match Alarm Delay(s)

Function Name	Description	
Alarm on Password	When a user uses the password verification method, an alarm signal will be generated, otherwise there will be no alarm signal.	
Alarm on 1:1 Match	When a user uses the 1:1 verification method, an alarm signal will be generated, otherwise there will be no alarm signal.	
Alarm on 1:N Match	When a user uses the 1:N verification method, an alarm signal will be generated, otherwise there will be no alarm signal.	
Alarm Delay (s)	Alarm signal will not be transmitted until the alarm delay time is elapsed. The value ranges from 1 to 999 seconds.	
Duress Password	Set the 6-digit duress password. When the user enters this duress password for verification, an alarm signal will be generated.	


15 USB Manager

You can import user information, access data and other data from a USB drive to computer or other devices.

Before uploading or downloading data from or to the USB drive, insert the USB drive into the USB slot first.

Click **USB Manager** on the main menu interface.

15.1 Download



Function Name	Description	
Download Access Records	To download access data within a specified time period or all data to a USB drive.	
User Data	To download all user information from the device to a USB drive.	

15.2 Upload

Once the identity of a user is verified, the access record is saved in the device. This function enables users to check their event logs.

♠	Upload	
Screen Save	r	
Wallpaper		
User Data		

Function Name	Description	
Screen Saver	To upload a screen saver from a USB drive to the device. Before uploading, you may select Upload selected picture or Upload all pictures .	
Wallpaper	To upload a wallpaper from a USB drive to the device. Before uploading, you may select Upload selected picture or Upload all pictures . The images will be displayed on the screen after manual settings.	
User Data	To upload all user information from a USB drive to the device.	

16 Attendance Search

Once the identity of a user is verified, the access record is saved in the device. This function enables users to check their event logs.

Select **Attendance Search** on the **Main Menu** interface to search for the required event Logs.

Ser ID				🔦 Time Range	11
Please Input(query all data without input)		● Today			
				⊖Yesterday	
	ABC	DEF	\otimes	○ This Week	
GHI	JKL	MNO	^		
PQRS	τυν	WXYZ	\sim	⊖Last Week	
5		EN	ок	⊖This Month	

- Enter the user ID to be searched and tap **OK**. If you want to search for records of all users, tap **OK** without entering any user ID.
- Select the time range in which the records need to be searched.

٠	Personal Record Sea 1		
Date	User ID Time		
05-09		04	
	0	09:10 09:10 09:10	
		09:10	
05-07		08	
	0	11:58 11:58 11:52	
		11:52 11:52 11:52	
		11:52 11:52	
05-06		04	
	0	09:03 09:03 09:03	
		09:03	
05-05		131	
	0	18:02 18:02 16:32	
		16:32 16:30 16:30	


 Once the record search completes. Tap the record highlighted in green to view its details.

User ID	Name	Time
0		05-09 09:10
0		05-09 09:10
0		05-09 09:10
0		05-09 09:10
Verification Status : 2	Mode : Oth	ier

4. The figure shows the details of the selected record.

17 Autotest

Select **Main Menu**, tap **Autotest**. It enables the system to automatically test whether the functions of various modules are working normally, including the LCD, Voice, Microphone, Fingerprint, Camera and Real-Time Clock (RTC).



Function Name	Description		
Test All	To automatically test whether the LCD, Voice, Microphone, Fingerprint, Camera and Real-Time Clock (RTC) are normal.		
Test LCD	To automatically test the display effect of LCD screen by displaying full-color, pure white, and pure black to check whether the screen displays colors normally.		

Test Voice	To automatically test whether the audio files stored in the device are complete and the voice quality is good.
Microphone test	To test if the microphone is working properly by speaking into the microphone.
Test Fingerprint Sensor	To test the fingerprint sensor by pressing a finger on the scanner to check if the acquired fingerprint image is clear. When you are pressing a finger on the scanner, the fingerprint image will display on the screen.
Test Face	To test if the camera functions properly by checking the pictures taken to see if they are clear enough.
Test Clock RTC	To test the RTC. The device tests whether the clock works normally and accurately with a stopwatch. Touch the screen to start counting and press it again to stop counting.

18 System Information

On the **Main Menu**, tap **System Info** to view the storage status, the version information of the device, firmware information and the privacy policy.



Function Name	Description				
Device Capacity	Displays the current device's user storage, fingerprint, card, password and face storage, administrators and records.				
Device Info	Displays the device's name, serial number, MAC address, fingerprint algorithm, face algorithm, platform information, MCU Version, Manufacturer, and manufacture date.				
Firmware Info	Displays the firmware version and other version information of the device.				
Privacy Policy	Display the device's privacy policy.				

19 Connect to ZKBio CVAccess Software

19.1 Set the Communication Address

> Device side

 Tap COMM. > Ethernet in the main menu to set the IP address and gateway of the device.

(<u>Note:</u> Please ensure that the IP address is in the same network segment as the server address and can communicate with the ZKBio CVAccess server.)

 In the main menu, click COMM. > Cloud Server Setting to set the server address and server port.

Server address: Set the IP address as of ZKBio CVAccess server. Server port: Set the server port as of ZKBio CVAccess.

♠	Ethernet 🗸	•	🔦 🛛 Cloud Server Settin	11
IP Address			Server Mode	
	192.168.163.99			ADMS
Subnet Mask			Enable Domain Name	
	255.255.255.0			\bigcirc
Gateway			Server Address	
	192.168.163.1		110.8	30.38.74
DNS			Server Port	
	0.0.0.0			8088
TCP COMM.F	Port		Enable Proxy Server	
	4370			\bigcirc

Software side

Login to ZKBio CVAccess software, click **System** > **Communication** > **Communication Monitor** to set the ADMS service port, as shown in the figure below:

System / Communication	management / Communication Menitor	
Adms Service Se	ttings	Adms Service Settings Server Side Network Condition
	Adms Service Port	
	The current part is for device communication service, if there is a network mapping for the service port, phase after to the actual mapped port.	
	Project control file version	
	Turn on encrypted transmission	
¢	🔿 Na 💿 Yes	

19.2 Add Device on the Software

Add the device by searching. The process is as follows:

- Click Access > Device > Search Device, to open the Search interface in the software.
- 2. Click Search, and it will prompt [Searching.....].
- 3. After searching, the list and total number of access controllers will be displayed.

evice Name	Serial Number	IP Address	More ~ Q	Q	
CRefresh ⊒+New I	∄ Delete ⊥ Export Q Search	🕮 Control 👻 🐵 Set up 👻 🗄	🖥 View / Get 👻 오 Communicati	ion -	
		Searc	h		
Search	to device found? Download Search To	ols to Local Disk			
Total Progress	100%	Searched devices count:1			
IP Address	Device Type	Serial Number	8		
IP Address	MAC Address Subnet M	ask Gateway Add Serial N	umber Device Type Set Ser	ver Operations	
192,168,137,32	255.255.2	55.0 192.168.137.1 7273212	700020 RevFace 19	Add	
	tem communication port is 8881, please	make sure the device is set correctly			

 Click [Add] in operation column, a new window will pop-up. Select Icon type, Area, and Add to Level from each dropdown and click [OK] to add the device.

19.3 Add Personnel on the Software

				New			
General Device Operation Role Ordinary User CEntend Passage CAccess Disabled Set Valid Time	First Name Gender Certificale Type Birthday Hire Date Device Verification Password Biometrics Type Enable app login		*	Last Name Mobile Phone Certificate Number Email Position Name	Department Name		
	Levels Settings Ceneral Add S	ielect All	Unselect All	Dev ⑦ Ext ⑦ Acc	vice Operation Role end Passage cess Disabled	Ordinary User	

1. Click **Personnel** > **Person** > **New**:

- 2. Fill in all the required fields and click [OK] to register a new user.
- Click Access > Device > Control > Synchronize All Data to Devices to synchronize all the data to the device including the new users.

19.4 Mobile Credential 🛧

After downloading and installing the App, the user needs to set the Server before login. The steps are given below:

 In ZKBio CVAccess > System > System Management > Parameters, set Enable QR Code to "Yes", and select the QR code status according to the actual situation. The default is Dynamic, the valid time of the QR code can be set.

ystem / System Manager	ment / Parameters				
QR Code Setting	Enable GR Code	QR Code Setting Video watermark Personal sensitive information pro Privacy Policy			
	No © Yes GrocketType Static © Dynamic				
⊖ since in parameter Energystom Mode ⊛ Mode A, j Mode E					
 The current device device of support E-mode worpston. Belies welching the excreption mode, places ensure that the device has supported the current mode, ethowake the QR code will not be recognized currently. 					
	Valid Time:				
	30 second(30-300)				
	Switch bitween static QR code and dynamic QR code should be careful, frequent switch may lead to device error!				


 On the Server, choose System > Authority Management > Client Register to add a registered App client.

System / Authority Management / Client Regi	ster	
Registration Code	Client Type Activation	•
C Refresh 🖅 New 오 Reset 💼 D	elete	
🗌 Registratio Client name Reg	gistration Key Activ Activated D Creation Date 0	Client Ty
	New	×
	Client Type*	
	Registration Code* 9651EF	_ 1
		- 1
		- 1
)		- 1
		_ 1
		_
	OK Cancel	

 Open the App on the Smartphone. On the login screen, tap Server Setting and type the IP Address or the domain name of the Server, and its port number.

Note: Smartphone and the Server must be in the same network segment.

- Tap the QR Code icon to scan the QR code of the new App client. After the client is identified successfully, set the client's name and tap Connection Test.
- 5. After the network is connected successfully, tap **Save**.



The Mobile Credential function is only valid when logging in as an employee, tap on Employee to switch to employee login screen. Enter the employee ID and password (Default: 123456) to login.

 Tap Mobile Credential on the App, and a QR code will appear, which includes employee ID and card number (static QR code only includes card number) information. 7. The QR code can replace a physical card on a specific device to achieve contactless authentication to open the door.



8. When using this function for the first time, the App will prompt to authorize the modification of screen brightness settings, as shown in the figure:



9. The QR code refreshes automatically for every 30s and supports manual refresh.



Note: For other specific operations, please refer to ZKBio CVAccess User Manual.

<u>Appendix 1</u>

Requirements of Live Collection and Registration of

Visible Light Face Templates

- It is recommended to perform registration in an indoor environment with an appropriate light source without underexposure or overexposure on the face.
- Do not place the device towards outdoor light sources like door or window or other harsh light sources.
- Dark-color apparels other than the background color are recommended for registration.
- Expose your face and forehead properly and do not cover your face and eyebrows with your hair.
- 5) It is recommended to show a normal facial expression. (A smile is acceptable, but do not close your eyes, or incline your head to any orientation).
- 6) Two images are required for persons with eyeglasses, one image with eyeglasses and one other without them.
- 7) Do not wear accessories like scarf or mask that may cover your mouth or chin.
- 8) Please face right towards the capturing device and locate your face in the image capturing area as shown in the image below.
- 9) Do not include more than one face in the capturing area.
- 10) A distance of 50cm to 80cm is recommended for capturing the image. (the distance is adjustable, subject to body height).



Requirements for Visible Light Digital Face

Template Data

The digital photo should be straight-edged, coloured, half-portrayed with only one person, and the person should be uncharted and in casuals. Persons who wear eyeglasses should remain to put on eyeglasses for getting photos captured.

Eye Distance

200 pixels or above are recommended with no less than 115 pixels of distance.

Facial Expression

A neutral face or smile with eyes naturally open are recommended.

Gesture and Angel

The horizontal rotating angle should not exceed $\pm 10^{\circ}$, elevation should not exceed $\pm 10^{\circ}$, and depression angle should not exceed $\pm 10^{\circ}$.

Accessories

Masks or coloured eyeglasses are not allowed. The frame of the eyeglasses should not cover the eyes and should not reflect light. For persons with thick eyeglasses frames, it is recommended to capture two images, one with eyeglasses and the other one without them.

Face

Complete face with clear contour, real scale, evenly distributed light, and no shadow.

Image Format

Should be in BMP, JPG or JPEG.

Data Requirement

Should comply with the following requirements:

- 1) White background with dark-coloured apparel.
- 2) 24bit true color mode.
- 3) JPG format compressed image with not more than 20kb size.
- 4) Resolution should be between 358 x 441 to 1080 x 1920.
- 5) The vertical scale of head and body should be in a ratio of 2:1.
- 6) The photo should include the captured person's shoulders at the same horizontal level.
- 7) The captured person's eyes should be open and with clearly seen iris.
- 8) A neutral face or smile is preferred, showing teeth is not preferred.
- 9) The captured person should be easily visible, natural in color, no harsh shadow or light spot or reflection in the face or background. The contrast and lightness level should be appropriate.

Appendix 2

Privacy Policy

Notice:

To help you better use the products and services of ZKTeco and its affiliates, hereinafter referred as "we", "our", or "us", the smart service provider, we consistently collect your personal information. Since we understand the importance of your personal information, we took your privacy sincerely and we have formulated this privacy policy to protect your personal information. We have listed the privacy policies below to precisely understand the data and privacy protection measures related to our smart products and services.

Before using our products and services, please read carefully and understand all the rules and provisions of this Privacy Policy. If you do not agree to the relevant agreement or any of its terms, you must stop using our products and services.

I. Collected Information

To ensure the normal product operation and help the service improvement, we will collect the information voluntarily provided by you or provided as authorized by you during registration and use or generated as a result of your use of services.

 User Registration Information: At your first registration, the feature template (Fingerprint template/Face template/Palm template) will be saved on the device according to the device type you have selected to verify the unique similarity between you and the User ID you have registered. You can optionally enter your Name and Code. The above information is necessary for you to use our products. If you do not provide such information, you cannot use some features of the product regularly.

2. Product information: According to the product model and your granted permission when you install and use our services, the related information of the product on which our services are used will be collected when the product is connected to the software, including the Product Model, Firmware Version Number, Product Serial Number, and Product Capacity Information. When you connect your product to the software, please carefully read the privacy policy for the specific software.

II. Product Security and Management

- When you use our products for the first time, you shall set the Administrator privilege before performing specific operations. Otherwise, you will be frequently reminded to set the Administrator privilege when you enter the main menu interface. If you still do not set the Administrator privilege after receiving the system prompt, you should be aware of the possible security risk (for example, the data may be manually modified).
- 2. All the functions of displaying the biometric information are disabled in our products by default. You can choose Menu > System Settings to set whether to display the biometric information. If you enable these functions, we assume that you are aware of the personal privacy security risks specified in the privacy policy.
- Only your user ID is displayed by default. You can set whether to display other user verification information (such as Name, Department, Photo, etc.) under the Administrator privilege. If you choose to display such

information, we assume that you are aware of the potential security risks (for example, your photo will be displayed on the device interface).

- 4. The camera function is disabled in our products by default. If you want to enable this function to take pictures of yourself for attendance recording or take pictures of strangers for access control, the product will enable the prompt tone of the camera. Once you enable this function, we assume that you are aware of the potential security risks.
- 5. All the data collected by our products is encrypted using the AES 256 algorithm. All the data uploaded by the Administrator to our products are automatically encrypted using the AES 256 algorithm and stored securely. If the Administrator downloads data from our products, we assume that you need to process the data and you have known the potential security risk. In such a case, you shall take the responsibility for storing the data. You shall know that some data cannot be downloaded for sake of data security.
- 6. All the personal information in our products can be queried, modified, or deleted. If you no longer use our products, please clear your personal data.

III. How we handle personal information of minors

Our products, website and services are mainly designed for adults. Without consent of parents or guardians, minors shall not create their own account. If you are a minor, it is recommended that you ask your parents or guardian to read this Policy carefully, and only use our services or information provided by us with consent of your parents or guardian.

We will only use or disclose personal information of minors collected with

their parents' or guardians' consent if and to the extent that such use or disclosure is permitted by law or we have obtained their parents' or guardians' explicit consent, and such use or disclosure is for the purpose of protecting minors.

Upon noticing that we have collected personal information of minors without the prior consent from verifiable parents, we will delete such information as soon as possible.

IV. Others

You can visit <u>https://www.zkteco.com/cn/index/Index/privacy_protection.html</u> to learn more about how we collect, use, and securely store your personal information. To keep pace with the rapid development of technology, adjustment of business operations, and to cope with customer needs, we will constantly deliberate and optimize our privacy protection measures and policies. Welcome to visit our official website at any time to learn our latest privacy policy.

Eco-friendly Operation

	product w with the p The eco-fr other cor	The product's "eco-friendly operational period" refers to the time during which this product will not discharge any toxic or hazardous substances when used in accordance with the prerequisites in this manual. The eco-friendly operational period specified for this product does not include batteries or other components that are easily worn down and must be periodically replaced. The battery's eco-friendly operational period is 5 years.						
		Hazardous	or Toxic substa	ances and their	quantities	\mathbf{X}		
Component			Hazardou	us/Toxic Substar	ice/Element			
Name	Lead (Pb)	Mercury (Hg)	C <mark>ad</mark> mium (Cd)	Hexavalent Chromium (Cr6+)	Polybrominated Biphenyls (PBB)	Polybrominated Diphenyl Ethers (PBDE)		
Chip Resistor	×	0	0	0	0	0		
Chip Capacitor	×	0	0	0	0	o		
Chip Inductor	×	0	0	0	0	0		
Diode	×	0	0	0	0	0		
ESD component	×	0	0	0	0	o		
Buzzer	×	0	0	0	0	0		

Adapter	×	0	0	0	0	0
Screws	0	0	0	×	o	0

 \circ indicates that the total amount of toxic content in all the homogeneous materials is below the limit as specified in SJ/T 11363—2006.

 \times indicates that the total amount of toxic content in all the homogeneous materials exceeds the limit as specified in SJ/T 11363—2006.

Note: 80% of this product's components are manufactured using non-toxic and eco-friendly materials. The components which contain toxins or harmful elements are included due to the current economic or technical limitations which prevent their replacement with non-toxic materials or elements.

ZKTeco Industrial Park, No. 32, Industrial Road, Tangxia Town, Dongguan, China. Phone: +86 769 - 82109991 Fax :+86 755 - 89602394 www.zkteco.com



Copyright © 2023 ZKTECO CO., LTD. All Rights reserved.