

KORO Large Rodent Trap Instructions

The KORO Large Rodent Spring Trap can currently be used to trap **rats and grey squirrels** in the UK under the conditions of use set out in The Spring Traps Approval Order.

Conditions of use are as follows:

The trap must be so positioned that animals can only enter it from the front, and set within an artificial blind tunnel which is suitable for the purpose. (The front is the side from which the letters KORO can be read face-on and the correct way up.)

A Koro Large Rodent Trap is set as follows:

Step one:

Place the trap on a solid surface facing away from you.



Step two:

Ensure safety catch & trigger pin are located outside of the trap.



Step Three:

Place thumb/s behind top rear bar of trap and lift strike bar with index finger/s.



Step Four:

Rotate safety catch to hook the strike bar.



Step Five:

Rotate trigger pin & place the end into the round hole located on the trigger pan. Trap sensitivity is adjusted by locating plate higher or lower on pin.



Step Six:

Rotate safety catch so that it is resting outside of the trap.
The trap is set.



If you require any further assistance please do not hesitate to contact us.



Visit our site