REPLACE SPECTRA CANOPY

TAKE OFF THE OLD CANOPY

Remove the fixation hook.

First slide down the tissue so you can remove the rubber cap first, then remove the fixation hook, then put the rubber cap back on.



Unscrew the bolt on the head. For a spectra before 2022, it will be fixed in position 1, for the 2022 model, it will be in position 2.

Keep this bolt and washer, you will need this to reattach the new canopy.



If you want to reuse the canopy, you can put a protection cloth down on the canopy.

Put the spectra in upright position, and the canopy will slide down. Pull out the glassfibre in the profile carefully. You need this to reinstall the new canopy.

Discard the old canopy properly.



REINSTALLING THE CANOPY

Put the glassfibre stick in the new canopy, it should slide easily in the smallest tunnel of the canopy, positioned in the middle.

Then, put a cloth or protection sheet on the base, so you do not stain the new canopy.





Stick a small piece of paper tape on the hinge of the frame to avoid scratches.

Find the middle, where you put in the glasfibre, and position this under the frame

First, put in the 4 longest ribs





Then, carefully slide in the glasfibre rib, into the arm profile. Do not use exsessive force so you don't rip the fabric.



Put in the other 4 ribs



Carefully slide the canopy up, this might be easier if you ask someone to help hold the canopy



UMBROSA

Beversesteenweg 565B 8800 Roeselare BELGIUM T: +32 51 30.22.60 F: +32 51 30.22.62 E: info@umbrosa.com When you reach the top of the frame, put the frame horizontal, so you can screw in the bolt



Make sure the small glasfibre rib is completely in the fabric and in the profile

Reattach the fixation hook and the rubber end, slide in the handles.

Well done, now you can use the parasol as before!

