





Model: SPAEX2.25 – 2.25KG Novec Extreme Electrical System

Installation Instructions

FIA Homologation EX.049.18

Please Read Carefully Before

Attempting To Install Your Fire <u>Suppression System</u>



The Mill House, Tamworth Road, Packington Hayes Nr Lichfield, Staffordshire, England, WS14 9PN Tel: 01543 434580 Fax: 01543 434581

> Email: sales@spa-uk.co.uk Web: www.spa-uk.co.uk



Electrical 2.25kg Novec 1230 System



Thank you for purchasing one of our latest range of FIA Homologated EX.049.18 fire suppression systems for open cockpit applications. This manual covers the following model system SPAEX2.25. It is important that you read the following instructions carefully before attempting to install your fire suppression system. The performance of these systems could be affected if they are in any way modified or tampered with which will void its homologation. Please ensure you only use genuine SPA parts should any part need replacing.

Should you require assistance with this please call below

Tel: +44(0)1543 434580

	Index	Pages
•	Contents List	2
•	Cockpit Nozzle Location	3
•	Engine Nozzle Location	4
•	Nozzle Orientation	5
•	Pipework & Fittings Layout	6
•	Cylinder Dimension Drawing	7
•	Automatic Head Information/ Fitting Instructions	8
•	Electrical Details	9
•	Wiring Schematic Diagram	10
•	General Maintenance Information	11
•	Cylinder Mounting Images	12
•	Novec 1230 Data Sheet	13

Contents List

Model: SPAEX2.25 2.25 KG Novec Extreme Fire Suppression System

- 1 x SP147 5" Diameter Retaining Straps x 2.
- 1 x SP319 Anti Torpedo Tabs x 2.
- 4.5 x SP032 8mm Decabon Tubing Per Meter.
- 2.5 x SP072 10mm Decabon Tubing Per Meter.
- 0.5 x SP181 12mm Decabon Tubing Per Meter.
- 1 x SP182 12mm 10mm Y Piece Connector.
- 1 x SP183 10mm 8mm Y Piece Connector.
- 1 x SP186 10mm 8mm Straight Reducer Connector.
- 1 x SP185 10mm Bulkhead Connector.
- 2 x SP187 8mm Engine Bay Nozzle.
- 1 x SP481 8mm Cockpit Deflector Nozzle.
- 1 x SP007H Power Pack Control Unit.
- 2 x SP005H 2M Connector and Lead.
- 1 x SP011 Internal Firing Button.
- 1 x SP012 External Firing Button.
- 1 x SP017 Large E Location Sticker.
- 1 x SP029 Small E Location Sticker.
- 1 x SP530 Manual Instructions.

Cockpit Nozzle Location Open Cockpit

The SP481 cockpit nozzle is specially engineered as a fully multidirectional nozzle, this allows you to position the nozzle as shown in figure 1 or 2 which will cover the driver and front foot-well position.

Fig1






Fig2



Engine Bay Nozzle Location

Two nozzles should be mounted in Engine compartment Figure 1 All models



Tubing

Each SPA Extreme system is supplied with Decabon tubing which is a coated aluminium tube which can be molded and flexed to suit this application.

The SPA Extreme system has been designed using this type of tube. DO NOT substitute this tube for any other type.

MULTI-DIRECTIONAL NOZZLES

Please note that nozzle shown in Fig.A must only be used in engine bay. Nozzle shown in Fig.B must only be used in cockpit.

fig A fig B





It is important that the correct nozzles supplied with the system are used, the nozzles produce a multi directional spray pattern and must be positioned as shown in Fig A.

fig A





Yes


Please note: Figure B Cockpit Nozzle Saloons Only


Cockpit Nozzle orientation for system model SPAEX2.25





Yes No





Automatic Head

The new activation valve fitted to certain models within the new range of SPA systems has a special safety feature, that does not interfere with the standard operating procedure of the fire suppression system.

The automatic activation feature is a standalone activation that will operate independently of user input at a temperature specified by the manufacturer.

Important Note

The fire suppression system requires input by the user by either mechanical cable pull or electrical switch to operate. The automatic activation is a safety backup feature only, it is not the primary means of activation the primary means of activation is the driver using the cable pull or electrical switch depending on model purchased.

Electrical Fitting Instructions

Unpack all parts and check components against 'kit list'.

- Remove bottle from mounting brackets if fitted by undoing the wing nuts. Decide the best position for the extinguisher – IT IS RECOMMENDED THAT THE BOTTLE SHOULD BE MOUNTED IN THE FORE AND AFT DIRECTION OF THE VEHICLE.
 - The extinguisher label, detailing the contents and the pressure gauge should be clearly visible for inspection, Mount the retaining brackets securely to the vehicle and put the bottle back into place.
- Mount the power pack in a clearly visible position.
- > Switch with red plastic shroud to be fitted in the cockpit so that it is in easy reach of both the driver and/or co-driver when sitting in the normal driving position and wearing fully fastened seatbelts.
- > The other switch with flexible red membrane (waterproof) is to be fitted to the outside of the vehicle, close to the exterior master switch (for activation by the Marshals).
- > Once the system has been wired as per wiring diagrams the following tests should be carried out to check the system is fitted correctly and will operate when required.

SPA Design Extreme Electrical Details

The SPA Extreme system uses actuators to operate valves located within the pressurized container that contains the extinguishant. These are triggered remotely using a battery-powered power pack.

In order to guarantee reliable operation, the connectors used are 1P67 and the actuators used are of a military specification with the system / battery test electronics integrated into the power pack.

The power pack electronics can test the continuity of the wiring and provides a high current pulse test to ensure system integrity before use. Unlike other systems, the battery test will not destroy or put an excessive drain on the battery during this critical test. These tests are performed using a three way switch on the power pack box and should be performed before each usage of the system, since the system is only as good as the battery that powers it and the integrity of the wiring loom and its connectors.

To check the condition of the battery press and hold up the switch on the power pack box in battery check position. **Every two seconds you will see a <u>YELLOW</u>** light flash, If the light flashes very dimly the battery must be replaced.

IF IN DOUBT REPLACE THE BATTERY !!!!

To check the continuity of the wiring, ensure that the switch on the power pack box is in the **SYSTEM INACTIVE** position to ensure that the extinguisher is not fired.

Press the internal firing button and check that the <u>**RED**</u> light comes on, press the external firing button, and check that this also makes the <u>**RED**</u> light come on.

The external button must be positioned close to the exterior master switch. When you are ready to race after all these checks push switch into system armed position, the control box will not illuminate in the system armed position if either internal or external switches are pressed the system will activate.


<u>**DO**</u> ensure that the wiring cables do not run next to looms especially if they contain ignition or battery cables

<u>DO</u> ensure that any exposed connections that are likely to get water sprayed are protected.

DO NOT allow cables to run through sharp edged apertures without protection

DO NOT fix cables to any surface that is likely to see excessive temperatures.

Wiring Schematic



The wiring loom is 3 cable please note only the Blue and Brown are used, cut Black off.

To test the battery, push and hold control box switch upwards in the "Battery Check" position until yellow light flashes.

If the extinguisher tubing is to be removed, push the black collet in and pull the tubing out at the same time.

RECOMMENDED: Use the continuity test and battery test before each race.

DO NOT: Run the cables next to power cables, or in the same loom.

General Maintenance Information

Tubing

Each SPA Extreme system kit is supplied with Decabon tubing which is a coated aluminium tube which can be molded and flexed to suit this application. The SPA Extreme system has been designed and homologated using this type of tube. <u>DO NOT</u> substitute this tube for any other type.

Tube Connectors

All fittings for tube to nozzles and bottles are of the push-in type. Insert the tube into the fitting, push firmly until it clicks. Once in you should not be able to pull it out. To remove the tubing, push the tube into the fitting and at the same time push the black plastic collet back towards the fitting and then pull the tube from the fitting.

Maintenance

Toensure maximum possible performance from your SPA Extreme system, the following checks and maintenance procedures should be carried out. Regularly check Nozzles for debris or any obstructions externally & internally.

Regularly check the integrity of the pipe work and fitting. Regularly check the cylinder for damage or corrosion.

Regularly check the mounting bracket, retaining straps and anti-torpedo tabs are secure.

Your SPA fire suppression system must be serviced every 2 years, a service due date is written on the contents label located on your cylinder. It is up to you to ensure the services are carried out at the correct intervals.


If your system has been discharged or requires a 2-year service, you must return it to SPA or a service agent approved by SPA for it to be FIA certified for continued use.

Notes


Please ensure that you monitor the following as you may not pass scrutineering

- 1. If the bottle contents label is worn, damaged or unreadable.
- 2. The system is not within service date.
- 3. The system is in poor condition.
- 4. The pressure gauge is reading in the red.

Cylinder Mountings



SP148 - 5" Cylinder Retaining Bracket



SP319 – Anti- Torpedo Style Mounting

Extreme Data Sheet

Auto-sport industry - including saloon race cars& single seaters. **Application**

Composition Dodecafluoro-2-methylpentan-3-one CF3CF2C(O)CF(CF3)2

Ozone depletion

potential

- 40 to + 80·C

None

Operating -108·C

temperature 168.7°C

Freezing point No observed adverse effect level and

lowest observed adverse effect level for

cardiac sensitization (halocarbon) and Critical temperature

oxygen depletion (Inert gas).

Physiological properties

A copy of the 3M™Novec™ 1230 fire protection fluid material safety data sheet can be obtained from SPA Design or SPA Technique upon request.

NOTES





