

OXYGENATION KIT

Description

It is used for wort oxygenation at the outlet of the plate cooler. Entrance is through the valve, with the oxygenated wort coming out through the sight glass. The butterfly valve allows flow regulation while the sight glass allows visual inspection of oxygenation.

Advantages

In oxygenation, the stones allow the incorporation of oxygen into the wort, which improves not only the reproduction of the yeast, but also the health of the cells. By improving their health, they acquire a greater tolerance to high alcohol content. For these reasons, it is possible to reduce the fermentation time with a correct oxygenation.



Components



Tri-clamp butterfly valve 38 mm. with 3-position stainless steel handle.



Tri-clamp tee 38 mm.



1/4" clamp-thread oxygenation stone, 100 mm. total length.



Tubular sight glass 38 mm.



All gaskets and clamps included in the kit.



Kit for wort oxygenation, prior to entering the fermenter.