



CYMRIC J01 OB

**Applications:**

- Medical Application
- Pharmaceutical Industries
- Hospital service
- Small Manufacturing unit
- Hotel Industries

## CYMRIC J01

**Material used**

Upper: Black microfiber

Lining: Mesh nylon black

Collar: Micro fiber black

Sole: Polyurethane direct injected double density sole

Toecap : Plastic

**Category/protective function:**

OB SRC

**Average Size**

Euro : 36 to 47

UK : 3-12

**Color**

Upper: Black

Mid Sole: Black

Out sole: Black

**Standards:**

EN ISO 20347:2012

IS 15298:2017 PART 4

**PPE CATEGORY:**

II



## OCCUPATIONAL FOOTWEAR

*Black easy clean microfiber upper with synthetic mesh lined low ankle footwear with double density PU injected sole*

*Removable EVA foot bed,  
Cleated PU sole ,  
Energy absorbent heel  
Antistatic  
Slip and Oil resistant sole*



**MALLCOM INDIA LTD**

EN 12, Sector V, Salt Lake City

Kolkata 700091, India

T: +E : [safety@mallcom.in](mailto:safety@mallcom.in), w : [www.mallcom.in](http://www.mallcom.in)



**Safe feet!!**

#### Instruction for use

These footwear to be worn in such place where mechanical hazard levels are low. These footwear will offer slip resistant protection and mild static electric

#### Limits to use:

Do not use this footwear out of its usage specifications defined in the instructions above. This footwear does not contain substance known as being carcinogenic, neither toxic, nor likely to cause allergies to the sensitive people.

#### Instructions for storage:

Store the footwear in cool dry place away from frost and light in their original carton and packing.

---

*Our superior range of Occupational footwear provides excellent comfort and durability with unparalleled mechanical resistant properties to keep feet safe*

---

#### Warning

Footwear not to be worn when there is a risk of entanglement by moving parts of machines.

#### Instructions for cleaning / maintenance:

After any use, leave unpacked footwear in a ventilated place away from heat source. To remove and any clay and dust, use normal puff brush or soft cloth. As this footwear is WASHABLE, can be cleaned with soft foam water and wipe with soft dry cloth

#### Performance:

These footwear comes under OB category and Complies under standard EN ISO 20347:2004 and IS 15298:2018 PART 4

#### Marking Instructions:

Marking usually takes place on footwear tongue. Components of marking placed one by one accordingly as follows –

- I. CYMRIC J01 OB
- II. Size marking
- III. Month/Year (MM/YY)
- IV. Logo of instruction manual
- V. Manufacturer's Name : Mallcom India Limited
- VI. Manufacturing -Country of Origin: India

#### Packaging Instruction:

1 pair footwear in primary box.  
10 boxes in corrugated carton.



**MALLCOM INDIA LTD**

EN 12, Sector V, Salt Lake City  
Kolkata 700091, India

T: +E : [safety@mallcom.in](mailto:safety@mallcom.in), w : [www.mallcom.in](http://www.mallcom.in)