

FREDDIE H01 S1 DD

# **Applications:**

Pharmaceutical Industry , Inspection and Maintenance Agrochemical handling Decomposition of production plants, Industrial cleaning and Maintenance Emergency response services, spill clean-up and accident interventions Disease and disaster management, Medical applications



# **FREDDIE H01**

# Material used

Upper: Knitted Polyester Collar lining: Airmesh black Sole: Polyurethane direct injected double density sole (Oliver) Toecap: Composite (impact resistant 200 J)

Sole insert: TPU shock absorber

heel patch

Category/protective function: S1 SRC

# **Average Size**

Euro : 37 to 47 UK : 4-12

# Color

Upper: Grey & Back blended Out sole: Grey Mid sole: black

**Standards:** EN ISO 20345:2011 IS -15298 (PART-2) : 2016

# Certification Category :



# SAFETY FOOTWEAR Low ankle non-

Low ankle nonmetallic safety shoe, Aesthetic design, Removable PU foot bed, Cleated PU sole for extra grip, Energy absorbent heel Antistatic Slip and oil resistant sole



## MALLCOM INDIA LTD

EN 12, Sector V, Salt Lake City Kolkata 700091, India T: +E : <u>safety@mallcom.in</u>, w : www.mallcom.in



Safe feet!!

# Instruction for use

Safety footwear worn in the workplace is designed to protect the foot from physical hazards such as falling objects, stepping on a sharp object, heat and cold, wet and slippery surfaces, exposure to corrosive chemicals, compression (roll over or piercing objects), Vibration.

#### Limits to use:

Do not use this footwear out of its usage specifications defined in the instructions above. This footwear does not contain substance known as being carcinogenic, neither toxic, nor likely to cause allergies to the sensitive people.

## Instructions for storage:

Store the footwear in cool dry place away from frost and light in their original carton and packing.

Our superior range of Safety footwear provides excellent comfort and dexterity with unparallel mechanical resistant properties to keep feet safe

#### Warning

Footwear not to be worn when there is a risk of entanglement by moving parts of machines.

#### Instructions for cleaning / maintenance:

After any use, leave unpacked footwear in a ventilated place away from any heat source. To remove any clay and dust, use a non metallic brush. For polishing, use a standard product. It is recommended to clean the footwear thoroughly after use and leave it to air prevent foul odor and maintain hygiene.

### Performance:

This safety footwear are personal protective equipment according the European Directive to 89/686, special for ergonomics, harmlessness. comfort and complies furthermore the basic and marked additional EN ISO requirements of 20345:2011 & IS -15298 (PART-2):2016

# **Marking Instructions:**

Marking usually takes place on footwear tongue. Components of marking placed one by one accordingly as follows – I. FREDDIE H01 S1C II. CE Marking 20345 III. Size marking IV. Month / year (MM/YY) V. Logo of instruction manual

# **Packaging Instruction:**

1 pair footwear in primary box. 10 boxes in corrugated carton.



#### MALLCOM INDIA LTD

EN 12, Sector V, Salt Lake City Kolkata 700091, India T: +E : <u>safety@mallcom.in</u>, w : www.mallcom.in