



## **Instructions Manual**

Please read carefully

**TLC Diagnostics Pty Ltd**

**23/62 Newton Rd, Wetherill Park NSW**

**info@medescan.com.au**

**www.medescan.com.au**

**1300 736 330**

**Designed in Australia**

**Made in China**



## Precautions

- Do not disassemble the machine during operation. Always unplug from power before refilling or cleaning.
- Use normal temperature water.
- The use of purified water is recommended.
- The water level must be filled below the “Max” water level line.
- Do not immerse in water to avoid electrical malfunction.
- Do not touch the atomizer directly by hand especially when the unit is in operation.
- Use a soft cloth to clean the water tank and atomizer once every 5 to 6 uses.
- Always dry the unit before storing.

## How to use

1. Open the covers.
2. Fill water tank with water below the “Max” water level line.
3. Add your preferred essential oil.  
We recommend 2 to 3 drops depending on personal taste.
4. Replace both inner and outer covers ensuring they are correctly aligned and firmly closed.
5. Connect the USB power cable into the socket on the Medescan Rainbow Mist Mini.
6. Connect the USB cable to a suitable power adapter or computer USB port. Power supply must be a minimum of 5V and 1000 mA.

## **Mist Button**

1. Press the Mist button one time, the ON indicator light on, Rainbow Mist Mini will produce continuous mist until it runs out of water. Press and hold the Mist button for two or three seconds to enter the intermittent mode (the Int indicator light on) and keep intermittent misting, 30 seconds on and 30 seconds off until it runs out of water.
2. Press Mist button a second time for the 2H timer mode, the 2H indicator light on, and will continuously mist for 2 hours, then diffuser will power off. Press and hold MIST button two or three seconds to enter the intermittent mode (the Int. indicator light on) and intermittent mist 2 hours then off.
3. Press Mist button a third time, the 4H indicator light on, and will continuously mist for 4 hours, then the diffuser will power off. Press and hold MIST button for two or three seconds to enter the intermittent mode (the Int indicator light on) and intermittent mist 4 hours then off.
4. Press fourth time, the machine turns off.

## **Light Button**

1. Press the LIGHT button once to slowly cycle through all the colors.
2. Press the light button a second time to keep the present color lit.
3. To change the color manually, repeatedly press the light button until you find your preferred color.
4. To turn the light off, hold the light button down for two or three seconds.

## Troubleshooting

<p>No mist spray or mist spray state is not well</p>	<ol style="list-style-type: none"><li>1. Clean if atomizer is dirty.</li><li>2. Make sure water level is below the "Max" water level line.</li><li>3. Make sure the inner and outer covers are installed correctly.</li><li>4. Please ensure the power adapter is correctly installed and plugged into the power. Ensure the correct power adapter is used (5V).</li></ol>
<p>Water leaking</p>	<ol style="list-style-type: none"><li>1. Ensure the outer and inner covers are firmly and correctly installed</li><li>2. Ensure both inner and outer cover are correctly aligned.</li><li>3. High ambient humidity or low ambient temperature may cause formation of dew.</li></ol>



**[info@medescan.com.au](mailto:info@medescan.com.au)**

**[www.medescan.com.au](http://www.medescan.com.au)**

**1300 736 330**

Vitis our YouTube channel for our latest easy to follow instructional videos. Simply search for MedeScan on YouTube and subscribe to our channel for the latest products and instruction videos.