



# H-2999.4F

## Concrete Vibrator



### Description:

Lightweight square-head model is used for vibrating concrete test cylinders and molds in the laboratory or field. Unit is flexible-shaft type, powered with 3/4 HP electric motor. Shaft is 24" (610mm) long; vibrating head is 1" sq x 13" L (25 x 330mm) with a speed of 10,000 vpm.

Supported standards:

ASTM C31, C138, C192; AASHTO T23, T97

### Models:

#### H-2999A

Power: 115V, 7 amps, 1ph

Suitable models for Australia:

#### H-4953.4F

Power: 230V, 3.6 amps, 1ph.

### Product Options

#### Part Number & Name



H-2999A

Concrete Vibrator Concrete Vibrator with Flexible Shaft, 120V 60Hz



H-2999A.4F

Concrete Vibrator Concrete Vibrator with Flexible Shaft , 230V 50/60Hz