

## THROAT PLUGS



### PLASTIC

The Adept Beef Plug can be used to provide temporary esophagus occlusion (weasand sealing) prior to application of the Adept Weasand Clip. Adept's Beef Plug is a fast and simple to insert using the Adept Throat Plug Pusher rod. The plug delivers effective short term ingesta hold. Available in two sizes.

- > Suitable for all types of cattle
- > Designed for minimal insertion resistance
- > Forms a secure internal seal of the weasand that blocks immediate release of ingesta
- > Packaged in stacks for ease of access to operator
- > Plugs can be used multiple times if recovered and washed

Product Code	1221-002 0162-001 (calf size)
Supplied	1,200 plugs per carton (calf 1000)
Material	Plastic
Dimensions	62mm or 50mm
Carton Dimensions	L: 460mm, W: 315mm, H: 380mm 10.3KGS
Applicators	Beef Throat Plug Pusher (1221-003) Beef Throat Plug Pusher - Water Flushing (1221-840)



### SOLUBLE

The Adept Soluble Beef Plug offers the same temporary esophagus occlusion as the Beef Plug with the added benefit of being water soluble. The plug is made from Adept's water soluble material ADSOL and safely dissolves after use.

- > No need or cost to recover as the plug dissolves inside the paunch (zero impact on paunch waste stream)
- > Suitable for all types of cattle
- > Designed for minimal insertion resistance
- > Forms a secure internal seal of the weasand that blocks immediate release of ingesta
- > ADSOL is Adept's proprietary water soluble technology, formulated from food grade components

Product Code	1221-017 0162-002 (calf size)
Supplied	1,200 plugs per carton (calf 1,000)
Colour	White, Orange, Green (additional colours available on request)
Material	Adsol Water Soluble
Dimensions	62mm
Carton Dimensions	L: 480mm, W: 315mm, H: 380mm 19.4KGS
Pushers	Beef Throat Plug Pusher (1221-830) Beef Throat Plug Pusher - Water Flushing (1221-810)
Dispenser	Soluble Beef Throat Plug Dispenser (1362-810)