

TCB SERIES

VER 001

TCB SERVICE MANUAL





TMT


INDEX


1. Calibration & Gravity compensation	3
2. Wireless Pairing	5
3. Exploded View	6
4. Firmware Update	7


















1. Calibration & Gravity Compensation

1.1. Calibration



When the power is off, press  while pressing 


When 'G-CAL' is displayed, and then press 

Then this calibration mode is started. 













No.	TITLE	DISPLAY	KEYBOARD & DESCRIPTION
1	How to enter	G-CAL	  
2	Program version	7.100	Move to a next step in automatic
3	Maximum capacity	CAPA 5000	 Initialized value  numeric increase  scale increase /  save
4	Minimum division	d w 2	 decrease /  increase  save
5	Setting weight	SEt-F 5000	 Initialized value  numeric increase  scale increase /  save
NB : Setting weight shall be within the range of 10 %~100 % of max. capacity			
6	Zero calibration	ZEro -----	Unload the tray and press 
7	Span calibration	LoAd -----	Load the weight which was set in step 5 and press 
8	Finish	End	Unload the tray and press 

1.2. Gravity compensation

When the power is off, press  while pressing 

When 'G-CAL' is displayed, and then press  again.

Then this gravity compensation mode is started.















No.	TITLE	DISPLAY	KEYBOARD & DESCRIPTION
1	How to enter	G-CAL	  
2	Program version	t - 100	Move to a next step in automatic
3	Calibration location	GrAu 1 9799 (9.799m/s ²)	 Initialized value  numeric increase  scale increase /  save
4	Using location.	GrAu 2 9799 (9.799m/s ²)	 Initialized value  numeric increase  scale increase /  save
5	Finish	End	Unload the tray and press 

i If the GrAu 1 value is same with GrAu 2, it doesn't need to compensation set.


1.3. Check message

Code	Description
Ch 03	The resolution is set to be exceeded the limit 1/50,000. Check the resolution.
Ch 04	The balance weight for span calibration is lower than 10%, or greater than 100% of the maximum capacity of the scale. The weight for span calibration should be within 10%~100% of the maximum capacity of the scale.
Ch 05	Load cell output is too small or large at span calibration. Check the weight unit and load cell or calibrate with lower resolution.

2. Wireless Pairing

Step	Operation & Description
1	<p><u>How to enter the pairing mode</u></p> <p>1) TCB crane scale When the display is off, press  key while pressing  key. When “$t=40$!”(Firmware version) is displayed, press  key. Then, “rF5Et” is displayed.</p> <p>2) TD3000(2300)F wireless display Press the  key to power on and immediately press  key. And press the  key again. Then, “rF5Et” is displayed.</p> <p>3) TF-100 controller When the display is off, press  key while pressing  key. When “$t=50$!”(Firmware version) is displayed, press  key. Then, “rF5Et” is displayed.</p> <p>4) TF-400 controller Press the  key and press  key at the same time. And then, press  key. Then, “rF5Et” is displayed.</p> <p>5) TF -200 wireless dongle Press the [SET] KEY for the 5 seconds with the power on that connected. Then, the green light is blinking.</p>
2	<p><u>Pairing</u></p> <p>When “rF5Et” is displayed at both products, if you press  key of TCB crane scale, pairing will finish.</p> <p> Please check “End” message at both products. (IR -200: green light will be turn on) If ending message is not appear, please repeat the pairing.</p>

3. Exploded view




No	NAME	SPEC				QTY
		1ton	3ton	5ton	10ton	
1	Shackle	5/8		7/8	1,1/4	1
2	Hook assy		3T	5T	10T	1
3	bolt		M5 x 20			4
4	Spec plate		95 x 40			1
5	bolt		M6 x30			4
6	Rivet		BLIND 2.5 x 6			2
7	gasket		200x120x3.5			1
8	Battery-cover assy		TCBL			1
9	LC CAP	66x55x9 1T	66x55x9 3T	66x55x9 5T	120x96x6 10T	1
10	Keypad	169x29(Selection for LCD type or FND type)				1
11	TCB body	215x220x135(5T)			10T	1
13	Front panel	201x121x20				1
14	PCB assy	LCD type or FND type				1
15	Screw	Flat head M4x16				10
16	Code-stopper	PG7				2
17	LC cover	1T	3T	5T	10T	1
19	Loadcell	CSS3-1T	CSS3-3T	CSS3-5T	CSS3-10T	1
20	LC BRK	1T	3T		10T	1
22	Wrench Bolt	Round Head M10 x 25				2
23	BATTERY PACK	TLP-100(LCD type) or TLP-200(FND type)				1
24	BATTERY COVER	LCD type or FND type				2
25	Power-cable	Ø2.5x400				1
26	Remocon	IR-100				10
27	Adaptor	LCD type : 5V,1A , Ø3.5 or FND type : 12V,1A , Ø3.5				1

4. Firmware Update



1. Install the 'MPLABX'
2. Run 'MPLAB X IDE'
3. Connect the PICkit3 to PC
4. Connect as shown in the picture below.

Aligned the RED wire and arrow mark of PCB, and then combines them.




5. Select the HEX file (File – Import – Hex/ELF... (Prebuilt) File)

SEE ATTACHED VIDEO

- 1) Prebuilt Filename: Bring up the HEX file
- 2) Family: 16-bit MCUs (PIC24)
- 3) Device: PIC24FJ64GA306
- 4) Supported Debug Header: None
- 5) Hardware Tool: PICkit3
- 6) After the above setting, click NEXT  NEXT  Finish.

6. Set the Project Properties (File – Project Properties) SEE ATTACHED VIDEO

- 1) Click PICkit3 in Categories
- 2) Option categories: Memories to Program
- 3) Preserve Program Memory: Select
- 4) Preserve Program Memory Start (hex): 0x0800
- 5) Preserve Program Memory End (hex): 0x1FFF
- 6) After the above setting, click Apply.
- 7) Option categories: Power
- 8) Power target circuit from PICkit3: Select
- 9) After the above setting, click Apply  OK.

7. Upgrade firmware SEE ATTACHED VIDEO

- 1) Click the Make and Program Device icon.
- 2) Confirm the complete message.