Ultra-Fast Tabletop Resin

MIX RATIO 2 to 1 BY Weight

Calculate the amount of resin you need. This can be done on the resin calculator at resinzwood.com. Accuracy is important when mixing **Part A** and **Part B** together. This product is designed for pouring up to 8mm deep in 18 to 22c with a Cure Time of 3 to 5 hours. Full tutorial and info under How To at resinzwood.com Phone Support Call Paul 021966397

- You can preheat resin in containers in a hot water bath.
- Measure out Part A and Part B in separate containers by volume.
- Best calculation to use is 2mm to 3mm per square meter
- Add your **Part A** to **Part B** and mix well till blended.
- Use a flat stirrer for mixing. Avoid hard beating creating air bubbles.
- Pour out your resin. Use a blue flame torch to pop bubbles.
- Full Tutorial can be found under How To on resinzwood.com
- Pot Life at 1 liter 10 mins Cure Time 3 to 5 hours

FIRST AID. Uncured mix of resin Wash off IMMEDIATELY with water. If resin comes into contact with your eyes, wash with water for at least 15 minutes and seek medical help. **NEVER RUB YOUR EYES.**

Ingestion: Never Induce vomiting, wash out mouth thoroughly and seek medical attention immediately

Caution: This product can be sensitive to the skin. Always wear correct PPE, glasses, mask, gloves. You may wish to use a barrier cream on your skin first as this aids in protection. You can use White vinegar to wash your hands/ skin then warm soapy water.

Notes: This product is intended for indoor use mainly but can be used in outdoor projects as resinzwood products contain a high UV additive. Keep out of direct sunlight when not in use to avoid damage and yellowing over extended time periods. Contact Paul 021966387 for more info. Full tutorials, Tips, Tricks under How To at resinzwood.com. This product has a shelf life of over 24 months when kept in a cool shaded place.

Contact Info.

- Email: resinwoodtablesnz@gmail.com
- Contact us on Messenger facebook/resinwoodtablesnz
- Phone Paul 021966387

Classification Symbol here