# **Repair Instructions**



### **Replacing and Installing a New Control Touch Panel**

Elite Models that Apply: EL04, 5, 5-LE.					
Step	Description	Tools	Picture		
1	Unscrew the (4) screws that attach the control panel to the red case.		Circuit Board Case Screws marked in white		
2	Disconnect the 2 red (positive) and 1 black (negative) wires from the battery terminals.		Battery Terminal Wires Marked in Green		
3	Unscrew the 4 screws which hold the Touch Panel to the Circuit Board.		Control Panel Removed  Unscrewing Circuit Board from Touch Panel.  Marked in Orange.		
4	Disconnect the blue Spectra Ribbon which connects to the circuit board.				

Author: JJ Contributors: MP,RR Orig Date: 2/12/14 Revised: 3/4/2022 support@lobsterinc.com Phone: 800.526.4041 Fax: 818.764.6061

# **Repair Instructions**



## **Replacing and Installing a New Control Touch Panel**

		Disconnected Spectra Ribbon Cable Marked in Red.
5	Attach the Spectra Ribbon to the circuit board (from the new touch panel).	Reconnected Spectra Blue Ribbon
6	Fasten the circuit board to the new Touch Panel.	Circuit Board being Fastened to Touch Panel.
7	Once you have connected all of the wires to the new control panel you then need to connect the battery terminal wires. Connect black (negative) and then the 2 red (positive) wires to the battery terminals.	Battery Terminal Wires
8	Fasten the control panel back onto the Red Case.	Circuit Board
9	If you have any difficulties or questions, or a motor or component is still not working after installing the control	

Author: JJ Contributors: MP,RR Orig Date: 2/12/14 Revised: 3/4/2022 support@lobsterinc.com Phone: 800.526.4041 Fax: 818.764.6061



Author: JJ



## **Replacing and Installing a New Control Touch Panel**

panel, please contact Technical Support at: 1-800-526-		
panel, please contact reclinical support at: 1-600-520-		
4041.		
<del>1</del> 011.		

Contributors: MP,RR Orig Date: 2/12/14 Revised: 3/4/2022 support@lobsterinc.com Phone: 800.526.4041 Fax: 818.764.6061