

#### **CONTENTS**

	02
FRAME ASSEMBLY	04
PRE-ASSEMBLY	60
CORE STABILIZER PAD PRE-ASSEMBLY	65
Mi7 FRAME PRE-ASSEMBLY	<b>6</b> 6
DECAL PLACEMENT	67
MI7 FRAME DECAL PLACEMENT	68
CORE STABILIZER PAD DECAL PLACEMENT	69
ACCESSORIES	73
TABLET/PHONE HOLDER	74
BOLTING MI7 CABLE TO THE FLOOR	73
DECAL REFERENCE	<b>7</b> 4
PART LIST	78
MI7 FRAME PARTS LIST	82
CORE STABILIZER PAD PARTS LIST	83
ABBREVIATIONS	84
BOLT SIZING CHART	85
WASHER SIZING CHART	86
MAINTENANCE SCHEDULE	88
GENERAL MAINTENANCE INFORMATION	89
WEIGHT TRAINING TIPS	90
WEIGHT RATIOS	91
WEIGHT TRAINING EXERCISE LOG	92
LIMITED WARRANTY	93

### **INSTRUCTIONS**

Before beginning assembly please take the time to read instructions thoroughly. Please use the various lists in this manual to make sure that all parts have been included in your shipment. When ordering, use part number and description from the lists. Use only HOIST replacement parts when servicing. Failure to do so will void your warranty and could result in personal injury.

HOIST equipment is designed to provide the smoothest, most effective exercise motion possible. After assembly, you should check all functions to ensure correct operation. If you experience problems, first recheck the assembly instructions to locate any possible errors made during assembly. If you are unable to correct the problem, call your authorized HOIST dealer. Be sure to have your serial number and this manual when calling. When all parts have been accounted for, continue on.

#### **TOOLS REQUIRED**

**Ratchet Wrench** 

1/2", 9/16" and 3/4" Sockets

**Adjustable Wrench** 

**Rubber Mallet** 

**Tape Measure** 

Level


**Phillips Screwdriver** 


SAE Hex Key Wrench Set


**Two People** 


Teflon (PTFE) Based Lubricant

\*\*\*THIS PAGE WAS INTENTIONALLY LEFT BLANK\*\*\*













#### \*\*THIS PAGE WAS INTENTIONALLY LEFT BLANK\*\*














**Mi7 CABLE ASSEMBLY** 













































**Mi7 CABLE ASSEMBLY** 


















































































Mi7 CABLE ASSEMBLY










































CORE STABILIZER PAD DECAL PLACEMENT	
	NOTE:.
C	PARTS FROM CORE STABILIZER PAD PARTS LIST
	- SOME PARTS MAY HAVE BEEN REMOVED FOR CLARITY




















### PART LIST

ITEM NO.	PART NUMBER	DESCRIPTION	QTY
1	010-01C0703	CABLE ASSY. 274 - 7/8"	2
2	026-01X0186	PULL-PIN ASSEMBLY	2
3	026-01X3728	45 DEG. SWIVEL HANDLE ASSEMBLY	2
4	026-01X3823	HANDLE ASSEMBLY	2
5	026-01X5630	CHAIN LINK REPLACEMENT	2
6	026-01X6012	BASE FRAME	2
7	026-01X6013	SPINDLE MOUNT-2	2
8	026-01X6014	HUB-2	1
9	026-01X6017	HUB-1	1
10	026-01X6018	TOP FRAME	2
11	026-01X6019	ROTABLE ARM	2
12	026-01X6020	FLEECE KNEE STRAP WITH (1) D-RING & 2 SQ. RINGS ASSEMBLY	1
13	026-01X6689	CHIN ASSIST STRAP 4" WIDE	1
14	026-01X7090	PULLEY CARRIAGE	2
15	026-01X7091	COLUMN MOUNT	4
16	026-01X7093	INDEXING PLATE	2
17	026-01X7094	ADJUSTABLE PULLEY MOUNT ASSEMBLY $Ø3.50$ "	2
18	026-01X7098	SPINDLE MOUNT-1	2
19	026-01X7100	PULLEY COVER ASSY.	2
20	026-01X7108	CARABINER ADAPTOR	2
21	026-01X7110	ALUMINUM STRAIGHT BAR ASSEMBLY	1
22	026-01X7112	ALUMINUM CURL BAR ASSEMBLY	1
23	026-01X7113	STRAP HANDLE WITH (3) SQUARE RINGS	2
24	026-01X7117	CHIN UP MAIN FRAME	1
25	026-01X7118	HANGER MOUNT	2
26	016-0203008	PUSH FASTENER, .18" X .375" GRIP	16
27	011-0411001	SET SCREW: 1/4"-28 X .25" LG. (SS)	4
28	011-0711001	SET SCREW: 1/4"-28 X .25" LG. (Ni)	16
29	011-0711002	SET SCREW: 5/16UNC-18 X .25" LG. (Ni)	4
30	012-0202001	1/2"-13 FLANGED NUT (WZ)	4
31	012-0201002	CAP NUT 3/8-18 (Ni)	2
32	012-0504017	1"-8 Thin Nylock Nut (Ni)	4
33	012-0609007	CLIP ON NUT, 10-32	24
34	014-0012024	BEARING: 608-2RS_BEARING (8mm BORE) with 1.00" OD PVC outer ring 608-2RS Bearing with 1.00" OD PVC outer ring	8
35	014-0012025	BALL BEARING: SELF ALIGNING,Ø30mm I.D. X Ø62mm O.D. X 16mm	4

# PART LIST CONTINUED

TEM NO.	PART NUMBER	DESCRIPTION	QTY
36	014-0015040	Retaining Ring, E clip, 1/2"	2
37	014-0015041	Internal Retaining Ring, 2.44"	4
38	014-0101005	BUSHING: OILITE FLANGED Ø1.38" O.D. X Ø1.00" I.D. X .81" LG.	10
39	014-0104002	BEARING: SLEEVE, BRONZE 1.00 I.D. X 1.38 O.D. X 1.00" LG.	2
40	016-0002007	VINYL SLEEVE Ø.38" X 1.63"	4
41	016-0201022	END CAP $\phi$ 2.00" (BLACK)	4
42	016-0201038		2
43	016-0203005-G	1/2" PLUG	2
44	018-0001001	PULLEY: 2" BLACK W/ CONV. GRADE BEARINGS	8
45	018-0001002	CABLE PULLEY: Ø3.50"	10
46	019-0001001	PLUG BUMPER	4
47	019-0001006	THICK RUBBER DONUT $ otin 3.00"$ X .50" BLACK	4
48	019-0002048	OPEN END GRIP Ø1.50" X 7.25" LG.	2
49	020-0011018	Compression Spring	2
50	020-0011020	SPRING, COMP., .480" OD X 1.250" LG	2
51	020-0011022	EXT. SPRING38" OD, 3.0" LG, WIRE DIA028"	1
52	026-01G0504	GUIDE ROD: Ø.7500" CRS X 74.9748" LG.	4
53	026-01M0532	HEAVY FLANGED SPACER: $\emptyset$ .391" I.D. X .688" LG.	4
54	026-01M0932	ALUMINIUM CAP: Ø1.25" ID	4
55	026-01M0933	ALUMINUM RING: Ø1.25" ID	8
56	026-01M0935	ALUMINIUM RING: Ø1.50" I.D.	2
57	026-01M3003	SPACER	2
58	026-01M3004	FINISH BOLT-1	4
59	026-01M3005	FINISH BOLT-2	4
60	026-01M3311	SPACER, Ø1.5000" X .250 X 1.00" ID X .3750" LG.	4
61	026-01M3313	COLUMN	2
62	026-01M3314	PULL PIN: SHORT TAPERED END $ arphi$ .5000"	2
63	026-01M3315	$\phi$ .375" SHAFT	4
64	026-01M3322	SPACER, Ø.55" X .39" ID X 1.94" LG	2
65	026-01P5845	WASHER 1.88 OD x 1.00 ID x 1mm T	4
66	026-01P5858	BRKT-U 50 X 100mm FLAT OVAL	2
67	026-01P7017	SHIELD MOUNT	4
68	026-01PL0235-11	GRIP OPEN END $Ø.118$ " X 13"	2
69	026-01PL0235-12	GRIP OPEN END $ otin 1.43" $ X 4.25" LG.	2
70	026-01PL0369	WEIGHT STAND OFF	4

## PART LIST CONTINUED

TEM NO.	PART NUMBER	DESCRIPTION	QTY
71	026-01PL0371	DELRIN BUSHING	1
72	026-01PL2158	PLASTIC KNOB: Ø1.50" - BASE	2
73	026-01PL2159	PLASTIC KNOB: Ø1.50" - CAP	2
74	026-01PL2211-B	RUBBER FOOT	2
75	026-01PL2393	Ø3.0000" X .8125" ID X.313" T SPACER	4
76	026-01PL2444	CLIMB HOLD, LEFT	1
77	026-01PL2445	CLIMB HOLD, RIGHT	1
78	026-01PL2615	BUMPER	4
79	026-01PL2617	FLANGED SPACER	8
80	026-01PL2628	COLUMN SLEEVE	4
81	026-01PL2631	CATCH	1
82	026-01PL2636	CATCH RETAINER	1
83	026-01PL2653	CUP HOLDER	1
84	026-01PL2654	SHIELD-1	2
85	026-01PL0235-31	Ø1.188" X 7.00" OPEN END GRIP	2
86	026-01PL2681	TABLET HOLDER-1	1
87	026-01PL2682	TABLET HOLDER-2	2
88	026-01PL2683	TABLET HOLDER-3	2
89	026-01PL2684	PANEL H-TRIM	4
90	026-01PL2704	BOOT-4	2
91	026-01PL2705	SHIELD-3	2
92	026-01PL2708	TOP CAP-2	2
93	026-01PL2709	TOP CAP-1	2
94	013-1002011	#10 FLAT WASHER (Ni)	24
95	013-1002007	3/8" X 22mm FLAT WASHER (Ni)	78
96	013-1002004	1/2" X 34mm USS FLAT WASHER (Ni)	4
97	013-1006003	3/8" SPLIT LOCK WASHER (Ni)	32
98	013-1010007	#10 INTERNAL LOCK WASHER (Ni)	24
99	011-0701113	#10-32UNC x .75 BHCS (Ni)	24
100	011-0702087	M6-1.00 x 14 FHB (WZ)	2
101	011-0116204	1/4"-20UNC X .75" LOW HEAD SHCS (Ni)	2
102	011-0116142	3/8"-16UNC X 1.00" LOW HEAD SHCS (Ni)	5
103	011-0116144	3/8"-16UNC X 1.50" LOW HEAD SHCS (Ni)	2
104	011-0116145	3/8"-16UNC X 1.75" LOW HEAD SHCS (Ni)	10
105	011-0116150	3/8"-16UNC X 3.00" LOW HEAD SHCS (Ni)	4

# PART LIST CONTINUED


ITEM NO.	PART NUMBER	DESCRIPTION	QTY
106	011-0116151	3/8"-16UNC X 3.25" LOW HEAD SHCS (Ni)	2
107	011-0116157	3/8"-16UNC X 4.75" LOW HEAD SHCS (Ni)	4
108	011-0116160	3/8"-16UNC X 5.50" LOW HEAD SHCS (Ni)	2
109	011-0407022	3/8"-16UNC X 1.00" HHB (WZ)	4
110	011-0701085	3/8"-16UNC X .75 SHCS (Ni)	2
111	011-0701111	3/8"-16UNC X 1.00" BHCS (Ni) W/ DRI-LOC PATCH	8
112	011-0701021	3/8"-16UNC X 1.25" BHCS (Ni)	14
113	011-0701026	3/8"-16UNC X 2.50" BHCS (Ni)	2
114	011-0702021	3/8"-16UNC X 1.25" FHCS (Ni) W/NYLON PATCH	4
115	011-0702010	3/8"-16UNC X 2.75" FHCS (Ni)	2
116	011-0702024	1/2"-13UNC X 1.00" FHS (Ni)	16
117	012-0504004	1/4"-20 UNC THIN NYLOCK NUT (Ni)	2
118	012-0504005	3/8"-16 UNC THIN NYLOCK NUT (Ni)	29
119	012-0504002	1/2"-13 UNC THIN NYLOCK NUT (Ni)	4
120	WS#22	150 LBS. STACK (8.25 LBS. TOP PLATE W/ 20 HOLE STEM)	2
121	CORE STABILIZER PAD	CORE STABILIZER PAD	1
122	021-0003416	DECAL WIDE	2
123	021-0003417	DECAL NARROW	2
124	021-0003427	DECAL ADJUST	4
125	021-0003627	DECAL HOIST 2.07" X 7.75"	2
126	021-0003949	COLUMN ARROW DECAL	4
127	021-0003963	EMBLEM, Mi7 2.4924" X 3.9747"	3
128	021-0003964	DECAL: MI7 DIP ARM ROTATION	2
129	021-0003965	DECAL: WEIGHT STACK 22 (10-200 LBS.)	2
130	021-0018022	HOIST EMBLEM + 2 SIDED TAPE	2
131	SERIAL # DECAL	DECAL HOIST SERIAL # 1.63" X 2.63"	1
132	002-0001013	1cc of Synthetic Multi-Purpose Grease (PTFE)	4
133	002-0001036	TOUCH-UP PAINT - BOTTLE: 1oz COLOR: PLATINUM	1
134	011-0702011	3/8"-16UNC X 3.00" FHCS (Ni)	2


### Mi7 FRAME PARTS LIST


ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	026-01X6005	CROSSMEMBER-1	1
2	026-01X7160	SIDE-1	1
3	026-01X7161	SIDE-2	1
4	026-01X7162	CROSS-MEMBER	1
5	026-01X5186	LEVELING FOOT (M16X2.0)	2
6	012-0504009	16M X 2.0 FLANGED NUT (Ni)	2
7	016-0201050	otin 2.50" END CAP (DOMED)	1
8	026-01PL2566	CAP 1.97" X 3.94"	2
9	013-1002007	3/8" X 22mm FLAT WASHER (Ni)	6
10	013-1006003	3/8" SPLIT LOCK WASHER (Ni)	6
11	011-0701111	3/8"-16UNC X 1.00" BHCS (Ni) W/ DRI-LOC PATCH	6
12	021-0003008	DECAL COMMERCIAL MAINTENANCE 1.50 X 6.69	1
13	021-0003135	DECAL WARNING 1.50" X 6.69"	1
14	021-0003230	DECAL HOIST 1.625" X 6.0613"	1
15	SERIAL # DECAL	DECAL HOIST SERIAL # 1.63" X 2.63"	1

# CORE STABILIZER PAD PARTS LIST


ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	022-01PD2135-A	PAD ASSEMBLY	1
2	026-01X0186	PULL-PIN ASSEMBLY	1
3	026-01X6708	REMOVABLE SUPPORT FRAME	1
4	026-01X6709	STABILIZER PAD MOUNT	1
5	014-0101034	BUSHING: OILITE FLANGED 12.8mm I.D. X 19.3mm O.D. X 11.1mm LG.	2
6	026-01P4709	ROM PLATE	1
7	026-01PL2503	RUBBER FOOT 8.41" X 9.13"	1
8	026-01PL2808	SLEEVE FOR .473" [M12] SHAFT X 5.5000"	2
9	013-1002010	5/16" SAE FLAT WASHER (Ni)	2
10	013-1002007	3/8" X 22mm FLAT WASHER (Ni)	2
11	013-1002006	1/2" X 27mm SAE FLAT WASHER (Ni)	2
12	013-1010003	5/16" INTERNAL LOCK WASHER (Ni)	2
13	011-0701004	5/16"-18UNC X 1.25" BHCS (Ni)	2
14	011-0701019	3/8"-16UNC X .75" BHCS (Ni)	2
15	011-0116118	1/2"-13UNC X 3.75" LOW HEAD SHCS (Ni)	1
16	012-0504005	3/8"-16 UNC THIN NYLOCK NUT (Ni)	2
17	012-0504002	1/2"-13 UNC THIN NYLOCK NUT (Ni)	1
18	021-0003426	DECAL PULL	1
19	021-0003512	DECAL PINCH POINT 1.18" X 1.35" (TRIANGLE)	2







**Mi7 CABLE ASSEMBLY** 



**PAGE 87** 

### **Mi7 CABLE ASSEMBLY**

### **MAINTENANCE SCHEDULE**

ROUTINE	COMMERCIAL / LIGHT COMMERCIAL MAINTENANCE	HOME MAINTENANCE	LATEST DATE ENTRY									
Inspect; Links, Pull Pins, Snap Locks, Swivels, Weight Stack Pins	DAILY	WEEKLY										
Clean; Upholstery	DAILY	WEEKLY										
Inspect; Cables or Belts and their tension	DAILY	WEEKLY										
Inspect; Accessory Bars, and Handles	WEEKLY	3 MONTHS										
Inspect; All Decals	WEEKLY	3 MONTHS										
Inspect; All Nuts and Bolts, Tighten if needed	WEEKLY	3 MONTHS										
Inspect; Anti-Skid Surface	WEEKLY	3 MONTHS										
Clean & Lubricate; Guide Rods with a Teflon (PTFE) based lubricant (Superlube)	MONTHLY	3 MONTHS										
Lubricate; Seat Sleeves, Turcite Bushings, Linear Bearing	MONTHLY	3 MONTHS										
Clean and Wax; All Glossy Finishes	6 MONTHS	YEARLY										
Repack with Grease; Linear Bearings	6 MONTHS	YEARLY										
Replace; Cables, Belts and Connecting Parts	YEARLY	3 YEARS										

Your equipment comes with a commercial maintenance decal. For personal, in home use, please follow the home maintenance schedule listed above.

Never use ammonia, acid-based, or petroleum-based solvents on any portion of the machine as it may damage the finish.

### HOIST FITNESS SYSTEMS GENERAL MAINTENANCE INFORMATION

#### Links, Pull-Pins, Snap Hooks, Swivels, Weight Stack Pins:

\*Check all pieces for signs of visible wear or damage.

\*Check springs in snap hooks and pull-pins for proper tension and alignment.

\*If the spring sticks or has lost its rigidity, replace it immediately.

#### **Upholstery:**

\*To ensure prolonged upholstery life and proper hygiene, all upholstered pads should be wiped down with a damp cloth after every workout.

\*Periodically take the time to use a mild soap or an approved vinyl upholstery cleaner to deter the onset of cracking or drying. Avoid using any abrasive cleaners or cleaners not intended for use on vinyl.

\*Replace ripped or warn upholstery immediately.

\*Keep sharp or pointed objects clear of all upholstery.

#### Decals:

\*Inspect and familiarize yourself with any safety warnings or other user information posted on each decal.

#### Nuts and Bolts:

\*Inspect all nuts and bolts for any loosening and tighten if needed.

\*Go through a re-tightening sequence periodically to ensure that all hardware is tensioned proper.

#### **Anti-Skid Surfaces:**

\*These surfaces are designed to supply secure footing and need to be replaced if they appear worn or become slippery.

#### **Belts and Cables:**

\*Hoist uses only high quality belt, and mil-spec cables.

\*Visually inspect the belts and cables for fraying, cracking, peeling or discoloration.

\*While the machine is not in use, carefully run your fingers along the belt or cable to feel for thinning or bulging areas.

\*Replace belts and cables immediately at the first signs of damage or wear. Do not use equipment until belts or cables have been replaced.

#### **Belt and Cable Tension:**

\*Referring to the Owners Manual, when belts or cables are used check all bolts attachments to be sure they are properly attached.

\*Check slack in cables and re-adjust cable tension if needed.

#### Seat Sleeves, Guide Rods:

\*Wipe down adjusting tubes with a dust free rag before applying lubricant.

\*Lubricate seat sleeves and Guide Rods with a Silicon or Teflon based lubricant spray.

#### Linear Bearings:

\*Referring to the Owners Manual carefully disassemble the bearing from its housing and place a finger full of light grease (lithium, super lube, etc.) into the inside of the bearing. Using your finger, press the grease into the ball-bearings and their tracks. repeat until the ball-bearing tracks are full of grease. Insert the shaft back into the bearing and wipe off excess grease.

### PLEASE KEEP THIS FOR YOUR RECORDS

### **Mi7 CABLE ASSEMBLY**

### WEIGHT TRAINING TIPS

Use this manual to guide you through the basic exercises you can perform on your Mi7 CABLE HOIST® Fitness System. To gain maximum results and avoid possible injury, consult a fitness professional to develop your complete exercise program.

Always consult your physician before starting any exercise program.

To be successful in your exercise program, it is important to develop an understanding of the basic principles of strength training. Now that you have your Mi7 CABLE HOIST® Fitness System, it is only natural that you want to get started immediately. First, determine a set of realistic goals and objectives for yourself. By deciding on an exercise plan that is right for you prior to starting, you will contribute significantly to your success.


Warm up properly before engaging in weight resistance training. Stretching, yoga, jogging, calisthenics or other cardiovascular exercise can help prepare your body for the heavier workload of lifting weights.

Learn how to perform the exercise correctly before using heavy weight. Correct form is important to avoid injury and to ensure that you work the proper muscle groups.

Know your limitations. If you are new to weight training or are embarking on an exercise regimen after a long layoff, start slowly and build foundational strength over a longer period of time.

Pay attention to your breathing. Exhale when you exert is a general rule of thumb. Never hold your breath.

Enjoy your Mi7 CABLE HOIST® Fitness System!



Totale													Ű	Date
													S	
	 										 		RW	
											 _		S b	
													R	
												-		
													S	
											 		R	
												_	W	
												_	S	
													R	
												_	♥	
_											-+		S	
													RW	
											$\rightarrow$	_	S A	
											+		R	
											$\neg$			
					 								S	
													R	
													$\blacksquare$	
													S	
											 		R	
												_	W	
_	 		-										S	
	 										 		R \	
_	 												<b>W</b>	
											 -+		I S	
											 -+		RW	
											 	_	S A	
											-+		S R	
											-+		~	
											$\rightarrow$	_	S A	
											-+		R	
											-+			

### HOIST FITNESS SYSTEMS LIMITED LIFETIME WARRANTY

Hoist Fitness Systems warrants this product to the **original purchaser** to be free from defects in workmanship and/or materials under normal use or service. If at any time a component part is defective, Hoist Fitness Systems shall repair or replace it (at Hoist Fitness Systems option) within a reasonable period of time. This warranty does not cover costs of removal, transportation or reinstallation. This warranty shall not apply if the defect was caused by misuse, neglect or normal wear and tear.

# WARRANTY CLAIMS. All claims require: Model number, Serial number, Date of installation, and any information supporting the existence of the alleged defect.

#### To complete Warranty Registration visit: <u>www.HOISTFITNESS.com</u> and click on the Warranty Registration link

Starting from the original date of purchase, normal wear and tear shall be considered as the following:

**COMMERCIAL USE:** All malfunctions of upholstery, grips, and coatings that occur up to one year; all malfunctions of belts, or cables up to one year; all malfunctions of pulleys, bearings, or bushings that occur up to three years. The frame and body components are warranted for ten years, with structural moving parts warranted for five years.

LIGHT COMMERCIAL USE: All malfunctions of upholstery, grips, and coatings that occur up to one year; all malfunctions of belts, or cables up to one year; all malfunctions of pulleys, bearings, or bushings that occur up to three years. The frame and body components are warranted for ten years, with structural moving parts warranted for five years.

**HOME USE**: All malfunctions of grips, paint, and chrome that occur up to ten years; all malfunctions of electronic components, belts, cables, or upholstery that occur up to ten years; all malfunctions of pulleys, bearings, or bushings that occur up to ten years. The frame and all welded components are warranted for the life of the product.

PLEASE NOTE THAT NOT ALL HOIST PRODUCTS ARE MADE FOR COMMERCIAL USE. Refer to the instructions page of your owners manual or consult with you fitness product dealer to establish if a product is made for commercial use or not. Using a non-commercial product in a commercial setting can result in serious injury or death! Hoist Fitness Systems sole responsibility shall be to repair or replace the component within the terms stated above. Hoist Fitness Systems shall not be liable for any loss or damage of any kind including any incidental or consequential damages resulting, directly or indirectly from any warranty expressed or implied or any other failure of this product.

**LIGHT COMMERCIAL USE**: Our Light Commercial warranty applies to facilities that **DO NOT** charge monthly membership dues and where the equipment would be used by **no more than 50** people per day. Examples of Light Commercial facilities include hotels, apartment complexes, personal training studios, fire stations, police stations, etc., that meet the criteria stated above.


WHAT IS NOT COVERED BY THIS WARRANTY: Hoist's sole obligation under this warranty is limited to either repair or replacement of parts, subject to the additions below. This warranty neither assumes nor authorizes any person to assume obligations other than expressly covered by this warranty.

**NO CONSEQUENTIAL DAMAGES**: Hoist is not responsible for economic loss; profit loss; or special, indirect, or consequential damages.

**WARRANTY IS NOT TRANSFERABLE:** This warranty is not assignable and applies only in favor of the original purchaser/user to whom delivered. Any such assignment or transfer shall void the warranties herein made and shall void all warranties, expressed, implied or statutory, except the one (1) and five (5) year warranties described above. These warranties are exclusive and in lieu of all other warranties, including implied warranty and merchantability or fitness for a particular purpose. There are no warranties which extend beyond the description on the face hereof.

**TRANSPORTATION COSTS:** Hoist will accept parts covered under this warranty freight collect, provided that shipment has received prior approval. Hoist is not responsible for any other transportation costs, but will ship freight collect parts either repaired or replaced under these warranties.

Hoist Fitness Systems 11900 Community Rd. Poway, CA. 92064 (800)548-5438 PLEASE KEEP THIS FOR YOUR RECORDS



# **CONTENTS**

INSTRUCTIONS	02
FRAME ASSEMBLY	04
PRE-ASSEMBLY	30
DECAL PLACEMENT	33
DECAL REFERENCE	34
PART LIST	36
ABBREVIATIONS	38
BOLT SIZING CHART	39
WASHER SIZING CHART	40
MAINTENANCE SCHEDULE	42
GENERAL MAINTENANCE INFORMATION	43
WEIGHT TRAINING TIPS	44
WEIGHT RATIOS	45
EXERCISE LOG	46
LIMITED WARRANTY	47

## **INSTRUCTIONS**

Before beginning assembly please take the time to read instructions thoroughly. Please use the various lists in this manual to make sure that all parts have been included in your shipment. When ordering, use part number and description from the lists. Use only HOIST replacement parts when servicing. Failure to do so will void your warranty and could result in personal injury.

HOIST equipment is designed to provide the smoothest, most effective exercise motion possible. After assembly, you should check all functions to ensure correct operation. If you experience problems, first recheck the assembly instructions to locate any possible errors made during assembly. If you are unable to correct the problem, call your authorized HOIST dealer. Be sure to have your serial number and this manual when calling. When all parts have been accounted for, continue on.

### **TOOLS REQUIRED**

**Ratchet Wrench** 

1/2", 9/16" and 3/4" Sockets

**Adjustable Wrench** 

**Rubber Mallet** 

**Tape Measure** 


Level


**Phillips Screwdriver** 


**SAE Hex Key Wrench Set** 


Two People


\*\*\*THIS PAGE WAS INTENTIONALLY LEFT BLANK\*\*\*
































### **MISMITH ASSEMBLY**





**MiSMITH ASSEMBLY** 



















**MISMITH ASSEMBLY** 




































# **DECAL REFERENCE**

EVENTICAL STATEMENT     EVENTICAL STATEMENT	NOTICE         COMMERCIAL       Important         Inspect:       Important         Links, Pull Pins,       Important         Snap Locks,       Important         Swivels,       Important         Veight Stack       Important         Pins       Important         Clean;       Important         Upholstery       Important         Inspect;       Important         Cables or Belts       Important         Inspect;       Important         Accessory Bars       Important         Inspect;       Important         All Decals       Important         Surfaces       Important         Lubricate; Guide       Important         Seat Sleeves,       Important         Lubricate; Seat Sleeves,       Important         Lubricate; Suide       Important         Repack with       Important         Clean & Wax;       Important	<image/>
8, TO PREVENT POSSIBLE TIPPING bolt this unit to the exercise floor.Failure to do so may result in serious injury or death.	Replace; Cables, Belts and Connecting Parts.	021-0003113 021-0003967
021-0003135	021-0003008	O21-0003962
		021 0003502

**MISMITH ASSEMBLY** 



#### PART LIST


#### NOTE: SOME OF THESE PARTS MAY COME PRE-INSTALLED


ITEM NO.	PART NUMBER	DESCRIPTION	QTY
1	026-01X6001	UPRIGHT-1	2
2	026-01X6002	UPRIGHT-2	2
3	026-01X6003	SAFETY TIER	2
4	026-01X6004	BASE 1	2
5	026-01X6005	CROSSMEMBER-1	2
7	026-01X6007	CROSSMEMBER/BEARING CARRIER	1
8	026-01X6008	OLYMPIC WEIGHT MOUNT	2
9	026-01X6009	BEARING HOUSING	2
11	026-01X7119	SHIELD	2
12	014-0007005	25mm LINEAR BEARING	10
13	014-0015005	SNAP RING: Ø40mm INTERNAL	10
14	016-0203006	PINETREE PLUG	12
15	026-STD-06-0201	WEIGHT HORN SLEEVE	2
16	026-STD-08-0041	$\phi$ .75" BEARING	2
17	026-STD-08-0021	3/4" FLANGED BEARING	2
18	026-01X7169	BRACKET MOUNT-2	2
19	026-01F0602	FLNG. 50 X 100mm FLAT OVAL	4
20	026-01G0501	GUIDE SHAFT, 36.06" LG.	3
21	026-01G0502	GUIDE SHAFT, $\phi$ .98" X 73.40" LG.	2
22	021-0003230	DECAL HOIST 1.625" X 6.0613"	2
23	026-01PL0264	WEIGHT HORN RUBBER DONUT	2
24	026-01PL2135	END PLUG $Ø$ 1.66"	2
25	026-01PL2641	FOOTCAP, 1.9685" X 3.9370" F.O.	4
26	026-01PL2801	6" PU RACK-OUT COVER	36
27	026-01PL2802	PU RACK-OUT UPPER CAP	4
28	026-01PL2803	PU RACK-OUT LOWER CAP	4
29	026-01P7010	SPREADER PLATE	1
30	026-01P7012	PLACARD MOUNT	2
31	026-01T2348	OLYMPIC WEIGHT BAR	1
32	013-1002007	3/8" X 22mm FLAT WASHER (Ni)	54
33	013-1006003	3/8" SPLIT LOCK WASHER (Ni)	42
34	011-0116150	3/8"-16UNC X 3.00" LOW HEAD SHCS (Ni)	4
35	011-0702020	3/8"-16UNC X 1.00" FHCS (Ni) W/NYLON PATCH	44


## PART LIST CONTINUED

NOTE: SOME OF THESE PARTS MAY COME PRE-INSTALLED


ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
36	011-0701089	3/8"-16UNC X .75" BHCS (Ni) W/ DRI-LOC PATCH	4
37	011-0701111	3/8"-16UNC X 1.00" BHCS (Ni) W/ DRI-LOC PATCH	26
38	012-0504005	3/8"-16 UNC THIN NYLOCK NUT (Ni)	4
39	021-0003008	DECAL COMMERCIAL MAINTENANCE 1.50 X 6.69	1
40	021-0003113	DECAL PINCH POINT 1.63" X 3.25" (VERTICAL)	4
41	021-0003135	DECAL WARNING 1.50" X 6.69"	1
42	021-0003221	DECAL HOIST 2.50" X 9.13"	2
43	021-0003228	DECAL 600 LB. WEIGHT RATING 1.6250" X 1.6250"	1
44	021-0003282	DECAL SPOTTER 1.63" X 3.25" (VERTICAL)	4
45	021-0003329	SAFETY TIER DECAL 1.63" X 3.25" HORIZONTAL	4
46	021-0003627	DECAL HOIST 2.07" X 7.75"	2
47	021-0003954	DECAL WEAR STRIP (BLACK) 1.50" X 31.75" X 30 MIL	2
48	021-0003962	MiSmith Emblem	2
49	SERIAL # DECAL	DECAL HOIST SERIAL # 1.63" X 2.63"	1
50	002-0001013	1cc of Synthetic Multi-Purpose Grease (PTFE)	4
51	002-0001036	TOUCH-UP PAINT - BOTTLE: 1oz COLOR: PLATINUM	1
52	011-0407022	3/8"-16UNC X 1.00" HHB (WZ)	12
53	026-01X7168	BRACKET MOUNT-1	2
54	026-01PL2685	INDEX NUMBER MOUNT	36
55	021-0003967	INDEX NUMBERS 1-9	4
56	011-0701084	3/8"-16UNC X 1.25" BHCS (Ni) W/ DRI-LOC PATCH	4







**MISMITH ASSEMBLY** 



#### **MISMITH ASSEMBLY**

#### **MAINTENANCE SCHEDULE**

ROUTINE	COMMERCIAL / LIGHT COMMERCIAL MAINTENANCE	HOME MAINTENANCE	LATEST DATE ENTRY								
Inspect; Links, Pull Pins, Snap Locks, Swivels, Weight Stack Pins	DAILY	WEEKLY									
Clean; Upholstery	DAILY	WEEKLY									
Inspect; Cables or Belts and their tension	DAILY	WEEKLY									
Inspect; Accessory Bars, and Handles	WEEKLY	3 MONTHS									
Inspect; All Decals	WEEKLY	3 MONTHS									
Inspect; All Nuts and Bolts, Tighten if needed	WEEKLY	3 MONTHS									
Inspect; Anti-Skid Surface	WEEKLY	3 MONTHS									
Clean & Lubricate; Guide Rods with a Teflon (PTFE) based lubricant (Superlube)	MONTHLY	3 MONTHS									
Lubricate; Seat Sleeves, Turcite Bushings, Linear Bearing	MONTHLY	3 MONTHS									
Clean and Wax; All Glossy Finishes	6 MONTHS	YEARLY									
Repack with Grease; Linear Bearings	6 MONTHS	YEARLY									
Replace; Cables, Belts and Connecting Parts	YEARLY	3 YEARS									

Your equipment comes with a commercial maintenance decal. For personal, in home use, please follow the home maintenance schedule listed above.

Never use ammonia, acid-based, or petroleum-based solvents on any portion of the machine as it may damage the finish.

#### HOIST FITNESS SYSTEMS GENERAL MAINTENANCE INFORMATION

#### Links, Pull-Pins, Snap Hooks, Swivels, Weight Stack Pins:

\*Check all pieces for signs of visible wear or damage.

\*Check springs in snap hooks and pull-pins for proper tension and alignment.

\*If the spring sticks or has lost its rigidity, replace it immediately.

#### **Upholstery:**

\*To ensure prolonged upholstery life and proper hygiene, all upholstered pads should be wiped down with a damp cloth after every workout.

\*Periodically take the time to use a mild soap or an approved vinyl upholstery cleaner to deter the onset of cracking or drying. Avoid using any abrasive cleaners or cleaners not intended for use on vinyl.

\*Replace ripped or warn upholstery immediately.

\*Keep sharp or pointed objects clear of all upholstery.

#### Decals:

\*Inspect and familiarize yourself with any safety warnings or other user information posted on each decal.

#### Nuts and Bolts:

\*Inspect all nuts and bolts for any loosening and tighten if needed.

\*Go through a re-tightening sequence periodically to ensure that all hardware is tensioned proper.

#### Anti-Skid Surfaces:

\*These surfaces are designed to supply secure footing and need to be replaced if they appear worn or become slippery.

#### **Belts and Cables:**

\*Hoist uses only high quality belt, and mil-spec cables.

\*Visually inspect the belts and cables for fraying, cracking, peeling or discoloration.

\*While the machine is not in use, carefully run your fingers along the belt or cable to feel for thinning or bulging areas.

\*Replace belts and cables immediately at the first signs of damage or wear. Do not use equipment until belts or cables have been replaced.

#### **Belt and Cable Tension:**

\*Referring to the Owners Manual, when belts or cables are used check all bolts attachments to be sure they are properly attached.

\*Check slack in cables and re-adjust cable tension if needed.

#### Seat Sleeves, Guide Rods:

\*Wipe down adjusting tubes with a dust free rag before applying lubricant.

\*Lubricate seat sleeves and Guide Rods with a Silicon or Teflon based lubricant spray.

#### Linear Bearings:

\*Referring to the Owners Manual carefully disassemble the bearing from its housing and place a finger full of light grease (lithium, super lube, etc.) into the inside of the bearing. Using your finger, press the grease into the ball-bearings and their tracks. repeat until the ball-bearing tracks are full of grease. Insert the shaft back into the bearing and wipe off excess grease.

#### PLEASE KEEP THIS FOR YOUR RECORDS

#### **MISMITH ASSEMBLY**

#### WEIGHT TRAINING TIPS

Use this manual to guide you through the basic exercises you can perform on your MiSMITH HOIST® Fitness System. To gain maximum results and avoid possible injury, consult a fitness professional to develop your complete exercise program.

Always consult your physician before starting any exercise program.

To be successful in your exercise program, it is important to develop an understanding of the basic principles of strength training. Now that you have your MiSMITH HOIST® Fitness System, it is only natural that you want to get started immediately. First, determine a set of realistic goals and objectives for yourself. By deciding on an exercise plan that is right for you prior to starting, you will contribute significantly to your success.


Warm up properly before engaging in weight resistance training. Stretching, yoga, jogging, calisthenics or other cardiovascular exercise can help prepare your body for the heavier workload of lifting weights.

Learn how to perform the exercise correctly before using heavy weight. Correct form is important to avoid injury and to ensure that you work the proper muscle groups.

Know your limitations. If you are new to weight training or are embarking on an exercise regimen after a long layoff, start slowly and build foundational strength over a longer period of time.

Pay attention to your breathing. Exhale when you exert is a general rule of thumb. Never hold your breath.

Enjoy your MiSMITH HOIST® Fitness System!



Totals														Exercise	Date		
														S			
												 		R			
	 _											 		8			
	 											 		S S			
														R ₩			
													_	S S	_		
														⊐			
			 													ت ا	$S = S_{oto} R = Remetition ner set W = Weight used$
														Ś		נ	2
													;	₽		5	÷.
													:				5 1
														S		Į	ד
													;	찐		che	5
													1	8			Į.
												 		S		I IIC	ś
												 		≂		Jer	5
												 		◙			) +
	 		 									 		S		1	
		_										 		R ₩			.  
												 	_	S S			
			 									 					۰ ۲
														R ₩		Uac	2
														s N	_	Ë	5.
	+													₽			
	$\top$													•			
														S			
													;	₽			
														$\blacksquare$			
														S			
														찐			
														•			
	 _											 		S			
_	 +			-				-						R			
													1		ノ		

#### HOIST FITNESS SYSTEMS LIMITED LIFETIME WARRANTY

Hoist Fitness Systems warrants this product to the **original purchaser** to be free from defects in workmanship and/or materials under normal use or service. If at any time a component part is defective, Hoist Fitness Systems shall repair or replace it (at Hoist Fitness Systems option) within a reasonable period of time. This warranty does not cover costs of removal, transportation or reinstallation. This warranty shall not apply if the defect was caused by misuse, neglect or normal wear and tear.

# WARRANTY CLAIMS. All claims require: Model number, Serial number, Date of installation, and any information supporting the existence of the alleged defect.

#### To complete Warranty Registration visit: <u>www.HOISTFITNESS.com</u> and click on the Warranty Registration link

Starting from the original date of purchase, normal wear and tear shall be considered as the following:

**COMMERCIAL USE:** All malfunctions of upholstery, grips, and coatings that occur up to one year; all malfunctions of belts, or cables up to one year; all malfunctions of pulleys, bearings, or bushings that occur up to three years. The frame and body components are warranted for ten years, with structural moving parts warranted for five years.

**LIGHT COMMERCIAL USE**: All malfunctions of upholstery, grips, and coatings that occur up to one year; all malfunctions of belts, or cables up to one year; all malfunctions of pulleys, bearings, or bushings that occur up to three years. The frame and body components are warranted for ten years, with structural moving parts warranted for five years.

**HOME USE**: All malfunctions of grips, paint, and chrome that occur up to ten years; all malfunctions of electronic components, belts, cables, or upholstery that occur up to ten years; all malfunctions of pulleys, bearings, or bushings that occur up to ten years. The frame and all welded components are warranted for the life of the product.

PLEASE NOTE THAT NOT ALL HOIST PRODUCTS ARE MADE FOR COMMERCIAL USE. Refer to the instructions page of your owners manual or consult with you fitness product dealer to establish if a product is made for commercial use or not. Using a non-commercial product in a commercial setting can result in serious injury or death! Hoist Fitness Systems sole responsibility shall be to repair or replace the component within the terms stated above. Hoist Fitness Systems shall not be liable for any loss or damage of any kind including any incidental or consequential damages resulting, directly or indirectly from any warranty expressed or implied or any other failure of this product.

**LIGHT COMMERCIAL USE**: Our Light Commercial warranty applies to facilities that **DO NOT** charge monthly membership dues and where the equipment would be used by **no more than 50** people per day. Examples of Light Commercial facilities include hotels, apartment complexes, personal training studios, fire stations, police stations, etc., that meet the criteria stated above.

**WHAT IS NOT COVERED BY THIS WARRANTY:** Hoist's sole obligation under this warranty is limited to either repair or replacement of parts, subject to the additions below. This warranty neither assumes nor authorizes any person to assume obligations other than expressly covered by this warranty.

**NO CONSEQUENTIAL DAMAGES**: Hoist is not responsible for economic loss; profit loss; or special, indirect, or consequential damages.

**WARRANTY IS NOT TRANSFERABLE:** This warranty is not assignable and applies only in favor of the original purchaser/user to whom delivered. Any such assignment or transfer shall void the warranties herein made and shall void all warranties, expressed, implied or statutory, except the one (1) and five (5) year warranties described above. These warranties are exclusive and in lieu of all other warranties, including implied warranty and merchantability or fitness for a particular purpose. There are no warranties which extend beyond the description on the face hereof.

**TRANSPORTATION COSTS:** Hoist will accept parts covered under this warranty freight collect, provided that shipment has received prior approval. Hoist is not responsible for any other transportation costs, but will ship freight collect parts either repaired or replaced under these warranties.

Hoist Fitness Systems 11900 Community Rd. Poway, CA. 92064 (800)548-5438 PLEASE KEEP THIS FOR YOUR RECORDS

#### **MISMITH ASSEMBLY**