OMNIPURE EFS2 INSTALLATION INSTRUCTIONS



- 1. Connect water inlet line to the 3/8" FPT water inlet valve.
- 2. Connect the supplied 3/8" tubing to the Bleeder Valve by pushing the tubing into the valve until it stops.
- 3. Connect the water line from the espresso machine to the 3/8" FPT water outlet valve.
- 4. Turn bleeder valve downward and turn water supply on, let 3-5 gallons of water pass through the system to purge the cartridges.
- 5. Shut water supply off and turn the Bleeder Valve off which allows the water to pass through to the espresso machine.
- 6. Turn water valve back on and purge your espresso machine of air.