

Fitshot.

Connect



USER MANUAL

Bluetooth Calling Smartwatch

Welcome

Thank you for purchasing the **Fitshot Connect** smartwatch. We recommend you to read the instructions manual carefully before using the product.

Package Contents

- 1N Fitshot Connect
- 1N USB Magnetic Charging Cable
- 1N Welcome cum Warranty Scan Card
- 1N Review cum User Manual Scan Card

Product Overview



Turning the Watch ON

To turn the watch on, press the button located on the right side of the watch for around 4 to 5 seconds.

NOTE: The smartwatch must be charged before initial use. You can wake the screen by lifting your wrist.

Charging the Watch

1. Turn the watch over, align and attach the charging pins to the magnet prongs.
2. You will see the charging icon on the watch screen after 5 seconds.
3. Complete charging may take up to 2 hours. The battery icon would change to full once the charging is complete.
4. Please clean the charging points before charging to avoid erosion of the prongs and other risks.

NOTE: Please charge this smartwatch with a 5V/1A adapter.

Download and Install the App by the name of "GloryFit"

You can set up the Smartwatch through the "GloryFit" app for iOS or Android devices. Scan the QR code from your watch to get GloryFit in your app store.



SCAN THE QR CODE
FOR APP

DO NOT PAIR THE WATCH DIRECTLY WITH BLUETOOTH IN YOUR PHONE'S SETTINGS.

Pairing Instructions

Turn ON Bluetooth on your smartphone.

1. After installing the GloryFit app on your smartphone, register and log into your account as per the instructions on the screen.
2. Ensure that the smartwatch and smartphone are kept near each other.
3. Continue following the onscreen instructions to connect or pair your smartwatch to your smartphone.

Note: The device should have at least android 4.4+ or iOS 9.0+ and above. The watch can only be paired with one smartphone at a time. To pair any other smartphone, please unbind the currently connected smartphone before pairing.


For Android

After the app and the watch are successfully bound, it will automatically prompt due to its SoloSync™ Technology whether to pair with the audio Bluetooth Connect (ID-XXXX), and you can directly pair it.

For iOS

After the app is successfully bound with the watch while using the smartphone function, it will prompt to connect with Bluetooth Connect (ID-XXXX), you need to allow all the permissions on your smartphone when prompted. Once you are done allowing the permissions, the pairing will be successful and complete.

Turning the Watch OFF

1. Long press the side button for around 3 seconds.
2. Click on  to turn it OFF.
3. Your smartwatch will successfully turn OFF.

Tips:

1. Please upgrade the app to the latest version to get a better experience.
2. For the first-time connection with an iPhone, a "Pair" reminder will pop up. Click to pair, and then incoming calls and instant messages will be pushed.
3. For the first-time connection with Android, a "Permissions" reminder will pop up, please follow up on the guidance and allow permissions to ensure all functions working properly.
4. To connect successfully, please turn ON the smartphone's Bluetooth, GPS and network.
5. If the device cannot be searched or connected during use, please reset or turn OFF the watch to try again.

Synchronize Data

In daily wear, the watch can detect and record all kinds of data. The user needs to connect the smartwatch with Bluetooth on the app and enable it to synchronize.

Note: To prevent data loss, please synchronize the watch at least once every 7 days.

Watch Faces

Your Fitshot Connect comes with 100+ watch faces for you to choose from. Once you pick your favorite watch face, your home screen will display the date, time, week, weather, steps you take, battery status and connection status. Long press the screen, swipe to choose and click to confirm.


Custom Watch Faces: Open the app -> Go to Device > Click on Watch Faces. Now, choose your desired watch face and click on the "Synchronous dial" button to apply.

Steps, Distance & Calorie Monitor

You can view daily records of steps, distance and calories on the app as well as on your smartwatch. The data will be cleared at the end of every day.

NOTE: All records will be available on the app if you keep it synchronized.

Bluetooth Calling (Phone)



Quick dial any number, and view recent call logs and contacts by clicking on the Phone icon.

Training



Go to Training to choose from different Exercise Modes. There are 100+ Exercise Modes in the Connectwatch.

During Sports

To Pause: Short press the side button

To End: Short press the side button

Status



Record steps, distance and calories for the day. More detailed information analysis and data records can be viewed in the app.

Sleep



It intelligently monitors your sleep and displays the total sleep duration, deep sleep and light sleep duration of the previous night. After wearing the watch properly, tap on the Sleep icon on the watch to record the sleep status throughout the night.

NOTE: You need to wear the watch for the measurements. The detailed data recording and analysis can be viewed in the GloryFit app.


Heart Rate



Tap on the icon to measure your heart rate. Wear the watch on your wrist correctly and stay still. It measures the current heart rate value; the watch can record and display the 24x7 heart rate value throughout the day, monitor the heart rate in real-time throughout the day, and the app saves the average heart rate value every ten minutes. More detailed information analysis and data records can be viewed in the app.

NOTE: Measurements are for reference only and not for medical purposes.

Pressure



Click on the Pressure icon to check your 24x7 stress levels throughout the day. For more detailed information and records, please check the app.

NOTE : Measurements are for reference purposes only.

SpO2



Wear the watch on your wrist, then click on the icon to start measuring your blood oxygen. It saves your data every ten minutes. You can also view the detailed analysis in the app.

NOTE : Measurements are for reference only and not for medical purposes as this is not a medical-grade equipment.

Blood Pressure Monitor



Keep a track of your Blood Pressure. You can view the detailed analysis in the app.

NOTE: Measurements are for reference only and not for medical purposes as this is not a medical-grade equipment.

Breath Rate



Measure your current respiratory rate. However, measurements are for reference only and not for medical purposes as this is not a medical-grade equipment.

Breath Training Mode (Breath)



Tap on the icon, now tap to start breath mode. Just set breath rhythm and time, and follow the instructions for a quick relaxing break.

Mood




Know yourself better with mood monitoring. In the app, it displays your full-day 24x7 mood status. More detailed information and records, please check it in the app.

Weather



Displays the weather conditions and the weather for the next 4 days. The weather information needs to be connected to the APP before the data can be obtained. If the connection is disconnected for a long time, the weather information will not be updated.

Music



After connecting the watch, it can remotely control the music, play/pause/previous/next song on the phone, and can also adjust the volume.

NOTE: Ensure the music app is running on your phone for this feature to work properly. This feature might not work for some of the Music Apps with different control protocols.

AI Voice Assistance




Click the AI voice function button, speak out and wake up the AI voice assistant. Please ensure that the Bluetooth function is successfully connected.

Game



There are 2 fun inbuilt games in the watch that can get those boring moments away.

Alarm



A total of 8 alarm clocks can be set. The watch will vibrate, ring and display will turn ON.

Shortcut Menu



Slide down from the main page, go to shortcut, and slide up to return.

Quick Access to Change Watch Faces



Long press the watch face on the main page and slide left or right to choose watch faces.

Cleaning and Maintenance

1. Keep the product clean.
2. Keep the product dry.
3. Do not wear it too tight.
4. Do not use household cleaners to clean the watch.

Safety and Product Information Notes

Battery Warning:

Do not disassemble, pierce or damage the battery. Do not disassemble the built-in batteries of non-replaceable battery devices. Do not use sharp objects to remove the battery.

Health Warning:

The watch's optical heart rate sensor glows green and ashes. If you suffer from epilepsy or are sensitive to blinking light sources, please consult your physician to affirm if you can wear this product.

The device tracks your daily activities through sensors. These data are intended to tell you about your daily activities, such as steps, sleep, distance, heart rate and calories, but may not be completely accurate.

The device, accessories, heart rate sensors and other relevant data are designed for entertainment and fitness, not for medical purposes. They are not applicable to the diagnosis, monitoring, treatment or prevention of any diseases or symptoms. The heart rate data is for reference only. We are not responsible for any consequences caused by any data deviation.

Matters Needing Attention

- Watch data needs to be kept once every 7 days to avoid data loss.
- The watch has no waterproof effect on seawater, acidic and alkaline solutions, chemical reagents and other corrosive liquids.
- The damage or defects caused by misuse or improper use are not covered by the warranty.
- Avoid wearing the watch too tight in daily use. Please keep the parts of the watch touching the skin dry.
- When your heart rate is measured, keep your arm still during the test.

Caution

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.



Old electrical appliances must not be disposed of together with the residual waste, but have to be disposed of separately. The disposal at the communal collecting point via private persons is free. The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort, you contribute to recycling valuable raw materials and the treatment of toxic substances.

Warranty Terms & Conditions

NOTE: For valid warranty claim, all information on the warranty certificate has to be completed and presented along with the original invoice.

- All warranty information, product features and specifications are subject to change without prior notice.
- All matters are subject to Delhi Jurisdiction.
- Fitshot Connect smartwatch comes under a warranty of 365 days against any manufacturing-related issues.
- The accessories (magnetic pin cable) which come along with the smartwatch come under a warranty of 90 days.
- The wear-and-tear accessories such as the straps are not covered under warranty.
- Warranty can not be claimed if the product is damaged by wrong operation or force majeure.

CUSTOMER CARE:

224, Second Floor, D-Mall, Netaji
Subhash Place, Delhi; India - 110034

Contact No.: +91 7290909017,

E-mail: 911@fitshot.tech

Web: www.fitshot.tech

Take your shot.

www.fitshot.tech

