

BIOMETHANE 3000

TECHNICAL SPECIFICATIONS

GENERAL SPECIFICATION				
Number of sampling points	1			
Gases to be monitored	CH ₄ , CO ₂ and O ₂ with optional H ₂ S, H ₂ and CO (choice of up to 4)			
Reading intervals	Continuous ¹ CH ₄ , CO ₂ and O ₂ measurement with user definable fourth gas reading			
Operating temperature range	-20°C to +50°C			
POWER				
Mains options	110-230 Vac 50/60 Hz			
Consumption	155W maximum			
Backup memory	Lithium manganese dioxide backup battery for memory retention			
GAS RANGES				
Gases measured	CH ₄ and CO ₂	By dual wavelength infrared cell with reference channel		
	O ₂	By internal electrochemical cell		
	H ₂ S / H ₂ / CO	By external electrochemical cell		
	Cell	Range	Typical accuracy (range : accuracy)*	
Standard gas cells	CH ₄	0-100%	0-100% : ±0.5% (vol)	
	CO ₂	0-100%	0-60% : ±0.5% (vol)	60-100% : ±1.5% (vol)
	O ₂	0-25%	0-1% : ±0.05% (vol)	1-2% : ±0.10% (vol) 2-25% : ±1.0% (vol)
	Cell	Range	Typical accuracy (range : accuracy)*	
			Module cell	System cell
Optional gas cells	H ₂ S	0-50ppm	±1.5% FS	±1.5% FS
	H ₂ S	0-200ppm	±2.0% FS	±1.5% FS
	H ₂ S	0-500ppm	±2.0% FS	±2.0% FS
	H ₂ S	0-1,000ppm	±2.0% FS	±2.0%
	H ₂ S	0-5,000ppm	±2.0% FS	±100ppm or 5% of reading (if greater)
	H ₂ S	0-10,000ppm	±5.0% FS	±200ppm or 5% of reading (if greater)
	CO	0-1,000ppm	±2.0% FS	±3.0% FS
	H ₂	0-1,000ppm	±2.5% FS	±1.5%
	Range	Response time	Range	Response time
Response time, T90**	CH ₄	≤10 seconds	H ₂ S (0-50ppm)	≤30 seconds
	CO ₂	≤10 seconds	H ₂ S (0-200ppm)	≤35 seconds
	O ₂	≤10 seconds	H ₂ S (0-500ppm)	≤35 seconds
	H ₂	<90 seconds	H ₂ S (0-1,000ppm)	≤35 seconds
	CO	<30 seconds	H ₂ S (0-5,000ppm)	≤40 seconds
				H ₂ S (0-10,000ppm)
Cell lifetime	O ₂ cell is 3 years in air, all other cells 2 years in air			

*Plus accuracy of calibration gas used

**Times are taken from the point gas enters the BIOMETHANE 3000 module. Sample times will vary depending on length of sample pipe

¹ The process will be paused during an auto calibration

© Product designs and specifications are subject to change without notice. User is responsible for determining suitability of product.



Distributed By:

DIAMOND
SCIENTIFIC

625 Peachtree Street
Cocoa, FL 32922
Phone: 1-321-223-7500
info@diamondsci.com
www.DiamondSci.com



BIOMETHANE 3000

TECHNICAL SPECIFICATIONS CONTINUED

PUMP	
Flow	300ml / minute typically. Please note that the default operation of the pump is always off and uses the positive pressure of the gas at the sample point
Flow-fail point	Flow rate less than 75ml / minute or vacuum greater than 350 mbar
Maximum vacuum restart	-375 mbar
COMMUNICATIONS	
Output channels	Up to six analogue 4-20mA output channels that are user configurable for current sink or source inputs plus Modbus RTU over RS-485 Optional Profibus, Profinet or Ethernet module
Alarm notifications	1 x fault relay 7 x user-configurable alarms that can trigger a relay when above or below a set value and one to inform the operator of the results of the autocalibration. In addition, one can be used to indicate to the operator when the catchpot is full and requires emptying
Relay outputs	Single pole changeover 6A 24Vdc relay volt free
ENVIRONMENT CONDITIONS	
Operating pressures	-350 mbar to +350 mbar*
IP rating	IP65
Humidity	0-95% non-condensing humidity
PHYSICAL	
Size	650 x 600 x 210mm (with supplied wall mounting brackets) per enclosure (2 enclosures)
Weight	Maximum 36.5kg per enclosure
Enclosure	Stainless steel, 600 x 600 x 210mm, IP65 rated
Operation keys	Alpha-numeric keypad with 'tactile' membrane
Display	480 x 272 pixel RGB TFT display, 96mm x 55mm
Moisture removal filters	User replaceable microfibre filter and 2.0µm PTFE water traps
Heater	100W mains powered ATEX certified heater for 110V or 230V mains supply
CERTIFICATION RATING	
ISO17025	Calibrated under UKAS accreditation (certificate number 4533)
ATEX / IECEx marking	⊕ II 3G Ex nA nC IIA T1 Gc (-20°C ≤ Ta ≤ +50°C) (main system only)
BS EN 61010-1:2010	Safety requirements for electrical equipment for measurement, control, and laboratory use
BS EN 50270:2006	Electromagnetic compatibility- electrical apparatus for the detection and measurement of combustible gases, toxic gases or oxygen

*Pressures will need regulating in order not to damage the system. This is the responsibility of the user.



© Product designs and specifications are subject to change without notice. User is responsible for determining suitability of product.

	Distributed By:	
	DIAMOND SCIENTIFIC	