

Baby Sippy Bottle Transferring Instructions

Read instructions completely before you begin.

Supplies Needed

- Coated Sippy Bottle
- Sippy Bottle Ultra Wrap™
- Heat Tape
- Heat Gloves or Oven Mitts



UltraWraps have been tested and proven to work successfully for hundreds of consecutive uses per wrap. However, deliberately stretching the wrap beyond its specifications can result in loss of tension or tearing. Likewise, over-heating the wrap or placing it too close to the oven heating coils can weaken the wrap, causing it to burn or tear.

To ensure the full life of each UltraWrap:

- *Never* over-stretch the wrap beyond the simple distance needed to connect the support bar.
- *Never* use a wrap for a product *other than* the one it is intended. Different wraps are required for mugs, steins, shot glasses, pet bowls, etc.
- Do not bake the UltraWrap at a temperature hotter, or a time longer, than recommended. See Step 1 for time and temperature recommendations.
- Never place the UltraWrap closer than 3" from the oven heating coils.

Note: Failure to follow these instructions will cause product .

Step 1: Adjust the Oven

UltraWraps are designed for use in regular or convection ovens or industrial conveyor ovens, *only*. Do not use in a microwave oven under any circumstances. For best results, always preheat your oven and place on the center rack. **When transferring to the sippy bottle, remember to remove the lid.**

Oven Temperature: **400° F (Do not exceed recommended time and temp)**
Dwell Time: **5 – 6 minutes**

Note: *These instructions, including transfer times and temperatures, are based on the inks, paper, ovens and products we use. Your inks, papers, etc. may require adjustments in your time/temp settings .Please adjust as needed.*

Step 2: Design and Print Your Transfers

1. Remember to design a mirror image so the final product will be correctly oriented once it is transferred.
2. Print your transfer(s).

Step 3: Transfer the Image

1. **Important - remove the top plastic components from baby bottle *before* putting it in the oven.**
2. Tape transfer to baby sippy bottle.
3. Wrap the UltraWrap around the bottle, clipping the wrap together on the opposite side of the transfer.
4. Place wrapped bottle in pre-heated oven. Bake at **40^{oo} F** for **5-6 minutes**. **Do not exceed recommended temperatures.**
5. Remove from oven, remove wrap and transfer. Allow to air cool. Do not immerse in water to cool.

Customer Support

For support on these or any of our products, please call our toll-free number for assistance: **877.795.1500**. You may also write to us at Support@LaserReproductions.com.