

STEP	Be careful to assemble all components in the sequence they are presented. NOTE: Finger tighten all hardware in this step. <u>Do Not</u> wrench tighten until end of step 2.		
	A. Attach rear leg (C) to mainframe (A) as shown using: two 18 (Hex Bolt M12 X 105mm) four 23 (Flat Washer 12mm) two 27 (Nylon Lock Nut M12)		
	 B. Attach two End Cap (16) to Back Pad Support structure (B) handle as shown using: two 16 (End Cap Ø25) two 29 (spring washer 6mm) C. Attach two End Cap (16) to Seat Support Structure (D) handle as shown using: two 16 (End Cap Ø25) two 29 (spring washer 6mm) 		
	 D. Attach two End Cap (17) to mainframe (A) front handle as shown using: one 17 (End Cap Ø30) one 26 (spring washer 8mm) 		
mn			
1			



Be careful to assemble all components in the sequence they are presented.

NOTE:

STFP

Finger tighten all hardware in this step. <u>Do Not</u> wrench tighten until end of step 2.

A. Attach Back Pad (8) with Pad Wrap (9) to Back Pad Structure (E) as shown using: four 20 (hex bolt M8 x 55 mm) four 26 (spring washer 8mm) four 25 (flat washer 8mm)

B. Attach Seat Pad (7) to Seat Pad Structure (F) as shown using:

two 21 (hex bolt M8 x 21 mm)

two 26 (spring washer 8mm)

two 25 (flat washer 8mm)







Mainframe Parts List

Part#	Qty	Description
1	2	shaft
2	4	Long Bushing
3	10	Short Bushing
4	2	Bushing Φ 30
5	1	Seat Pad Struture Shaft
6	1	Main Pivot Shaft
7	1	Seat Pad
8	1	Back Pad
9	1	Pad Wrap
10	1	Back Frame Support Tubing
11	2	Back Pad Structure End Cap
12	2	Transfer Wheel
13	1	Front Handle Foam Grip
14	4	Side Handle Foam Grip
15	4	Plug
16	4	End Сар Ф25
17	1	End Cap Φ30
18	2	Hex Bolt M12 X 105mm
19	2	Hex Bolt M8 X 60mm
20	4	Hex Bolt M8 X 55mm
21	2	Hex Bolt M8 X 25mm
22	8	Round Allen Head Bolt M8 X 15mm
23	4	Flat Washer 12mm
24	8	Big Flat Washer 8mm
25	10	Flat Washer 8mm
26	14	Spring Washer 8mm
27	2	Nylon Lock Nut M12
28	2	Nylon Lock Nut M8
29	4	Spring Washer 6mm
30	2	Spring Washer 10mm
31	1	Round Allen Head Bolt M10 X 20mm
32	1	Back Pad Rubber Stopper
Α	1	Bottom Frame
В	1	Rear Frame
C	1	Rear Leg
D	1	Seat Pad Support Frame
E	1	Back Pad Frame
F	1	Seat Pad Board

SFID325 Exploded View



ΝΟΤΕ

Body-Solid[®] Built for Life

1900 S. Des Plaines Ave. Forest Park, II 60130 1 (800) 556-3113 Hours: M-F 8:30 - 5:00

www.bodysolid.com

© Copyright 2010. Body-Solid. All rights reserved. Body-Solid reserves the right to change design and specifications when we feel it will improve the product. Body-Solid machines maintain several patented and patent pending features and designs. All rights reserved on all design patents and utility patents.