# **QUICK START GUIDE**







# **DURAIVACU**

Vacuum storage device for still wines.

#### Package contents:

- 1 Duravacu system including external 24Vdc Power supply
- 1 x Pack of 10 Still Wine Corks

#### You will need:

Power supply 110/230 Vac

### **WARNINGS**

**ATTENTION!** The device cannot be used by children under the age of 8 and by people with reduced physical, sensory, or mental abilities unless under direct supervision.

**ATTENTION!** It cannot be used for people without the necessary knowledge and experience if we have not received instructions on safe use and understanding the dangers inherent to them.

**ATTENTION!** Children must NEVER play with the appliance.

**ATTENTION!** Cleaning and maintenance of the appliance must NEVER be carried out by unsupervised children.

**ATTENTION!** It must ONLY be used with the power supply unit supplied with the appliance.

**ATTENTION!** If the power cable of the external power supply is damaged, replace it with a special cable or assembly provided by the manufacturer or the technical assistance service.

**ATTENTION!** Disconnect the machine at the end of the service and during the work procedures.

ATTENTION! If no maintenance is required, NEVER open the machine or remove its parts.

**ATTENTION!** NEVER use Duravacu on full bottles.

**ATTENTION!** NEVER store bottles closed on one side.

**ATTENTION!** NEVER try to reseal damaged bottles.

# **Technical assistance and support**

<u>support@winefit.it</u>

+39 0332 961167

#### **POWER CONNECTION**

- 1. Plug one end of the power cord into the socket on the back of the device.
- 1.

- 2. Insert the plug into the socket.
- 3. Turn on the power supply if it is off
- 4. Turn on the device switch.



# Your DURAVACU is ready for use





## **ILLUMINATED NOZZLES:**

The Duravin + system is equipped with illuminated nozzles.

By pressing the "+" and "-" buttons you can change the intensity of the chosen color.

By pressing the colored capacitive button it is possible to interchange 7 different colors.

Regardless of the selected color, during the reclosing and pressurization process, the nozzle turns red and then green once the operation is complete.

Once the bottle is removed, the nozzles will return to the set color.

#### **TECHNICAL INFORMATION:**

Model: DURAVACU Degree of protection: Class III


Freq./Volt.: 100-240VAC D- 24VAC, 50/60Hz Vacuum pressure: -0.6 bar

Current: 1.4A D 2.5A

Power: 90W Acoustic pressure: 75 db(A)

#### **ATTENTION!**

Use Duravin + only with the Mean Well power supply unit - GST90A24-P1M.



## Transport and installation of Duravin +

The machine is shipped in its cardboard box with adequate protection inside.

It is advisable to examine the condition of the machine upon arrival to verify that it has not been damaged during transport.

During the operations of loading, lifting, handling and unloading of the machine, use the appropriate PPE supplied to each operator.

The machine is supplied assembled in all its parts and able to start the activity.

Do not place the machine near liquid and heat sources that could cause damage and pose a risk to the user.

It is necessary to leave a space of about 15-20 cm on the side of the appliance to facilitate air circulation.

## Disposal of the appliance

This appliance is marked in accordance with the European directive 2012/19 / EU and the regulations on waste electrical and electronic equipment (WEEE).



This symbol indicates that this product must not be disposed of with other household waste in the EU territory to prevent damage to the environment or human health due to improper disposal.

# **Explanation of symbols**



Class III



Separable power supply unit



Compliance of the appliance with EU directives

# VIDEO MANUALS AND FURTHER INSTRUCTIONS FOR THE DURAVIN + RANGE AVAILABLE ON OUR CLOUD

#### Final Use Instructions:

- The top of the bottles must always be clean and free of wine residues.
- The caps must be cleaned regularly. Use a mild cleanser and rinse them thoroughly. You could soak them overnight.
- Monitor the performance of all caps. If a cap cannot hold the vacuum, set it aside immediately and replace it with a new one.
- Make sure glasses are thoroughly cleaned and dried before use.

The company relieves itself of any responsibility for a use other than that suggested for both the machine and the accessories.



