



ArteSeal Paraloid™ B-72 Guidance

Thank you for purchasing your Paraloid™ B-72 mixture from ArteSeal.

CAUTION

Paraloid™ B-72 mixture contains Acetone so it is important that the you are aware of the safety considerations below.

- Repeated exposure may cause skin dryness or cracking.
- Highly flammable liquid and vapour.
- It can cause serious eye irritation.
- It may cause drowsiness or dizziness.
- Keep away from heat / sparks / open flames / hot surfaces – **No smoking.**
- Wear protection such as gloves/eye and face protection.
- It can damage painted, resin or plastic surfaces.
- IF ON SKIN: Remove contaminated clothing and rinse skin with water.
- IF INHALED: Remove person to fresh air and breath naturally.
- IF IN EYES: Rinse with water for several minutes, remove contact lenses if fitted and continue rinsing.
- Seek medical advice/attention as soon as possible.
- Use and store in a well ventilated place.

Application Steps

1. Ensure the Artefact or Coin is **completely dry** and free from any dirt, loose material or dust.
2. The Artefact or Coin should be held securely either on a suitable mount or between your fingers (ensure hand protection is worn) to avoid dropping.
3. Using the brush provided (or your own) apply a nice even coat making sure the object is fully covered. Watch our application video on the website as a guide.
IMPORTANT: Use a brush that is solvent safe and take care not to coat the painted section of the brush handle with, or immerse it in Paraloid™ B-72 mix as it may cause damage.
4. Make sure the cap is fully sealed after use or the product will evaporate.
5. If you are holding the object between your fingers and notice a build up of small white flakes near the edge you're holding, simply re-coat that area to dissolve the flakes.
6. It is not advisable to re-coat the object as it may dissolve the initial coat, however small areas can be touched in. If you wish to re-coat simply clean off the existing Paraloid™ B-72 coat with acetone and reapply.

Removal

If you're not happy with the finish, or wish to return the artefact or coin to it's natural finish, Paraloid™ B-72 can be removed by dipping a lint free cloth in Acetone, wiping the object to dissolve the coating and repeating until the coating has been removed.

If you have any further questions please checkout the website at www.arteseal.co.uk or email us at info@arteseal.co.uk.