

If you have any further queries please contact our customer service team on 0121 328 7507 or email at 'contact@jllfitness.co.uk'

## **R200 SENSOR INSTRUCTIONS**

**TOOLS** 



**MAGNET** 

## **INSTRUCTIONS**



Locate the sensor under the slideway



Run any kind of magnet over the sensor



Whilst doing this the digits on the monitor should change

## **ADVICE**

Any kind of magnet can be used for the test, for example a fridge magnet.

After the magnet has been ran over the sensor if there are still no readings this may indicate that it is a faulty sensor.