

906

Fibre Glast Developments Corporation

385 Carr Drive
Brookville, Ohio 45309
Phone: 800.214.8572
Fax: 937.833.6555
www.fibreglast.com

T-Fitting



Accomplish Twice the Vacuum with One Pump

When used with 1/2" Vacuum Tubing (#893) for vacuum bagging, this T-Fitting can be used to draw down two bags with a single pump, or to install multiple vacuum ports in a single bag. Barbed connectors are reliable and resistant to leaks. It can also be used with 1/2" Spiral Tubing (#1403) to extend vacuum lines inside the bag, or be used to extend resin feed lines in a vacuum infusion application.

T-Fitting is nylon, with a maximum service temperature of 140°F.