

PEDICUTE™ PORTABLE SPA

OWNERS MANUAL



Patents Pending

pedicute™
BY CONTINUUM
FOOTSPAS



IMPORTANT SAFETY INSTRUCTIONS

Read all instructions before using this appliance.

When using an electrical appliance, basic precautions should always be followed, including the following:

DANGER

To reduce the risk of electric shock:

- 1) Always unplug this appliance from the electrical outlet immediately after use and before cleaning.
- 2) Do not reach for an appliance that has fallen into water. Unplug immediately.
- 3) Do not use while in the bath or in the shower.
- 4) Do not place or store appliance where it can fall, or be pulled, into a tub or sink.
- 5) Do not place or drop into water or other liquid.

WARNING

To reduce the risk of burns, electric shock, or injury:

- 1) Appliance should never be left unattended when plugged in. Unplug from outlet when not in use.
- 2) Do not operate under blanket or pillow. Excessive heating can occur and cause fire, electric shock, or injury to persons.
- 3) This appliance should not be used by, or near, children or individuals with certain disabilities.
- 4) Use this appliance only for its intended use as described in this manual.
Do not use attachments not recommended by Continuum Footspas.
- 5) Never operate this appliance if it has a damaged cord or plug. If it is not working or if it has been dropped, dropped in water, or damaged, contact Continuum Footspas service center for examination and repair.
- 6) Do not carry this appliance by supply cord or use cord as a handle.
- 7) Keep the cord away from heated surfaces.
- 8) Never operate the appliance with the air openings blocked. Keep the air openings free of lint, hair and other debris.
- 9) Never drop or insert any object into any opening.
- 10) To disconnect, turn all controls to the OFF position, then remove plug from the outlet.
- 11) Do not use outdoors.
- 12) Do not operate where aerosol (spray) products are being used or where oxygen is administered.
- 13) Do not attempt to plug or unplug unit while feet or other body parts are in the water.
- 14) **DO NOT STAND ON OR IN THE FOOT MASSAGER (PEDICUTE). USE ONLY WHILE SEATED. PLACE FEET IN MASSAGER AND REMOVE FEET FROM MASSAGER ONLY WHILE IN A SEATED POSITION.**
- 15) Never operated on a soft surface, such as a bed or couch, where air openings may be blocked.
- 16) Use heated surface carefully as it may cause serious burns. If utilizing heating surface only, (dry massage) one **MUST** use the lowest heat setting only. Do not use over sensitive areas or in the presence of poor circulation. The unattended use of heat by children or incapacitated persons may be dangerous.
- 17) **DO NOT** use cracked, leaking, or otherwise damaged tub with the heating/vibrating unit.
- 18) This appliance is designed for professional use only.

SAVE THESE INSTRUCTIONS

OPERATING INSTRUCTIONS

To reduce the risk of electric shock, this appliance has a grounded plug. This plug will fit in a grounded outlet. If it does not fit, contact a qualified electrician to install a proper outlet. Do not change the plug in anyway.

CAUTIONS

The Pedicute™ should not be used if the following cases are present:

tuberculosis, benign and malignant tumors, hemorrhages, inflammations of the skin, phlebitis or thrombosis, open or fresh wounds, bruises, broken skin or varicose veins, undetermined calf pain, or joint pain.

- Consult a physician if you have any questions regarding therapeutic use of this product.
- Consult a physician before using if clients are experiencing unexplained pain, swollen muscles, or if they have recently sustained a serious muscular injury.
- Keep away from children.
- Discontinue use of massager/heater if pain increases or swelling occurs after application.
- If clients are pregnant, please consult a physician before using.

IMPORTANT NOTICE

In order for the Pedicute to function properly it must operate at room temperature (at least 65°F). If for any reason it is not at room temperature and one tries to activate the basin heater, the heating lights will continually blink. This is normal and once the unit is at room temperature the basin heater will function normally.

USER/MAINTENANCE INSTRUCTIONS

The Pedicute massaging/heating platform is designed for use in a professional salon environment only with The Pedicute tub or as dry heated foot massager.

- 1) Make sure massager/heater is in OFF position.
- 2) Fill tub with warm water and place Pedicute tub on top of the massager and plug massager into wall outlet. Never plug or unplug the massager/heater while client's feet are in the water. To eliminate splashing, do not fill tub with more than 1 and 1/2 gallons of water (approximately 2.5 inches deep). Do not fill Pedicute tub to capacity.
- 3) The heat setting is desired to maintain the temperature of warm water, not to heat cold, or room temperature water.
- 4) Have clients sit in a chair and place feet in the water. **NEVER STAND IN THE PEDICUTE FOOTSPA.**
- 5) Turn Pedicute massager heater on by pressing the ON/OFF button and select setting on the touchpad located on the unit.
- 6) Select one or a combination of the settings below:
 - Vibration and Heat (combination High/Low of vibration and heat)
 - Heat High/Low (heat only)
 - Vibration High/Low (vibration only)
- 7) To turn off, simply press the OFF button on the touch pad.
- 8) To select heat High/Low/Off press the heat button one, two, or three times.
- 9) To select vibration High/Low/Off press vibration button one, two, three or four times (for power massage).
- 10) Pedicute massager/heater can also be used as a dry foot massager when used without water.
Attention: use heat on low setting for dry use (without Pedicute Tub) to prevent burning.
- 11) Do not hang unit from power cord.
- 12) To clean Pedicute massager/heater, wipe with a damp cloth (Never submerge unit in water). Do not use any strong chemical cleaners such as benzene or acetone.
- 13) **CHECK WITH YOUR STATE BOARD FOR SPECIFIC CLEANING AND/OR SANITIZING REQUIREMENTS.**

CONTROL FEATURES

Touchpad controls combine custom settings:

- 1) ON/OFF (OFF will turn unit off and reset previous setting).
- 2) Vibration and Heat (combinations Hi and Low heat and vibration).
- 3) **Heat Only**
 - a. Press heat button one time LOW. (Low heater light lit).
 - b. Press heat button two times HIGH. (HI heater light lit).
 - c. Press heat button three times for POWER HEAT. (Both heater lights lit).
 - d. Press heat button four times to turn heat OFF.
- 4) **Massage Only**
 - a. Press vibration button one time LOW. (Low vibrating light lit).
 - b. Press vibration button two times HIGH. (HI vibrating light lit).
 - c. Press three times for POWER MASSAGE (both vibrating lights lit). Power Massage setting is not recommended for use with the Pedicute tub. Power Massage setting may cause water to splash.
 - d. Press four times to turn vibration OFF.

Heater/Massager has automatic shut off (standby) feature. The massage will shut off after 35 minutes. The heat will shut off after 70 min. Simply push either the Heat or Massage button to restart the settings.
ALWAYS TURN UNIT OFF AFTER USE.

ASSEMBLY INSTRUCTIONS

Attaching Center Foot Support Cushion to Telescoping Tube

- 1) Extend Telescoping Tube to maximum height and tighten black tension knob to secure.
- 2) Locate Center Foot Support Cushion. Position cushion over top of telescoping tube making sure hole in cushion aligns with silver push pin located on telescoping tube. Depress push pin at the same time as you push down slightly on cushion. When push pin aligns with cushion hole, it will snap into place.

Client Chair

If client chair was ordered, make sure the five (5) glides are installed as opposed to the five (5) casters.
A stationary client chair works far better than a client chair that is movable.

PEDICUTE™ PORTABLE SPA

**DANGER! ELECTRIC CORDS
CAN BE HAZARDOUS.
Misuse Can Result in Fire or
Death by Electric Shock During Use.**

- Keep Children and Pets Away from Cord.
- **Avoid Overheating.** Uncoil Cord and Do Not Cover it with any Material.
- Do Not Drive, Drag, or Place Objects over Cord.
- Fully Insert Plug into Outlet.
- Do Not Remove, Bend or Modify Any Metal Prongs or Pins of Cord or GFCI.
- Do Not Run Through Doors Ceiling, Walls or Floors.

After Use

- Grasp Plug to Remove from Outlet.
- Always Store Indoors.
- Always Unplug When Not in Use.
- Do Not Unplug by Pulling on Cord.



Continuum Footspas

2236 South 162nd Street • New Berlin, WI 53151
Phone: 262-754-4900 • Fax: 262-754-4901 • Toll Free: 1-877-255-3030
salonpedicurespas.com

PEDICUTE™ PORTABLE SPA

Specifications

- **Model:** PC 001
- **Overall Dimensions with footrest down:** 17" W (43 cm) x 19" L (48 cm) x 16" H (41 cm)
- **Overall Dimensions with footrest up:** 17" W (43 cm) x 19" L (48 cm) x 25" H (64 cm)
- **Empty Weight:** 24 lbs. (11 kg)
- **Capacity of removable basin:** 1.5 US gallons (5.7 liters)
- **Weight of filled basin:** 13 lbs (6 kg)
- **Power Source:** 110 VAC, 60 HZ, .75 A
220 VAC, 50 HZ, .45 A
- **Construction:** Welded steel frame with cherry wood veneer panels, heavy duty rubber composite casters, three (3) chemical resistant footrests - (center foot support is adjustable).
- **Heater/Massager Unit:** Three (3) levels of vibration, two (2) levels of heat, ON and OFF, removable sanitary liners. All components of Heater/Massage unit are heavy duty industrial grade, manufactured exclusively for Continuum Footspas to their specifications.
- **Shipping Information - Pedicute**
Pedicute: 28 lbs (13 kg) **Dimensions:** 20.25" W (51 cm) x 22" L (56 cm) x 19" H (48 cm)

- **Compliances:** ETL Certified
- **Limited Warranty - Pedicute:** Three (3) years on parts from date of shipment (refer to Owners Manual for complete details)



Pedicute Package Information:

- **Technician Chair:** Low profile, real cherry veneer. Base 24" diameter (61 cm)
Height range: 12.5" (32 cm) to 15" (38 cm) **Net weight:** 15 lbs. (6.8 kg)
Shipping Dimensions: 25" W (64 cm) x 24" L (61 cm) x 12" H (31 cm) **Shipping weight:** 19 lbs. (8.6 kg)
- **Accessory Cart:** Large work surface, removable storage tray, large towel bin (assembly required).
Dimensions: 18" W (46 cm) x 25" L (64 cm) x 23" H (58 cm) **Net weight:** 33 lbs. (15 kg)
Shipping Dimensions: 24" W (61 cm) x 28" L (71 cm) x 11" H (28 cm) **Shipping weight:** 35 lbs. (16 kg)
- **Client Chair:** Black leather upholstery with mock leather trim, single position tilt lock with tension adjustment, seat height adjustment, scuff resistant base with glides (assembly required).
Dimensions: Base 24" (61 cm) diameter, 26.5" D (67 cm) x 24" W (61 cm) x 41" H (104 cm)
Height range: 17" (43 cm) to 22" (56 cm) **Net weight:** 40 lbs. (18 kg)
Shipping Dimensions: 12" W (30 cm) x 27" L (68 cm) x 26" H (66 cm) **Shipping weight:** 43 lbs. (19 kg)

- **Limited Warranty - Pedicute Package Accessories:** One (1) year on parts from date of shipment (refer to Owners Manual)

Note: Due to continuous improvement, all specifications are subject to change without notice. All dimensions and weights are approximate.



salonpedicurespas.com

Continuum Footspas, LLC | New Berlin, Wisconsin
p: 262 754 4900 | f: 262 754 4901 | tf: 1 877 255 3030

PEDICUTE™ PORTABLE SPA

Limited Warranty

Continuum Footspas has designed and manufactured The Pedicute Portable Spa to the highest standards. Accordingly, Continuum Footspas expressly warrants The Pedicute Portable Spa as follows:

To the original owner of The Pedicute Portable Spa, Continuum Footspas may repair or replace, at its option, any Pedicute Portable Spa found to be defective in material or workmanship upon inspection by a factory authorized representative of Continuum Footspas. This limited warranty covers the following:

- **Pedicute:** Including "Shell" and Heater/Massager unit - Three (3) years from date of shipment from Continuum Footspas facility.
- **Pedicute Pedicure Tub:** Life-time limited warranty.
- **Accessories:** One (1) year from shipment from Continuum Footspas facility.

The exchange of a Pedicute Portable Spa is limited to supplying a replacement Pedicute Portable Spa of equal style. Owner is responsible for all labor and shipping costs necessary to replace a Pedicute Portable Spa.

NO CONSEQUENTIAL, INCIDENTAL, CONTINGENT, INDIRECT, SPECIAL OR OTHER DAMAGES WILL BE ALLOWED WHATSOEVER. This limited warranty is null and void if the Pedicute Portable Spa is subjected to improper maintenance, negligence, improper cleaning or any other circumstances beyond Continuum Footspas control.

EXCLUDED FROM LIMITED WARRANTY:

- 1) Unauthorized repairs.
- 2) Damage due to freight, accident, natural disaster and/or abuse.
- 3) Staining, fading or discolorization of any accessories, wood surfaces or any of the three (3) foam support pads located on the front of the Pedicute.
- 4) Fading, discoloration or staining of any part due to improper water additives or harmful cleaning agents or chemicals.

For service or information regarding this limited warranty, please contact.

Continuum Footspas, LLC ♦ P.O. Box 363 Brookfield, WI 53008

Toll Free: 1 877 255 3030 ♦ Telephone: 262 754 4900 ♦ Fax: 262 754 4901 ♦ salonpedicurespas.com

This limited warranty is to the original owner and is not transferable. The original owner agrees by using The Pedicute Portable Spa the obligation of Continuum Footspas shall not extend to indirect or contingent damages or injury. Furthermore, the obligations of Continuum Footspas are limited to those set forth herein. This limited warranty is the exclusive remedy and is in lieu of all other warranties, express or limited, including, but not limited to, any implied warranty of fitness or merchantability for a particular purpose. No distributor, dealer or other person has the right or authority to bind Continuum Footspas to changes to this limited warranty. Consequently, Continuum Footspas is not responsible for such warranties or representations.

ADDITIONAL PROVISIONS

- Any assistance Continuum Footspas provides to the original owner above and beyond the scope of this limited warranty does not constitute a waiver of such terms, limitations or exclusions. Furthermore, such assistance does not extend this limited warranty.
- Continuum Footspas shall not be liable for any other obligations or liabilities as a result of breach of contract of warranty, negligence or strict liability with regards to The Pedicute Portable Spa.
- This Limited Warranty applies only to Pedicute Portable Spas utilized in any one of the fifty states of the United States, the District of Columbia or provinces of Canada.



salonpedicurespas.com