

CCELL[®]

Palm

User Manual

USER GUIDE

- Screw the magnetic adapter onto your cartridge and drop into the slot.
- Draw directly from the mouthpiece to activate.
- The inhale protection function will cut off any session over 10 seconds.
- To avoid residue build-up, remove cartridge when not in use.

CHARGING

- Remove the cartridge before charging.
- The device can be charged with a Micro-USB cable. A full charge takes approx. 90min. The LED light will remain on while the device is charging.
- When the device is fully charged, the LED light will blink 20 times.
- When the charging cable is disconnected, the LED light will blink 3 times.
- Do not leave the charging device unattended or charged overnight.

OPERATING CONDITIONS

- Charging temperature: 50-113°F (10-45°C)
- Working temperature: 14-140°F (-10-60°C)
- Storage temperature: 64-82°F (18-28°C)
- Operating humidity: 35%-70% RH
- Storage humidity: 35%-70% RH

WARNING

- Do not expose device to water and keep away from any flammable gases and liquids.
- Do not use in wet environments or extreme temperatures.

- Do not leave the device exposed to direct sunlight for prolonged periods.
- Do not allow other metal objects to contact electronic components in the battery.
- Keep device and accessories out of reach of children and pets.
- Do not attempt to disassemble device as damage and personal injury may occur.
- The device contains a lithium-ion battery and should be recycled or disposed of in accordance with local requirements to avoid potential injury and/or environmental harm.
- Do not dispose of the battery or any component of the device in a fire as it could cause an explosion or other serious injuries.



**CCELL DOES NOT PRODUCE,
DISTRIBUTE OR SELL ANY
MATERIAL FILLED IN
CARTRIDGES AND OIL TANKS.**

NOT FOR SALE TO MINORS.

WARNING:
REPRODUCTIVE HARM -
WWW.P65WARNINGS.CA.GOV

**WWW.CCELL.COM
PATENTS: CCELL.COM/
PATENTS**

FOLLOW US @CCELLOFFICIAL

