



EQUIPCON

Centrifuge Tube Set

#E-CT-Set

- Individually calibrated for accuracy
- Monitors concentration and contamination
- Tubes with increments of 0.05ml & 0.1ml
- Set Includes:
 - Tube (E-CT)
 - Tube Stand (E-CTS)
 - Cleaning Brush (E-CTB)
- All items available separately



The Centrifuge Tube Set is used for the determination of content of solid particles in inspection carrier solution for magnetic particle examination. The concentration of particles in the suspension is a very important parameter in the inspection process and must be closely controlled.

The lines on the centrifuge tube are to help you easily and accurately measure the magnetic bath concentration. The particle concentration is checked after the suspension is prepared and regularly monitored as part of the quality system checks.

It is manufactured as per ASTM E1444 & E709 standards.