

Instructions for Mounting the Retractable Workbench Casters (BCS-001)



1. Hold the mounting plate up against the leg and allow the silver lever bar to drop down to hang just above the floor. (About 5-1/4" from the floor to the top of the mounting plate).



2. Mark the location of the top hole with a pencil.



3. Drill a 1/8" pilot hole at the top mark you just created.



4. Drive the top screw in place, then check that the mounting plate is straight, pilot the second hole and add the second screw.



5. Once the plate is attached, put the stem caster up through the bottom of the plate. Put the lock washer in place and then screw the nut in place till hand tightened.



6. Use a 3/4" wrench to tighten the nut, grasping the top of the caster to hold it in place until the lock washer has grabbed and you can tighten without having to hold the caster.