

Product Overview

An alternative to a close-coupled WC, this pack contains everything needed to install a fully compliant low-level WC with lever flush, finger rinse wash basin with Monobloc mixer tap, and a selection of grab rails able to support up to 30st (200kg).

Pack Specification

- Navlin Doc M raised-height, back-to-wall rimless toilet pan
- + Water-saving, low-level cistern with lever flush, screw-down lid and flush pipe
- + Ergonomic toilet seat with soft-close hinges and seat lugs, without lid (available in blue or white)
- + Padded back rest (available in blue or grey)
- + Navlin Doc M finger rinse 400mm wash basin with two tap holes
- + Monobloc spray mixer tap
- + 600mm straight grab rails with uPVC fluted finish (available in blue or white) x 4
- + 450mm straight grab rail with uPVC fluted finish (available in blue or white)
- Fold-up rail with adjustable leg and optional toilet roll holder, finished with an epoxy resin coating (available in blue or white), and treated with a rust inhibitor



Guarantees & Approvals

- + WC conforms to BS EN 997 and current UK Water Supply (Water Fittings) Regulations
- + Wash basin conforms to BS EN 14688
- AKW are self-certifying and supplying approved flush fittings in line with current UK water regulations for compliance purposes
- + WRAS approved cistern fittings



Sanitaryware (ceramic), toilet seats, brassware & grab rails



Flush fittings & fold-up rails



R₹IC€

& brassware



Features & Benefits

- Rimless toilet pan offers improved hygiene levels by reducing the build-up of bacteria and making cleaning easier
- + 480mm raised-height, back-to-wall toilet pan (height with seat affixed) complies with Doc M guidelines and aids with side transfer
- + Ergonomic toilet seat (without lid) is shaped for comfort and easy cleaning, comes with seat lugs for stability when side transferring, and soft-close hinges for safety
- Designed for use with the low-level cistern with lever handle, flush pipe and padded back rest which offers user comfort
- Low-level lever flush cistern can be easily operated by hand, closed fist, or elbow – ideal for those with limited dexterity – with a screw-down lid for added security and safety in public facilities
- + 3/6 litre flush options increase performance and water efficiency

- Two tap hole finger rinse wash basin for flexibility when installing – blanking plug supplied
- + Monobloc spray mixer tap with stylish lever handle design
- Grab rails feature a fluted uPVC finish which offers superb grip even when wet, and can support loads of up to 15.5st (100kg)
- Fold-up rail supports loads of up to 30st (200kg), features an adjustable leg and optional toilet roll holder, is finished with an epoxy resin coating and treated with a rust inhibitor for longevity
- + Components individually packaged in recyclable materials to prevent damage during transit

Product Codes

Pack 4 Low-Level Std Doc M Pack	
Fluted Blue	28313FBU
Fluted White	28313FWH



Related Products

Pack 2Fully Compliant Low-Level Doc M Pack – Fluted Blue28311FBUPack 3Close-Coupled Std Doc M Pack28312FBUFluted White28312FWHFluted White28312FWFluted Dark Blue28312FWStainless White28312SWHStainless White28312SWHStainless Mid-Grey28312SWGPack 5Close-Coupled Std Doc M Pack with TMV3 Mixer TapFluted Blue28314FWFluted White28314FWFluted White28314FWStainless White28314FWStainless White28314FWStainless White28314FWStainless White28314FWStainless White28314FWStainless White28314FWStainless White28314FWStainless White28314FWStainless Mid-Grey28314FWStainless Mite28314SWStainless Mite28314SWStainless Mite28314SWStainless Mite28314SWStainless Mite28314SWStainless Mite28314SWStainless Mite28314SWStainless Mite28314SWStainless Mite28315FWPack 6Low-Level Std Doc M Pack with TMV3 Mixer TapFluted Blue28315FWPack 7Close-Coupled Contemporary Doc M Pack – Stainless Steel28315FWPack 8Low-Level Contemporary Doc M Pack – Stainless Steel28316SPack 9Close-Coupled Peninsular Doc M Pack28317FWFluted Blue28317FW28317FW	Pack 1 Fully Compliant Close-Coupled Doc M Pack – Fluted Blue	28310FBU
Fluted Blue28312FBUFluted White28312FWHFluted White28312FWBFluted Mid-Grey28312FMGStainless White28312SWHStainless Dark Blue28312SWHStainless Mid-Grey28312SMGPack 5Close-Coupled Std Doc M Pack with TMV3 Mixer TapFluted Blue28314FWHFluted Mid-Grey28314FWHFluted Mid-Grey28314FWHFluted Mid-Grey28314FWHFluted Mid-Grey28314FWHStainless White28314FWHStainless White28314FWHStainless White28314FWHStainless White28314SWHStainless White28314SWHStainless Mid-Grey28314SWHStainless Dark Blue28314SWHStainless Dark Blue28314SWHStainless Mid-Grey28314SWGPack 6Low-Level Std Doc M Pack with TMV3 Mixer TapFluted Blue28315FBUFluted Blue28315FBUFluted Blue28315FBUFluted Blue28315FBUFluted Blue28315FBUFluted Blue28316SSPack 7Close-Coupled Contemporary Doc M Pack – Stainless Steel28316SSPack 8Low-Level Contemporary Doc M Pack28317FBUFluted Blue28317FBU28317FBUFluted Blue28317FBUFluted Blue28317FBUFluted Blue28317FBUFluted Blue28317FBUFluted Blue28317FBUFluted Blue28317FBUFluted Blue <td>Pack 2 Fully Compliant Low-Level Doc M Pack – Fluted Blue</td> <td>28311FBU</td>	Pack 2 Fully Compliant Low-Level Doc M Pack – Fluted Blue	28311FBU
Fluted White28312FWHFluted Dark Blue28312FDBFluted Mid-Grey28312FMGStainless White28312SWHStainless Dark Blue28312SDBStainless Mid-Grey28312SMGPack 5Close-Coupled Std Doc M Pack with TMV3 Mixer TapFluted Blue28314FBUFluted White28314FBUFluted Mid-Grey28314FBUFluted Mide28314FBUStainless White28314FBUFluted Mide Grey28314FBUStainless White28314FBUStainless White28314FBUStainless White28314FBUStainless Mide Grey28314SBBStainless Mide Grey28314SBBStainless Mide Grey28314SBBStainless Mide Grey28314SBBStainless Dark Blue28314SBBStainless Mide Grey28314SBBStainless Mide Grey28314SBBStainless Mide Grey28314SBBStainless Mide Grey28314SBBStainless Mide Grey28314SBBPack 6Low-Level Std Doc M Pack with TMV3 Mixer TapFluted Blue28315FBUFluted Blue28315FBUPack 7Close-Coupled Contemporary Doc M Pack - Stainless Steel28313FBUPack 8Low-Level Contemporary Doc M Pack - Stainless Steel28317FBUFluted Blue28317FBU28317FBUFluted Blue28317FBU28317FBUFluted Blue28317FBU28317FBUFluted Blue28317FBU28317FBUFluted Blue28317FBU	Pack 3 Close-Coupled Std Doc M Pack	
Fluted Dark Blue28312FDBFluted Mid-Grey28312FMGStainless White28312SDHStainless Mid-Grey28312SDBStainless Mid-Grey28312SDMGPack 5Close-Coupled Std Doc M Pack with TMV3 Mixer TapFluted Blue28314FBUFluted White28314FBUFluted White28314FBUStainless White28314FBUStainless White28314FBUStainless White28314FBUStainless White28314FBUStainless White28314FBUStainless White28314SDBStainless White28314SDBStainless Mid-Grey28314SDBStainless Mid-Grey28314SDBStainless Mid-Grey28314SDBStainless Mid-Grey28314SDBStainless Mid-Grey28314SDBStainless Mid-Grey28314SDBStainless Mid-Grey28314SDBStainless Mid-Grey28314SDBStainless Mid-Grey28314SDBStainless Mid-Grey28314SDBPack 6Low-Level Std Doc M Pack with TMV3 Mixer TapFluted Blue28315FBUFluted White28315FWHPack 7Close-Coupled Contemporary Doc M Pack - Stainless Steel283135SBPack 8Low-Level Contemporary Doc M Pack - Stainless Steel28317FBUFluted Blue28317FBU28317FWHPack 9Close-Coupled Ambulant Doc M Pack28317FWHPack 10Close-Coupled Ambulant Doc M Pack28318FBUFluted Blue28318FBU28318FBU </td <td>Fluted Blue</td> <td>28312FBU</td>	Fluted Blue	28312FBU
Fluted Mid-Grey28312FMGStainless White28312SWHStainless Dark Blue28312SDBStainless Mid-Grey28312SMGPack 5Close-Coupled Std Doc M Pack with TMV3 Mixer TapFluted Blue28314FBUFluted White28314FBBFluted Dark Blue28314FBBStainless White28314FBBStainless White28314FBBStainless White28314FBBStainless White28314SBBStainless Dark Blue28314SDBStainless Mid-Grey28314SBBStainless Mid-Grey28314SDBStainless Mid-Grey28314SDBStainless Mid-Grey28314SDBStainless Mid-Grey28314SDBStainless Mid-Grey28314SDBStainless Mid-Grey28314SDBStainless Mid-Grey28314SDBStainless Mid-Grey28314SDBStainless Mid-Grey28314SDBPack 6Low-Level Std Doc M Pack with TMV3 Mixer TapFluted Blue28315FWHPack 7Close-Coupled Contemporary Doc M Pack – Stainless Steel28316SSPack 8Low-Level Contemporary Doc M Pack – Stainless Steel28316SSPack 9Close-Coupled Peninsular Doc M Pack28317FBUFluted Blue28317FBU28317FBUFluted Blue28317FBUFluted Blue28317FBUFluted Blue28317FBUFluted Blue28317FBUFluted Blue28317FBUFluted Blue28317FBUFluted Blue28318FBUFluted Blue<	Fluted White	28312FWH
Stainless White28312SWHStainless Dark Blue28312SDBStainless Mid-Grey28312SMGPack 5Close-Coupled Std Doc M Pack with TMV3 Mixer TapFluted Blue28314FBUFluted White28314FWHFluted Dark Blue28314FDBFluted Mid-Grey28314FWGStainless White28314FWHStainless White28314SWHStainless White28314SWHStainless Mid-Grey28314SWHStainless Mid-Grey28314SWHStainless Mid-Grey28314SWGPack 6Low-Level Std Doc M Pack with TMV3 Mixer TapFluted Blue28315FBUFluted White28315FBUFluted White28315FBUPack 7Close-Coupled Contemporary Doc M Pack – Stainless Steel28319SSPack 8Low-Level Contemporary Doc M Pack – Stainless Steel28317FBUFluted Blue28317FBU28317FBUFluted Blue28317FBUFluted Blue28318FBUFluted Blue28318FBUFluted Blue28318FBUFluted Blue28318FBUFluted Blue28318FBUFluted Blue28318FBUFluted Blue28318FBUFluted Blue28	Fluted Dark Blue	28312FDB
Stainless Dark Blue28312SDBStainless Mid-Grey28312SMGPack 5Close-Coupled Std Doc M Pack with TMV3 Mixer TapFluted Blue28314FBUFluted White28314FWHFluted Dark Blue28314FDBFluted Mid-Grey28314FMGStainless White28314SWHStainless Dark Blue28314SWHStainless Dark Blue28314SWHStainless Dark Blue28314SWHStainless Dark Blue28314SWHStainless Dark Blue28314SWHStainless Mid-Grey28314SWGPack 6Low-Level Std Doc M Pack with TMV3 Mixer TapFluted Blue28315FBUFluted White28315FWHPack 7Close-Coupled Contemporary Doc M Pack - Stainless Steel28319SSPack 8Low-Level Contemporary Doc M Pack - Stainless Steel28317FBUFluted Blue28317FBU28317FBUFluted Blue28317FBU28317FBUFluted Blue28317FBU28317FBUFluted Blue28317FBU28317FBUFluted Blue28317FBU28317FBUFluted Blue28317FBU28317FBUFluted Blue28317FBUFluted Blue28317FBUFluted Blue28317FBUFluted Blue28317FBUFluted Blue28317FBUFluted Blue28317FBUFluted Blue28318FBUFluted Blue28318FBU	Fluted Mid-Grey	28312FMG
Stainless Mid-Grey28312SMGPack 5Close-Coupled Std Doc M Pack with TMV3 Mixer TapFluted Blue28314FBUFluted White28314FWHFluted Uhite28314FDBFluted Dark Blue28314FDBFluted Mid-Grey28314FMGStainless White28314SWHStainless Dark Blue28314SWHStainless Dark Blue28314SWHStainless Dark Blue28314SWBStainless Mid-Grey28314SWBStainless Mid-Grey28314SWGPack 6Low-Level Std Doc M Pack with TMV3 Mixer TapFluted Blue28315FBUFluted Blue28315FWHPack 7Close-Coupled Contemporary Doc M Pack - Stainless Steel28316SSPack 8Low-Level Contemporary Doc M Pack - Stainless Steel28316SSPack 9Close-Coupled Peninsular Doc M Pack28317FBUFluted Blue28317FBU28317FBUFluted Blue28317FBUFluted White28317FBUFluted Blue28317FBUFluted Blue28318FBUFluted Blue28318FBUFluted Blue28318FBUFluted Blue28318FBU	Stainless White	28312SWH
Pack 5 Close-Coupled Std Doc M Pack with TMV3 Mixer Tap Fluted Blue 28314FBU Fluted White 28314FWH Fluted White 28314FDB Fluted Dark Blue 28314FDB Fluted Mid-Grey 28314FMG Stainless White 28314SWH Stainless Dark Blue 28314SDB Stainless Dark Blue 28314SDB Stainless Dark Blue 28314SWH Stainless Mid-Grey 28314SDB Stainless Mid-Grey 28314SMG Pack 6 Low-Level Std Doc M Pack with TMV3 Mixer Tap Fluted Blue 28315FBU Fluted White 28315FBU Fluted White 28315FBU Pack 7 Close-Coupled Contemporary Doc M Pack – Stainless Steel 28316SS Pack 8 Low-Level Contemporary Doc M Pack – Stainless Steel 28316SS Pack 9 Close-Coupled Peninsular Doc M Pack 28317FBU Fluted Blue 28317FBU 28317FBU Fluted Blue 28317FBU 28317FBU Fluted Blue 28317FBU 28317FBU Fluted Blue 28317FBU 28317FWH	Stainless Dark Blue	28312SDB
Fluted Blue28314FBUFluted White28314FWHFluted Dark Blue28314FDBFluted Dark Blue28314FDBFluted Mid-Grey28314FMGStainless White28314SWHStainless Dark Blue28314SDBStainless Mid-Grey28314SDBStainless Mid-Grey28314SMGPack 6Low-Level Std Doc M Pack with TMV3 Mixer TapFluted Blue28315FBUFluted Blue28315FBUFluted White28315FWHPack 7Close-Coupled Contemporary Doc M Pack - Stainless Steel28319SSPack 9Close-Coupled Peninsular Doc M Pack28317FBUFluted Blue28317FBU28317FBUFluted White28317FBUFluted White28317FBUFluted Blue28317FBUFluted Blue28318FBU	Stainless Mid-Grey	28312SMG
Fluted White28314FWHFluted Dark Blue28314FDBFluted Mid-Grey28314FDGStainless White28314SWHStainless Dark Blue28314SDBStainless Mid-Grey28314SDBStainless Mid-Grey28314SMGPack 6Low-Level Std Doc M Pack with TMV3 Mixer TapFluted Blue28315FBUFluted White28315FWHPack 7Close-Coupled Contemporary Doc M Pack - Stainless Steel28319SSPack 8Low-Level Contemporary Doc M Pack - Stainless Steel28316SSPack 9Close-Coupled Peninsular Doc M Pack28317FBUFluted Blue28317FBU28317FBUFluted White28317FBUFluted Blue28317FBUFluted Blue28318FBU	Pack 5 Close-Coupled Std Doc M Pack with TMV3 Mixer Tap	
Fluted Dark Blue28314FDBFluted Mid-Grey28314FMGStainless White28314SWHStainless Dark Blue28314SDBStainless Mid-Grey28314SMGPack 6Low-Level Std Doc M Pack with TMV3 Mixer TapFluted Blue28315FBUFluted White28315FWHPack 7Close-Coupled Contemporary Doc M Pack – Stainless Steel28319SSPack 8Low-Level Contemporary Doc M Pack – Stainless Steel28316SSPack 9Close-Coupled Peninsular Doc M Pack28317FBUFluted Blue28317FBUFluted Blue28318FBU	Fluted Blue	28314FBU
Fluted Mid-Grey28314FMGStainless White28314SWHStainless Dark Blue28314SUBStainless Mid-Grey28314SMGPack 6Low-Level Std Doc M Pack with TMV3 Mixer TapFluted Blue28315FBUFluted White28315FWHPack 7Close-Coupled Contemporary Doc M Pack – Stainless Steel28319SSPack 8Low-Level Contemporary Doc M Pack – Stainless Steel28316SSPack 9Close-Coupled Peninsular Doc M Pack28317FBUFluted Blue28317FBU28317FBUFluted Blue28317FBUFluted Blue28317FBUPack 10Close-Coupled Ambulant Doc M PackFluted Blue28318FBU	Fluted White	28314FWH
Stainless White28314SWHStainless Dark Blue28314SDBStainless Mid-Grey28314SMGPack 6Low-Level Std Doc M Pack with TMV3 Mixer TapFluted Blue28315FBUFluted White28315FWHPack 7Close-Coupled Contemporary Doc M Pack – Stainless Steel28319SSPack 8Low-Level Contemporary Doc M Pack – Stainless Steel28316SSPack 9Close-Coupled Peninsular Doc M Pack28317FBUFluted Blue28317FBU28317FBUFluted Blue28317FBUFluted Blue28317FBUFluted Blue28317FBUFluted Blue28317FBUFluted Blue28317FBUFluted Blue28317FBUFluted Blue28317FBUElue28317FBUStainless 10Close-Coupled Ambulant Doc M PackFluted Blue28318FBUFluted Blue28318FBU	Fluted Dark Blue	28314FDB
Stainless Dark Blue28314SDBStainless Mid-Grey28314SMGPack 6Low-Level Std Doc M Pack with TMV3 Mixer TapFluted Blue28315FBUFluted White28315FWHPack 7Close-Coupled Contemporary Doc M Pack - Stainless Steel28319SSPack 8Low-Level Contemporary Doc M Pack - Stainless Steel28316SSPack 9Close-Coupled Peninsular Doc M Pack28317FBUFluted Blue28317FBUFluted White28317FWHPack 10Close-Coupled Ambulant Doc M PackFluted Blue28317FWHPack 10Close-Coupled Ambulant Doc M PackFluted Blue28318FBUFluted Blue28318FBU	Fluted Mid-Grey	28314FMG
Stainless Mid-Grey28314SMGPack 6Low-Level Std Doc M Pack with TMV3 Mixer Tap28315FBUFluted Blue28315FBUFluted White28315FWHPack 7Close-Coupled Contemporary Doc M Pack - Stainless Steel28319SSPack 8Low-Level Contemporary Doc M Pack - Stainless Steel28316SSPack 9Close-Coupled Peninsular Doc M Pack28317FBUFluted Blue28317FBU28317FWHPack 10Close-Coupled Ambulant Doc M Pack28317FWHPack 10Close-Coupled Ambulant Doc M Pack28318FBU	Stainless White	28314SWH
Pack 6 Low-Level Std Doc M Pack with TMV3 Mixer Tap Fluted Blue 28315FBU Fluted White 28315FWH Pack 7 Close-Coupled Contemporary Doc M Pack – Stainless Steel 28319SS Pack 8 Low-Level Contemporary Doc M Pack – Stainless Steel 28316SS Pack 9 Close-Coupled Peninsular Doc M Pack 28317FBU Fluted Blue 28317FBU 28317FBU Fluted Blue 28317FWH 28317FWH Pack 10 Close-Coupled Ambulant Doc M Pack 28318FBU	Stainless Dark Blue	28314SDB
Fluted Blue28315FBUFluted White28315FWHPack 7Close-Coupled Contemporary Doc M Pack – Stainless Steel28319SSPack 8Low-Level Contemporary Doc M Pack – Stainless Steel28316SSPack 9Close-Coupled Peninsular Doc M Pack28317FBUFluted Blue28317FBU28317FBUFluted White28317FWHPack 10Close-Coupled Ambulant Doc M Pack28317FWHFluted Blue28317FWH28317FWHPack 10Close-Coupled Ambulant Doc M Pack28318FBU	Stainless Mid-Grey	28314SMG
Fluted White28315FWHPack 7Close-Coupled Contemporary Doc M Pack – Stainless Steel28319SSPack 8Low-Level Contemporary Doc M Pack – Stainless Steel28316SSPack 9Close-Coupled Peninsular Doc M Pack28317FBUFluted Blue28317FBU28317FWHFluted White28317FWHPack 10Close-Coupled Ambulant Doc M Pack28318FBU	Pack 6 Low-Level Std Doc M Pack with TMV3 Mixer Tap	
Pack 7Close-Coupled Contemporary Doc M Pack – Stainless Steel28319SSPack 8Low-Level Contemporary Doc M Pack – Stainless Steel28316SSPack 9Close-Coupled Peninsular Doc M Pack28317FBUFluted Blue28317FBU28317FWHFluted White28317FWH28317FWHPack 10Close-Coupled Ambulant Doc M Pack28318FBU	Fluted Blue	28315FBU
Pack 8 Low-Level Contemporary Doc M Pack – Stainless Steel 28316SS Pack 9 Close-Coupled Peninsular Doc M Pack 28317FBU Fluted Blue 28317FBU 28317FWH Fluted White 28317FWH 28317FWH Pack 10 Close-Coupled Ambulant Doc M Pack 28318FBU Fluted Blue 28317FWH 28318FBU	Fluted White	28315FWH
Pack 9 Close-Coupled Peninsular Doc M Pack Fluted Blue 28317FBU Fluted White 28317FWH Pack 10 Close-Coupled Ambulant Doc M Pack Fluted Blue 28318FBU	Pack 7 Close-Coupled Contemporary Doc M Pack – Stainless Steel	28319SS
Fluted Blue 28317FBU Fluted White 28317FWH Pack 10 Close-Coupled Ambulant Doc M Pack Fluted Blue 28318FBU	Pack 8 Low-Level Contemporary Doc M Pack – Stainless Steel	28316SS
Fluted White28317FWHPack 10Close-Coupled Ambulant Doc M PackFluted Blue28318FBU	Pack 9 Close-Coupled Peninsular Doc M Pack	
Pack 10 Close-Coupled Ambulant Doc M Pack Fluted Blue 28318FBU	Fluted Blue	28317FBU
Fluted Blue 28318FBU	Fluted White	28317FWH
	Pack 10 Close-Coupled Ambulant Doc M Pack	
Fluted White 28318FWH	Fluted Blue	28318FBU
	Fluted White	28318FWH



Dimensions







Doc M Installation – Plan View

Doc M compliancy is dependent on the design of the space and placement of the products. This means that although you may have purchased a Doc M sanitaryware pack most relevant for the environment and user needs, unless this is installed correctly and follows guidance issued within Doc M Building Regulations, your washroom will **not** be fully compliant.

The below drawing illustrates how to correctly install this pack to create a compliant Doc M washroom.



Key

- 1. Sanitary dispenser
- 2. Alternative door position
- 3. Waste disposal bin
- Shelf, installed 760mm above finished floor level
- Wheelchair turning space (1500x1500mm)
- 6. Long mirror
- 7. Wall A (see side view)
- 8. Wash basin, this should project no further than 250mm from wall
- 9. Vertical grab rails
- **10.** Mixer tap, installed on side of basin nearest WC
- **11.** Two clothes hooks, installed 1050mm and 1400mm above finished floor level
- 12. Alarm pull cord
- 13. Horizontal grab rail
- Sanitary disposal unit
- 15. Fold-up support rail
- 16. Vertical grab rail
- 17. Flush mechanism, installed on side of cistern furthest from wall
- Flat-topped, close-coupled cistern, provides back rest and colostomy bag changing surface for standing users *
- **19.** Horizontal pull rail on outward-opening door

* Where low-level cisterns are used, a rail with padded back rest should be provided, and a colostomy bag changing shelf installed 950mm above finished floor level.

NOTE: Examples shown are for right-handed transfer to WC.



Doc M Installation – Side View



Dimensions shown in millimetres

Key

- 1. Wall A (see plan view)
- 2. Alarm pull cord with two red bangles
- **3.** Vertical grab rails installed above wash basin 500-700mm apart with basin positioned centrally below
- Colostomy bag changing shelf, installed 950mm above finished floor level *
- Sanitary dispenser, installed on wall adjacent to door, with coin slot positioned 750-1000mm above finished floor level
- 6. Automatic hand dryer
- 7. Soap dispenser

- 8. Paper towel dispenser
- 9. Toilet tissue dispenser
- 10. Alarm reset button
- 11. Centre of vertical grab rails should be 1100mm
- 12. Horizontal grab rail
- 13. Shelf, installed 760mm above finished floor level
- 14. Wash basin, mixer tap installed on side of basin nearest WC
- Flat-topped, close-coupled cistern, provides back rest and colostomy bag changing surface for standing users *

* Where low-level cisterns are used, a rail with padded back rest should be provided, and a colostomy bag changing shelf, installed 950mm above finished floor level.

NOTE: Examples shown are for right-handed transfer to WC.

AKW | For External Use akw-ltd.co.uk | AKW, Pointon Way, Hampton Lovett, Droitwich Spa WR9 0LR