



#### MONTAGGIO PERIMETRALI POSTERIORI

*Instuction to mount rear perimetric pipe*

Alzare la sella dello scooter, svitare le viti che fissano il portapacchi di serie, allentandolo ed estrarre le due viti che lo fissano alla scocca sopra il fanale posteriore, FIG. B.

Fissare al sottoscocca il supporto portaperimetricale dotato di 3 viti TE 5x16 di fissaggio e centrarlo. Infilare il piolo del perimetricale nella parte sottoscocca, primo quello di SX frontemarcia, indi avvitare sotto il portapacchi lasciandolo lento, poi stessa operazione con il DX badando di infilare la boccia di connessione fig. C-D Stringere il tutto assestando in posizione ottimale.

#### INSTRUCTION TO MOUNT REAR PERIMETRIC PIPE

Lift the scooter saddle, disassemble the screws which fix its own rear carrier, take off the screws that are fixing the rear carrier on the shield over the rear lamp. (Fig. B). Fix to the under-shield the perimetric pipe plate which have its own 3 screws to fix and centre. Insert the left perimetric pipe pin under the shield after assemble the rear carrier and leave it loose and it is the same with the right side, to have attention to insert the connection bush as FIG C-D. Tighten all the parts arrangement the right position.