

Heat Activated Data Sheet

TechMount® Dry Mount Tissue

Techmount® is a breathable, porous dry mount tissue created for dry mounting RC photographs and most paper based prints. It produces a smooth permanent bond activating at low temperatures. TechMount® is a tissue based material coated on both sides with a heat activated adhesive that bonds as it heats. The bond becomes permanent when cool.

SPECIFICATION

Construction

Adhesive

Processing Temperature

Recommended temperatures and dwell times should be used as a guideline. The best combination could vary depending upon equipment, substrate, size and humidity.

Porous Breathable pH neutral base paper.

pH neutral adhesive 7.0 with a permanent bond

85 – 95C The temperature may vary according to the substrate and equipment

used.

Dwell Time - Mechanical Press 1.5 - 2mins Vacuum Press 2 - 3mins

HEALTH & SAFETY

When used for the purpose intended this product presents no known hazard

WARRANTY

All data pertaining to this product has been compiled from research and is believed to be correct however it is for guidance only. It is recommended that the purchaser independently determines that the product is suitable for purpose.

Mountingsubstrates.com reserves the right to alter or amend information without giving prior notice.

Mountingsubstrates.com Moulton Park Business Centre Redhouse Road Northampton NN3 6AQ

01604 497775

sales@mountingsubstrates.com www.mountingsubstrates.com