

# H600 PRODUCT DATA SHEET

With a Hydraloop device, you can recycle up to 95% of shower & bath greywater and optionally 50% of washing machine greywater – which enables you to reuse up to 45% of the total in-house domestic greywater. Due to its innovative and breakthrough technology, Hydraloop reusable water is clean, clear, safe and certified and for toilet flushing, washing machine, garden irrigation and/or swimming pool top-up.

## HYDRALOOP H600

H600	<p>Input: Greywater from shower and bath</p> <p>Output: Two (2) valves for reusable water to the toilets and the washing machine</p> <p>Colour: Stone</p> <p>Front Plate: Stainless-steel front plate with white coloured logo and small status light</p>
H600 Premium	<p>Input: Greywater from shower and bath</p> <p>Output: Two (2) valves for reusable water to the toilets and the washing machine</p> <p>Choose from three colours: Dew, Chili and Stone</p> <p>Front Plate: Premium stainless-steel front plate with Hydraloop LED logo lights</p>

## ADD-ONS

Output Garden (auxiliary outlet)	One (1) extra valve for reusable water in the garden
Output Pool (auxiliary outlet)	One (1) extra valve for reusable water for the pool
Lift pumps *	<p>DAB Novabox 30/300. This lift pump is submerged underneath the floor</p> <p>DAB Genix VT 030. This lift pump is on the floor</p>

\*A lift pump is only necessary if Hydraloop device is positioned on same floor or a story higher as shower/bathtub.

\*Please note: DAB pump listed above is not certified in NA

## HYDRALOOP H600 SPECIFICATIONS

Volume	600 L / 160 gallons
Cleaning capacity	1000 L / 260 gallons per day
Dimensions	80 cm wide, 69 cm deep, 187 cm high 31.5" wide, 27.5" deep, 74" high
Voltage	100/240 V, 24V internal
Usage	40 W during treatment Average power consumption: 350 kWh/year
WiFi	The Hydraloop device needs to be connected to internet with a WiFi-network
Average reusable water quality	Non-potable water CBOD5: < 10 ppm TSS: <10 ppm Turbidity: NTU E. coli: < 14 pH: 6.0 – 9.0
Noise Level	± 46 dB.

## LED LIGHT INDICATIONS

White	Hydraloop device provides recycled greywater.
Blue	Hydraloop device provides backup water (until reusable water becomes available).
Purple	The washing machine mode is active.
Green	In self-cleaning mode.
Orange + two (2) short sound signals per minute	The UV disinfection lamp is not functioning properly.
Red + three (3) short sound signals/minute	The water distribution pump has switched itself off. Which might happen when water is leaking somewhere in-house.






## CONNECTION OVERVIEW

### Input connections

Main greywater inlet into the top of the Hydraloop device: 40 mm | 1 ½" OD

- Bring all greywater sources into one dedicated line.
- Please ensure all greywater lines are separated from black water.
- If the greywater input is on a higher floor than the Hydraloop device, gravity will direct the flow.
- In other circumstances, install a lift pump.

### Greywater inlet to the Hydraloop device from

- 1**  Shower  
Bath
- 2**  Tumble dryer  
Air conditioning  
Heat pump
- 3**  Optional: Washing machine (only with inlet diverter)  
You can connect only one (1) washing machine per Hydraloop device

### Power/Network connections

- 4** Permanent WiFi internet connection:  
Bandwidth of 2.4GHz or 5 GHz  
Ethernet & Bluetooth (v 2.0)
- 5** Power supply: 100-120V (60Hz) or 200-240V  
Outlet to be within 1.2 m of device
- 6** Backup water inlet  
Tap water or other: 15 mm | ½" MNPT – flow of 12 LPM | 3.2 USGPM  
If the flow rate is higher than 12LPM | 3.2 USGPM, floater cap and flow regulator.  
If you use a rainwater pump, install an expansion vessel and 50-micron mesh pre-filter.

## Output connections

- 7** Wastewater outlet  
Connection to sewer: 40 mm | 1 ½" OD (min. of 50 mm | 2") with rubber sleeve  
Wastewater from the Hydraloop device to sewer (gravity) operates on a timer for wastewater release every 7 days
- 8** Toilet flushing (pressurized):  
15 mm | ½" MNPT
- 9** Washing machine (pressurized):  
15 mm | ½" MNPT
- 10** Auxiliary outlet (non-pressurized):  
15 mm | ½" MNPT

