

WEIGHT INFORMATION SHEET

WKP CAN AM HD SECONDARY CLUTCH ROLLER

PART NUMBER(s): WKP-CASCR

STEPS

P/Ns: WKP-CASCR

- 1) Use the digital scale to weight each item.
- 2) Set the scale measurement to grams.
- 3) Place a small parts bin on the scale. The small parts bin should weight 100 grams.
- 4) Tare the weight on the scale with the small parts bin still on top so the weight gets calibrated to 0 grams.
- 5) Start placing each item into the bin until the desired weight is reached for each item count.
- 6) If weight measurements are off you are encouraged to count manually for verification or add more items to exceed the allowed item count.



PARTS BREAKDOWN

ITEM	PART DESCRIPTION	QTY	WEIGHT PER QTY
Α	ROLLER	1	7-8 grams
А	ROLLER	25	195-196 grams
Α	ROLLER	50	387-390 grams
А	ROLLER	100	773-775 grams