


Tools Required:
1. Philips Head Screwdriver



"Original" Mounting Hardware Installation Instructions

TIP: Make sure the round mounting bases have clear rubber gaskets pre-installed on the underside and that they are clean and dry. Use a little Windex® or any glass cleaner around the mounting holes of the toilet to get the mounting surface squeaky clean.



1. Install the mounting bases on the bowl.

- a) Insert clear plastic ribbed inserts into the holes in the toilet.
- b) Place mounting bases over holes in toilet (posts facing front of bowl).
- c) Place stainless steel washers in mounting base slots.
- d) Insert screws through rectangular washer, mounting base and clear plastic ribbed insert.



IMPORTANT: The black rubber washer goes on first, then the white washer and finally, the white wingnut.

TIP: Stack washers on wingnut and hold in one hand to thread onto screw. Place thumb or finger on screw head to keep it from turning. Do not completely tighten.

2. Attach and adjust seat.

3. Tighten very firmly with a screwdriver. IMPORTANT: To tighten properly, it is necessary to hold the wingnuts beneath while tightening with a screw driver.