

flexique™ Preparation Instructions

Instructions below are based on mixing one unit of Flexique™
(one pouch each of Part A and Part B).

Makes approximately 0.6 cup (150ml) of product.

1. Open the dry ingredient pouch (Part A) and add the contents to 1/2 cup (125 ml) cold water. Tip: you can use the jar in which the product was packed.
2. Mix thoroughly and quickly with your choice of utensil until all ingredients are wet.
3. Cover and let sit for 15 minutes to overnight.

4. Heat mixture:

Microwave Instructions - heat the mixture for 15 seconds and stir. Repeat three times or until everything is liquid. Do not overheat. Boiling may cause it to overflow. Temperature will reach approximately 140 degrees F (60°C).

Note:

- based on a 950-watt microwave. Adjust your heating times if your microwave's wattage differs.
- if you mix smaller quantities you'll want to start with lower heating times to avoid overflowing.

Stovetop Instructions - although a microwave produces more exact results, a stove or fondue pot may also be used. We recommend using a cooking/candy thermometer. Heat product slowly on low heat and bring temperature to approximately 140 degrees F (60°C), stirring occasionally. Remove from heat and pour into a separate container.

Tip: If you want a clear product, remove any white bubbles that might form on the top and discard. You can eliminate this step if you are going to color the product so that it is opaque.

5. Add the contents of the liquid pouch (Part B) and mix.
 6. At this point you can add any desired colors, scents or flavors. A little goes a long way (for instance, a few drops of white will make it opaque).
 7. The product is ready to use as long as it is in liquid form. When it begins to get too thick, re-heat it in the microwave at 15-second intervals until it is liquid again. An alternate method for extending the working time is to keep the container in a warm water bath so that it retains heat.
 8. Refrigerate any unused product that has been mixed.
-

For more instructions on how to use and store Flexique, visit our online FAQs and tutorial section at www.flexique.com/how-to