

# CARTA

## HOW TO GUIDE



## FOCUS V



### IN THE BOX

- ✗ Carta
- ✗ 18350 batteries x 2
- ✗ USB-C charging cable
- ✗ Carb Cap
- ✗ Quartz Buckets
- ✗ Loading tool
- ✗ Glass Top
- ✗ Wax Pod
- ✗ Wipes

On/Off – 5 clicks

Change Temp – 1 clicks

Reactivate heating from Standby – 1 click

Activate Temp Selection – 1 click

In activation mode, holding down the On/Off button will cancel the heat up but keep the unit in Standby mode.

## HOW TO OPERATE

1

## LED SETTINGS

START-UP: blinking white  
HEATING UP: blinking blue  
READY TO USE: solid green  
LOW BATTERY: blinking red

Battery Life/Charging:

- 1 Solid Red LED = 25%
- 2 Solid Red LED's = 50%
- 3 Solid Red LED's = 75%
- ALL LED's = 100%

Level 1 = 500F / 260C

Level 2 = 630F / 332C

Level 3 = 770F / 410C

Level 4 = 842F / 450C

## TEMP SETTINGS

2

## WARRANTY

Focus V warrants this device against any defects in materials used to produce this product for a period of 3 years and atomizer for 1 month, from the retail purchase date. This warranty can only be used by the original end-user.

If a claim is received and determined to be valid, Focus V will either:

1. Repair the product defect
2. Exchange the product

\*Warranty does not apply to normal performance degradation, battery or glass attachment.

3

## CARTA QUICKSTART

### Charging Your Carta

Before your first use, you will want to charge it using the included USB-C charging cable. Using this charging cable, a full charge will take about 2 hours. LED lights will blink while the device is charging. When the device is fully charged the lights will turn off completely.

### Install Batteries

Put the included batteries into the battery case located on the bottom of the unit.

4

### Carta Glass Top

Fill glass attachment with water and attach to base.

•Make sure the attachment hole lines up with the atomizer.

\*Do not over fill with water.

\*Device can be used without water.

### Loading The Buckets

Use the included loading tool to add your concentrates to the atomizer before turning on the device.

It is best to place concentrates on the bottom of the chamber rather than on the sides.

5

### Ready to Get Started!

Make sure the glass attachment is securely on the base before \ turning on device.

Turn device on (5 clicks on/off)

Change temp (1 clicks)

Set temp (1 click)

Device will vibrate when temp is reached

Steady inhales and enjoy!

6

## WARNINGS

Do not blow into glass when filled with water and attached to base.

Allow chamber to fully cool before touching.

Avoid contact with active atomizer.

Do not overcharge the battery.

Do not overfill glass with water.

Attach/detach glass carefully.

Do not overfill chamber.

Do not short circuit it.

### Overheating:

Carta LEDs will blink 8 times and shut off

### Short circuit:

Carta LEDs will blink 5 times and shut off

This device contains a Lithium-Ion battery. These batteries contain toxic materials that are hazardous to our health and the environment if left in a landfill. Please recycle them appropriately.

7