

Mask Making Kit

- Instuctions and Info
- 1 yard of fabric
- 2 yards of elastic
- Yield: Up to 12 masks

Instructions

Cut 2 squares of fabric according to the template, and 2 pieces of elastic 7" long for adult or children You can make 2 sizes: Adult (9"x6") or Child (7.5"x5")

- 1. Put right sides of fabric together.
 - 2. Sew along the bottom edge

4. Insert elastic at one corner. Sew in place and back stitch to anchor in place.

5. Sew to the next corner, stop, and bring the other end of that same elastic to the corner and sew a few stitches forward and back.

6. Now sew across one third of the top edge.

Repeat steps 4-6 with the opposite side, being careful to leave a 1"-2" turning hole on the top edge.

7. Turn inside out.

- 7. Pin 3 tucks or pleats on each side of the mask. Make sure the tucks are the same direction.
- 8. Sew along the edges of the mask 1/8" from the edge to secure pleats and close the turning hole.

Using Your Masks

You may keep the masks you make with this kit for personal use. Pennsylvania residents are encouraged to wear masks whenever you enter a public place. This will prevent you from spreading the virus to others if you are carrying it without exhibiting symptoms. When wearing a mask you should still practice social distancing, frequent hand washing, and launder your mask after each use.

Donating Your Masks

The following organizations are accepting mask donations:

Derry Presbyterian Church in Hershey, PA

The Hershey Fire Department

Grocery Outlet Bargain Market

PPE Collection Site on Stonegate Road in Hummelstown

www.MakeMasks.org

If you would like your organization to be added to this list, please contact Kelly@Cabooties.com

For an updated list please visit www.cabooties.com/pages/masks



Mask Making Kit Template - Trace on scrap paper and save your original

Adult Mask - 9"x6"

Children's Mask - 7.5"x5"