

Tales from the Crypt Electric Chair Mod Installation

1. Make sure power is turned off
2. Remove lockbar take out glass
3. Disconnect the wiring harness near the black zip tie, notice black to back and red to red wire
4. Find a suitable hole near the location you are installing the chair
5. Remove pinballs or stuff the small rag near shooter lane hole
6. Lift the playfield all the way up leaning up against the back box
7. Push small wire through the desired hole in the playfield
8. Connect alligator clips to a 12V flasher light socket near chair location (see attached pic)
9. Lower the playfield, place the chair in desired position, plug the two wires together (red to red, black to black)

The chair sits pretty tight in this location without moving, enclosed are few various size brackets that can be used if needed.

10. Turn on game to test.
11. Test by going to menu flasher test, or by playing the game