

# The

# Axis Pulse



PurePressure by Agrify's Axis Pulse is a vessel shaker or drum vibrator that reduces the blinding, or blocking, of filtration bags during the filtration process of ice water extraction. This reduces the need for the operator to physically shake the filtration bag, improving operator efficiency. Add the Axis Pulse to a Bruteless Hash Washing System to improve flow rate during filtration, enabling increased efficiency and reduced operational costs.

## Reduced Blinding

Product tests revealed reduced blinding of filter bags during the hash filtration process, improving flow rate.

## Bruteless Compatibility

For use with the Bruteless Vessel Elevated Axis Dolly and the Axis Hash Washing System. Available for existing users and as a part of a Solventless Extraction Package.

## Improved Operator Efficiency

The Axis Pulse reduces the need to physically shake the vessel, freeing up the operator and improving efficiency.

Specification	
Mounting & control kit included	
Pneumatic adjustable operation	1920 VPM @ 27 PSI   2580 VPM @ 87 PSI
Operational CFM	2 - 6.8 CFM
Force	158.63 LBS

## Reliability, Guaranteed

PurePressure is committed to making operators as efficient as possible. The team is legendary for exceptional customer service and solventless extraction trainings. The Axis Pulse includes a 1-year manufacturer warranty.