

Light Coloured Epoxy How to finish an epoxy table







Sand the whole table using Galaxy 150mm Sanding Discs in 120 grit, then 180 grit using the Mirka Deros Random Orbital Sander with 5mm Orbit.



Sand the resin section using Galaxy 320, 600, 1000 and lastly 1500 grit.



Wet sand the resin using Abralon Foam Sanding Discs in 2000 grit, followed by 3000 grit.



Polish the resin using the ARP-B 300NV Cordless Polisher with a Yellow Waffle Pad and Polarshine 10.



Finish the surface with an oil of your choosing.