


# Flush to Wall Triple Monitor Desk Mount

Instruction Manual



## SKU: STAND-V103C



Scan the QR code with your mobile device or follow the link for helpful videos and specifications related to this product.

https://vivo-us.com/products/stand-v103c

GET IN TOUCH | Monday-Friday from 7:00am-7:00pm CST



help@vivo-us.com



www.vivo-us.com Chat live with an agent!



309-278-5303

## 

If you do not understand these directions, or if you have any doubts about the safety of the installation, please call a qualified technician. Check carefully to make sure there are no missing or defective parts. Improper installation may cause damage or serious injury. Do not use this product for any purpose that is not explicitly specified in this manual. Do not exceed weight capacity. We cannot be liable for damage or injury caused by improper mounting, incorrect assembly or inappropriate use.



#### **TIPOVER WARNING**

SERIOUS OR FATAL CRUSHING INJURIES CAN OCCUR FROM TIPOVER. TO HELP PREVENT TIPOVER:


- NEVER ALLOW CHILDREN TO CLIMB, STAND, HANG, OR PLAY ON ANY PART OF MONITOR OR STAND.
- USE TIPOVER RESTRAINT OR ANCHOR STAND TO WALL

USE OF TIPOVER RESTRAINTS MAY ONLY REDUCE, BUT NOT ELIMINATE RISK OF TIPOVER.



## **WARNING: CHOKING HAZARD**

SMALL PARTS - NOT FOR CHILDREN UNDER 3 YEARS. ADULT SUPERVISION IS REQUIRED.




NOTE: SOME HARDWARE INCLUDED MAY NOT BE USED

Failure to do so may result in serious injury.



## **ASSEMBLY STEPS**


#### STEP 1



## STEP 2


#### **OPTION A: Clamp Installation**

Attach Upper Clamp (B1) to Pole (A) using the M6x16mm Flathead Screws (S-G) and 4mm Allen Wrench (T-A). Peel the protective film off of Soft Pad (J) and place it onto Upper Clamp (B1).




#### **OPTION B: Grommet Base Installation**

Remove the screw from the top of Lower Clamp (B2) using a Phillips screwdriver, and set aside Clamp Bolt (B3) and Support Plate (B4). Cut Soft Pad (J) along the perforated lines. Peel the protective film off of Soft Pad (J) and place the pieces onto Grommet Plate (K) as shown below.





#### **OPTION A: Clamp Installation**

For thinner desktops (10-50mm), re-attach Lower Clamp (B2) to Upper Clamp (B1) and tighten the screws using the 4mm Allen Wrench (T-A).



For thicker desktops (40-85mm), disassemble Lower Clamp (B2) using a Phillips screwdriver as shown below. Flip the L-bracket over and reassemble. Then re-attach Lower Clamp (B2) to Upper Clamp (B1) and tighten the screws using 4mm Allen Wrench (T-A). Tighten the clamp assembly to the desktop.







#### **OPTION B: Grommet Installation**

If not using an existing through-hole, using a 10mm (%") drill bit, drill through the desktop at least 2" away from the edge.

Desktop with Existing Through-Hole.




Secure Grommet Plate **(K)** to Pole **(A)** using M5x16mm Flathead Screw **(S-H)** and a Phillips Screwdriver. Attach Pole assembly to the desktop using Support Plate **(B4)** and Clamp Bolt **(B3)** as shown below.




#### STEP 3

Assemble Arms (D), Arm Support
Bracket (I) and Bracket Plate (H)
using M6x27mm Screws (S-F) and
4mm Allen Wrench (T-A). Secure
Arm Extensions (E) to Arms (D)
using M8x42mm Screws (S-I)
and 6mm Allen Wrench (T-B).
Mount Center VESA Bracket (G) to
Bracket Plate (H) using M8x50mm
Screw (S-C), M8 Washers (S-D),
and M8 Nut (S-E) with 6mm Allen
Wrench (T-B) and Wrench (T-C).


#### STEP 4




#### STEP 5




## STEP 6




## STEP 7




## STEP 8





### STEP 10





## Open Monday - Friday 7:00am - 7:00pm CST,

our dedicated support team can offer immediate assistance with rapid response times. If any parts are received damaged or defective, please contact us. We are happy to replace parts to ensure you have a fully functioning product.



309-278-5303

AVG. RESOLUTION TIME (within office hrs): 5M 4S



www.vivo-us.com
Chat live with an agent!

AVG. RESOLUTION TIME (within office hrs): < 15 M



help@vivo-us.com

AVG. RESPONSE TIME (within office hrs): 1HR 8M

- 23% within < 15m
- 38% within < 30m
- 61% within < 1hr
- 83% within < 2hr
- 92% within < 3hr