Pantechnicon Group Cover for Linea Mini

Installation Instructions

Thanks for your purchase of this Pantechnicon Group Cover for the Linea Mini!

- Step 1. For safety, turn off and unplug your machine. Remove the 4 screws and cover plate on top of the group.
- Step 2. Remove two screws which attach paddle from the bottom.
- Step 3. Remove nuts and washers which attach the factory plastic group cover to the control panel.
- Step 4. Install new group cover using the same nuts and washers.
- Step 5. Install paddle
- Step 6. Verify that the paddle can move through the full range of motion without rubbing on the group cover, either on the top or on the inside where the lever pokes through.
- Step 7. Reinstall the cover plate and you are done!

Let us know if you have any comments or feedback, and go do something nice for somebody!

Best, Jacob jacob@pantechnicondesign.com