

EDGE SERIES

BINOCULAR USER MANUAL



- 1 EYECUPS
- 2 DIOPTER
- 3 FOCUS
- (4) TRIPOD COVER
- **5** OBJECTIVE LENS

SETTING DIOPTER FOCUS

- Close left eye, open right eye.
- Adjust the Diopter ring setting until the image is clear.
- Now, use center focus adjustment to get a clear image.

TWIST UP EYE CUPS

- Leave in the closed position for use with glasses.
- Twist-up for use without eyeglasses for proper eye relief.

CENTER HINGE

 This allows for widening or narrowing the binocular to allow for a perfect eye alignment.

CARE & STORAGE

- Use a soft cloth or airbrush to clean the lens of debris.
- Keep lens covers in place when not in use.
- Store in a dust and moisture-free area.
- No maintenance or lubrication is required.