

Bumper Guard for Canister Vacuum

Installation Instructions

1. Thoroughly clean the vacuum with a non-bleach and non-oil-based cleaning solution. **Note:** Dirt will prevent Velcro® adhesive from adhering well.
2. Peel plastic backing from Velcro and attach strips directly onto front and sides of vacuum as shown in Figure 1.

Important: Do not attach Velcro:
a. above vacuum's top door
b. onto or over vacuum's ventilation

3. For best results, install bumper 24-hours after attaching Velcro.
Note: Adhesive reaches maximum strength 24-hours after Velcro installation.

4. Center, stretch and attach the bumper as shown in Figure 2.
5. For each side, peel plastic backing from pre-attached Velcro and press bumper onto vacuum's side to secure in place as shown in Figure 3.

Important: Bumper must:
a. completely cover Velcro to prevent dirt from attaching to adhesive.
b. not hang below vacuum, as this will impede vacuum's performance.

Care Instructions

Remove dust and debris with a vacuum attachment or lint-roller.
Machine washable; air dry.

