

Front Access Light Installation Instructions

Model: 59350



Your G/G Front Access Light is designed to provide a chromatherapy system in your bath / spa and permit the replacement of the bulb from the front.

The Front Access Light has been specifically designed to enhance the enjoyment of your bath or spa.

Please read and follow all instructions carefully.

IMPORTANT SAFETY INSTRUCTIONS

You should have received safety instructions with your bath / spa. Please read and follow them carefully.

ELECTRICAL INSTRUCTIONS

WARNING – RISK OF ELECTRICAL SHOCK: Drain bath / spa and disconnect power before attempting to open lens.

INSTALLATION INSTRUCTIONS

- 1. Determine a suitable 3.5" flat surface for light placement.
- 2. Drill a 2.5" hole for the light assembly.
- 3. Insert the light assembly through the provided gasket and next insert the assembly into the hole.
- 4. Hand tighten the nut to approximately 15 ft-lbs.
- 5. Screw the white reflector onto the back of the light assembly.
- 6. Insert bayonet bulb into socket assembly and insert through reflector and twist lock into place.
- 7. If desired, a colored filter can be press fit onto the front of the light assembly.

INSTALLATION INSTRUCTIONS FOR OPTIONAL LED BULB

- 1. Determine a suitable 3.5" flat surface for light placement.
- 2. Drill a 2.5" hole for the light assembly.
- 3. Insert the light assembly through the provided gasket and next insert the assembly into the hole.
- 4. Hand tighten the nut to approximately 15 ft-lbs.
- 5. Insert the lamp socket assembly through reflector and twist lock into place.
- 6 .Insert the LED bulb into the lamp socket assembly.
- 7. Screw the white reflector with mounted LED bulb onto the back of the light assembly.

LIGHT FEATURES

- High impact clear light for Chromatherapy.
- Accepts both LED and standard 912 bulbs.
- Optional colored filters available for use with 912 bulb.
- Low voltage (12 v) UL recognized assembly.
- Transformer available in 120v and 240 volt.

RELAMP INSTRUCTIONS

WARNING - RISK OF ELECTRIC SHOCK:

- Drain bath / spa and disconnect power before attempting to open lens.
- Only open the lens of the light using the G/G lens insert tool provided for that purpose.
- Do not attempt relamping without the proper tool. Contact a qualified service professional if the tool is not available.

FOLLOW THE INSTRUCTIONS ON THE LENS INSERT TOOL PROVIDED.

- 1. Remove lens insert with tool.
- 2. Pull bulb straight out.
- 3. Gently push in new bulb.
- 4. Verify the o-ring is not damaged and is properly in place. Contact a qualified service professional if a replacement o-ring is needed.
- 5. Replace lens insert with tool.
- 6. Tight to align tool with notch.

IN THE ILLUSTRATIONS BELOW, LEFT TO RIGHT:

- 1. Remove lens with insert tool.
- 2. Remove lens. Pull bulb straight Out. Verify the o-ring is not damaged and is properly in place. Contact a qualified service professional if a replacement o-ring is needed.
- 3. Gently push in new bulb.
- 4. Replace lens insert with tool. Tighten to align tool with notch.









US Operations

1382 Bell Avenue, Tustin, California 92780

Main Number 1-714-384-0384 | Fax Number 1-714-384-0385 | Inside Sales 1-714-384-0384 | Tech Support 1-714-384-0384

28545 Livingston Avenue, Valencia, California 91355

Main Number 1-661-257-5700 | Fax Number 1-714-384-0385 | Inside Sales 1-714-384-0384 | Tech Support 1-714-384-0384

www.balboawatergroup.com

email: customerservice@balboawater.com

© 2009 Balboa Water Group Inc. All rights reserved. Your **Single Source** Solution. Disclaimer: Every endeavour has been made to publish the correct details in this data sheet. No responsibility will be taken for errors, omissions or changes in product specifications. Balboa Water Group reserves the right to change specifications.