

PULSAR 510 DL 3.0 TWIST VARIABLE VOLTAGE VAPE PEN | MANUAL

PULSAR®

510
DL 3.0

DISCREET
CARTRIDGE
VAPE

SPECS:

Size: 3.97 x 1.1 x 1.1 inches
(101 x 28 x 28mm)

Maximum Cartridge Size: 0.55 inches diameter,
2.4 inches length (14mm x 61mm)

Battery Capacity: 650mAh

Voltage: 2.8V-4.0V (1.8V Pre-heat) flex temp dial

Charging: USB-C

Resistance: 0.8-2.0 Ω

KIT INCLUDES:

1 x Pulsar 510 DL 3.0 Twist

1 x Bottom Magnetic Connector

POWER ON/OFF:

Quickly pull - draw in air, within 1.5 seconds - from mouthpiece 5 times to switch the power on or off. The light will flash once.

PRE-HEATING:

Quickly pull from mouthpiece twice to activate the pre-heat function.

CHANGE VOLTAGE SETTING:

Twist the dial on the base of the unit to change the setting.

CHARGING:

Charging: Red light

Fully charged: Green light

Low Battery: Red light will flash 10 times to alert user, and will then enter standby mode. Charge before continuing use.

PROTECTION FEATURES:

Battery life/cartridge protection: After 10 continuous seconds of use, the red light will flash 4 times, and the automatic vape time cutoff will activate, turning off the heat (but not the power).

Over-voltage/short-circuit protection: red light will flash 3 times, and device will fully turn off.

QUICK START:

1. Connect your device to a power source and charge until the light turns green.
2. Insert the 510-threaded cartridge (not included) of your choice.
3. Quickly pull 5 times to power on the device.
4. Twist the flex temp dial to change voltage to your preferred temperature.
5. Quickly pull twice to start pre-heating.
6. Pull from mouthpiece and enjoy.

INSTRUCTIONS:

1. Make sure that the bottom magnetic connector is properly connected to the bottom of the unit. The battery will not charge if the bottom connector is not attached.
2. Plug in USB-C cable and connect to a power source. You will see the light flash once when the battery is connected.
3. Allow the battery to fully charge before first use. The light will turn green. Disconnect the device from the power source before use.
4. Remove the bottom magnetic connector by twisting until it clicks, then pull out. Firmly screw in the 510-threaded cartridge of your choice.
5. Insert the cartridge into the device and ensure that the bottom magnetic connector is properly reconnected.
6. If the unit is powered off, place your lips on the mouthpiece and give it 5 quick pulls to power on.
7. Adjust the voltage by twisting the dial.
8. Activate the pre-heat function to prime the cartridge by giving the unit 2 quick pulls. This will activate the unit at 1.8V for 15 seconds. After 15 seconds, the unit will switch to your selected voltage.
9. Simply pull from mouthpiece to activate the cartridge vapor and enjoy your session!

CLEANING:

1. Remove the bottom magnetic connector from the battery.
2. Wipe the outside and inside of the bottom magnetic connector with an isopropyl alcohol pad. Use an alcohol swab to wipe any excess oil out of the 510 screw-in connector.
3. Clean the inside air pathway with an alcohol swab. Using a circular motion, work your way up and down the air pathway until you do not see any more oil.
4. Do not submerge any part of the device in cleaning solution. Allow all parts to air dry prior to resuming use.

! The mouthpiece is NOT removable. Attempting to remove it could impair or permanently disable the breath control functionality.



IMPORTANT SAFETY WARNINGS

Do not expose to extreme temperatures or direct sunlight.
Do not drop the device or accessories.
Do not drop or submerge in any liquid.
Do not modify the electronics in any way.

This device is intended for adults only. Do not sell or provide to minors. Keep all parts, concentrates, herbs, and liquids away from children and pets. This is not a medical device and is not intended to diagnose, treat, mitigate, cure, or prevent any ailment, disease, or other conditions. Consult a physician before use, especially if you suffer from heart disease or any other medical condition, or if you are pregnant or breastfeeding. Failure to follow any of these instructions could result in product damage, property damage, personal injury, and may void warranty.

PULSAR®
ENJOY HIGHER CULTURE™

Manufactured by Pulsar®
Asheville, NC 28806

Designed in USA, Made in China

PulsarVaporizers.com